Silonn SLIM17B-1

Silonn Nugget Ice Maker User Manual

Model: SLIM17B-1

Introduction

Thank you for choosing the Silonn Nugget Ice Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and retain it for future reference.



The Silonn Nugget Ice Maker, designed for countertop use, efficiently produces chewable nugget ice, perfect for various beverages.

Product Overview

The Silonn Nugget Ice Maker is engineered to provide a convenient and reliable source of nugget ice. Key features include:

- **Lightning-Fast Ice Production:** Capable of producing up to 33 lbs of ice per day, with the first batch ready in as little as 6 minutes.
- **Delicious Nugget Ice:** Produces soft, chewable nugget ice, ideal for smoothies, cocktails, sodas, and more, offering a satisfying crunch and texture.
- **Hassle-Free Maintenance:** Features a removable cover for easy access and a convenient automatic self-cleaning cycle.
- **Quiet Ice-Making:** Designed with a quiet cooling process, operating at only 47 dB, ensuring minimal disturbance.
- **Compact and Portable:** Its compact size makes it suitable for home, office, or party use.



Enjoy the unique chewable texture of nugget ice, perfect for enhancing your favorite drinks.

What's in the Box

Upon opening your Silonn Nugget Ice Maker package, please ensure all the following items are present:

- Silonn Nugget Ice Maker Unit
- Ice Scoop

- Ice Basket
- User Manual (this document)

Setup

1. **Unpacking:** Carefully remove the ice maker and all accessories from the packaging. Retain packaging for future transport or storage.
2. **Placement:** Place the ice maker on a flat, stable, and level surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit (at least 4 inches of space on all sides). If the unit has been tilted during transport, allow it to stand upright for at least 24 hours before plugging it in to allow the refrigerant to settle.



The compact design of the Silonn Nugget Ice Maker allows for easy placement on most countertops.

3. **Cleaning Before First Use:** Before using for the first time, clean the interior of the ice maker. Refer to the "Maintenance" section for detailed cleaning instructions.
4. **Power Connection:** Plug the ice maker into a grounded electrical outlet. Ensure the voltage matches the specifications of the unit.

Operation

1. **Add Water:** Open the top cover and fill the water reservoir with clean, filtered water up to the MAX fill line. Using


filtered water is recommended to prevent mineral buildup.

2. **Start Ice Production:** Press the "ICE/CLEAN" button once to begin the ice-making cycle. The "ICE" indicator light will illuminate.



Experience rapid ice production, with the first batch of nugget ice ready in approximately 6 minutes.

3. **Ice Collection:** The ice maker will automatically produce nugget ice and dispense it into the ice basket. The "ICE FULL" indicator light will turn on when the basket is full, and the unit will pause ice production.



The ice maker can produce up to 33 pounds of chewable nugget ice per day, ensuring a steady supply.

4. **Quiet Operation:** The Silonn Nugget Ice Maker operates with a quiet cooling process, minimizing noise during use.



Designed for quiet operation, the ice maker produces minimal noise, suitable for any environment.


5. **Low Water Indicator:** If the water level in the reservoir is too low, the "ADD WATER" indicator light will illuminate, and the unit will pause. Refill the reservoir to resume ice production.

Maintenance

Regular cleaning and maintenance are crucial for the longevity and optimal performance of your Silonn Nugget Ice Maker.

1. **Automatic Self-Cleaning Cycle:**

- Ensure the water reservoir is filled.
- Press and hold the "ICE/CLEAN" button for 5 seconds to activate the self-cleaning cycle.
- The unit will run a cleaning cycle, circulating water through its system.
- Once the cycle is complete, drain the water from the unit using the bottom water outlet.



The ice maker features a removable cover for thorough manual cleaning and an automatic self-cleaning function for convenience.

2. **Manual Cleaning:**
   - Unplug the ice maker before cleaning.
   - Remove the ice basket and the removable cover.

- Clean the interior surfaces, water reservoir, and ice basket with a soft cloth and a mild detergent. Rinse thoroughly with clean water.
- Drain all water from the unit.
- Dry all parts completely before reassembling and plugging in the unit.

3. **Descaling (Mineral Buildup Prevention):**

   If you live in an area with hard water (high mineral content), mineral buildup can occur, affecting performance and making cleaning difficult.

   - Use filtered water to minimize mineral deposits.
   - Perform descaling monthly, or more frequently in very hard water areas.
   - For descaling, use a solution of water and white vinegar or a commercial descaling agent specifically designed for ice makers. Follow the product's instructions for dilution and application.
   - Run the self-cleaning cycle with the descaling solution, then drain and rinse thoroughly with fresh water multiple times to remove any residue.

Troubleshooting

Before contacting customer support, please refer to the following troubleshooting guide for common issues:

Problem	Possible Cause	Solution
Unit not producing ice.	No water in reservoir. Power supply issue. Ambient temperature too high. Mineral buildup.	Fill water reservoir. Check power connection and outlet. Move unit to a cooler location. Perform descaling and thorough cleaning.
"ADD WATER" indicator is on.	Water level is low.	Add water to the reservoir up to the MAX fill line.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket. The unit will resume production automatically.
Ice melting quickly in the basket.	Ice maker is not a freezer. High ambient temperature.	Transfer ice to a freezer for storage. Ensure unit is in a cool, well-ventilated area.
Low ice production.	Insufficient water. Mineral buildup affecting ice-making components. Poor ventilation.	Ensure water is at MAX fill line. Perform descaling and thorough cleaning. Ensure adequate space around the unit for airflow.
Excessive noise during operation.	Unit not level. Normal operational sounds (compressor, water pump).	Ensure unit is on a flat, level surface. Some noise is normal for ice makers. If noise is unusual or very loud, contact support.

Specifications

Attribute	Detail
Brand	Silonn

Attribute	Detail
Model Name	Countertop Ice Maker, Nugget Ice Maker
Item Model Number	SLIM17B-1
Product Dimensions (W x D x H)	11.3 x 8.66 x 12.68 inches
Weight	21.1 Pounds
Ice Production Capacity	Up to 33 Pounds per 24 Hours
Wattage	160 watts
Frequency	60 hertz

Warranty and Support

For information regarding the product warranty, please refer to the warranty card included with your purchase or visit the official Silonn website.
Should you encounter any issues not covered in this manual or require further assistance, please contact Silonn Customer Support. Contact details are typically available on the manufacturer's website or on the product packaging.

© 2023 Silonn. All rights reserved.