

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Anker](#) /

> [Anker 100W USB C Charger Instruction Manual](#)

Anker A2672

Anker 100W USB C Charger Instruction Manual

Model: A2672

INTRODUCTION

Thank you for choosing the Anker 100W USB C Charger. This compact and powerful charger is designed to provide high-speed charging for a wide range of USB-C devices, from laptops to smartphones. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your charger to ensure optimal performance and safety.

WHAT'S IN THE BOX

- Anker 317 Charger (100W)
- 5ft / 1.5m USB C to USB C cable
- Welcome Guide



The Anker 100W USB C Charger and its accompanying 5ft USB-C to USB-C cable.

SETUP

Follow these simple steps to begin using your Anker 100W USB C Charger:

1. Unfold the prongs of the charger.
2. Plug the charger into a standard wall outlet.
3. Connect one end of the included USB-C to USB-C cable to the charger's USB-C port.
4. Connect the other end of the USB-C cable to your device (e.g., laptop, tablet, smartphone).

5. Ensure your device indicates that it is charging.



The Anker 100W USB C Charger connected to a wall outlet and charging a laptop.

OPERATING INSTRUCTIONS

High-Speed Charging

The Anker 100W USB C Charger delivers a powerful 100W output, enabling rapid charging for compatible devices. For example, it can charge a MacBook Pro 16" (M1 Max, 2021) to 100% in approximately 1 hour and 20 minutes, significantly

reducing downtime.

100W Fast Charging



Fully Charge a MacBook Pro 16" (M1 Max) in
1 H 29 Min

ANKER
— The World's —
NO.1
Mobile Charging Brand

100W
USB-C

Note: Data based on Anker internal testing charging a MacBook Pro 16" (M1 Max, 2021). Actual results may vary.

The charger's 100W output provides fast charging for high-power devices like the MacBook Pro.

Wide Compatibility

Equipped with Anker's proprietary PowerIQ 3.0 technology, this charger offers flawless compatibility with a vast array of mobile devices. It intelligently identifies your device to deliver the optimal charging speed, ensuring efficient and safe power delivery across different brands and models.

Charge Faster and Safer with the Included 5 ft Cable

5 ft



100W Max Output



E-Marker Cable



USB-C to USB-C



One charger for all your devices: The Anker 100W USB C Charger is compatible with a wide range of electronics.

Wide Compatibility

Others



Apple Watch Series
7 / 8 / Ultra

USB-C to USB-C Cable (Included)



MacBook Pro 16" (M2 Pro) /
(M1 Max, 2021)



HP Chromebook 14 /
Dell XPS 13 9360



iPad Pro 12.9" / 11" (M2) /
Air (9th Gen) / mini 6



Samsung S23 / S23 + /
S23 Ultra



Steam Deck

And More

USB-C to Lightning Cable (Not Included)



iPhone 14 Pro Max / 14 Pro / 14 /
13 Pro / 13 / 12 mini / 12 Pro



Airpods / Airpods Pro /
Airpods Pro 2 / Airpods 3

And More



Detailed compatibility list for the Anker 100W USB C Charger, including MacBooks, iPads, Samsung Galaxy phones, and more.

SAFETY FEATURES


Your safety and the safety of your devices are paramount. The Anker 100W USB C Charger incorporates exclusive ActiveShield safety technology. This system provides continuous 24/7 temperature monitoring, performing over 570,000 temperature checks per night to prevent overheating and ensure a secure charging experience.

Superior Safety with ActiveShield

Monitors Temperature

570,000*

Times Per Night



ActiveShield technology provides superior safety by monitoring temperature continuously.

MAINTENANCE

To ensure the longevity and optimal performance of your Anker 100W USB C Charger, follow these maintenance guidelines:

- **Cleaning:** Disconnect the charger from the power outlet and your devices before cleaning. Use a soft, dry cloth to wipe the surface. Avoid using liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the charger in a cool, dry place away from direct sunlight and extreme temperatures. The foldable prongs help protect the charger during storage and travel.

- **Cable Care:** Avoid sharp bends or kinks in the USB-C cable. Do not pull the cable forcefully when disconnecting; always grasp the plug.

TROUBLESHOOTING

If you encounter issues with your Anker 100W USB C Charger, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Device not charging	Loose connection; incompatible cable; device issue; power outlet issue.	Ensure all connections are secure. Use the included Anker USB-C cable. Test with a different device or cable. Try a different wall outlet.
Slow charging	Cable not supporting high wattage; device not supporting fast charging; background apps consuming power.	Use the original Anker USB-C to USB-C cable. Verify your device supports 100W USB-C PD charging. Close unnecessary applications on your device.
Charger feels warm	Normal operation during high-power charging; poor ventilation.	A warm charger is normal. Ensure adequate ventilation around the charger. If it becomes excessively hot or emits smoke/odor, disconnect immediately and contact support.
Charger not recognized by device	Outdated device firmware; cable issue.	Update your device's operating system/firmware. Try a different USB-C cable.

SPECIFICATIONS

Feature	Detail
Model Number	A2672
Product Dimensions	2.74 x 1.33 x 2.36 inches
Item Weight	10.6 ounces
Input Voltage	240 Volts (DC)
Connectivity Technology	USB
Connector Type	USB Type C
Special Feature	Fast Charging, Foldable Plug, ActiveShield Safety
Color	Black
Manufacturer	Anker
Country of Origin	China

WARRANTY AND CUSTOMER SUPPORT

Anker stands behind the quality of its products. The Anker 317 Charger (100W) comes with a worry-free 18-month warranty. If you encounter any issues or have questions regarding your product, please do not hesitate to contact our friendly customer service team. Refer to the contact information provided in your welcome guide or visit the official Anker website for support.