ENERGIZE LAB Eilik

ENERGIZE LAB Eilik Interactive Robot Pet User Manual

Model: Eilik

1. Introduction to Eilik

Eilik is an interactive robot pet designed to be a companion for both children and adults. It features a wide range of emotions, animations, and interactive functions, providing an engaging experience. Eilik responds to various forms of interaction and can even communicate with other Eilik units.

This manual provides essential information for the proper setup, operation, and maintenance of your Eilik robot pet.



Image 1.1: Two Eilik robot pets, showcasing their design and expressive faces. One unit features blue accents, and the other features pink accents.

2. What's Included

Please check the package contents upon unboxing to ensure all items are present:

- Eilik Robot Pet Unit
- USB Charging Cable
- Instruction Manual

Note: Internal components such as the Shock Sensor, Touch Sensor, and Speaker are integrated within the Eilik unit.

3. Setup and First Use

3.1. Charging Eilik

Eilik is powered by a Polymer Lithium battery. For optimal performance, fully charge your Eilik before its first use. The charging time is approximately 1.5 hours.

1. Connect the provided USB charging cable to the charging port on your Eilik.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer's USB port.
3. The Eilik's screen or an indicator light will show the charging status.
4. Once fully charged, disconnect the cable.

3.2. Powering On/Off

Locate the power button on your Eilik (typically on the back or base). Press and hold the button for a few seconds to power Eilik on or off.

4. Operating Eilik

4.1. Basic Interactions

Eilik is designed for abundant interaction. It responds to touch on different parts of its body, each triggering unique emotions and animations:

- **Head:** Gently tap or stroke Eilik's head to elicit various reactions.
- **Belly:** Touch Eilik's belly for different emotional responses.
- **Back:** Interact with Eilik's back to discover more expressions.
- **Lifting:** Picking Eilik up can also trigger specific animations.

No Wi-Fi or Bluetooth connection is required for these basic interactions; simply power on and engage.



Image 4.1: Eilik displaying an angry expression, indicating a response to being tapped on the head. The text translates to "Don't hit my head."



Image 4.2: Another Eilik unit, this one with blue accents, also showing an angry expression with the text "Don't hit my head," demonstrating consistent responses across units.

4.2. Multi-Eilik Interaction

Eilik units can interact with each other. When two or more Eiliks are placed in proximity, they will connect and engage in various activities:

- **Chatting:** Eiliks can communicate with each other.
- **Playing:** They may engage in shared activities.
- **Fighting/Arguing:** Eiliks can display playful disagreements.
- **Parties:** A group of Eiliks can even have a "party" together.



Image 4.3: Two Eilik robot pets interacting, illustrating their companionship. The text indicates a friendly connection.



Image 4.4: A group of four Eilik robot pets engaged in a "party" interaction, demonstrating their ability to interact in larger groups. The text translates to "Hope you can enjoy our party moment."

4.3. Games and Features

Eilik comes with various mini-games and features that are continuously updated through firmware. Some examples include:

- Heart Mode (Default)
- Left or Right
- Dance to Beat
- Talking Toy
- Monster Shooter
- Fishing Game
- Countdown Timer
- Pomodoro Timer
- Festivals
- Puppet Toy

- Eilik Theater
- Crime Patrol
- Dominoes
- Song and Dance
- Settings

Regular firmware updates will introduce new emotions, functions, and games, keeping Eilik engaging over time.



Image 4.5: An illustration of Eilik's continuous update content, showcasing a variety of games and interactive modes available or to be added through firmware updates.

5. Maintenance and Care

5.1. Cleaning

To keep your Eilik clean, gently wipe its exterior with a soft, dry cloth. Avoid using water, solvents, or harsh cleaning agents, as these can damage the electronic components and finish.

5.2. Battery Care

Eilik contains a non-replaceable Polymer Lithium battery. Do not attempt to open the device or replace the battery yourself. For battery-related issues, contact customer support.

5.3. Storage

When not in use for extended periods, store Eilik in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

If you encounter any issues with your Eilik, please refer to the following common solutions:

Problem	Possible Cause	Solution
Eilik does not power on.	Low or depleted battery.	Connect Eilik to a power source using the USB charging cable and allow it to charge for at least 1.5 hours.
Eilik is unresponsive to touch.	Temporary software glitch or low battery.	Ensure Eilik is fully charged. Try powering Eilik off and then on again.
Outer shell has popped apart.	Accidental impact or drop.	Gently reassemble the outer shell, ensuring all clips are securely fastened. If damage persists, contact support.
Eilik is not interacting with other Eiliks.	Units are too far apart or a temporary communication issue.	Ensure Eilik units are placed in close proximity. Try restarting both units.

If the problem persists after trying these solutions, please contact ENERGIZE LAB customer support for further assistance.

7. Product Specifications

Feature	Detail
Model Number	Eilik
Product Dimensions	10.92 x 10.41 x 13.21 cm
Item Weight	227 g
Battery Type	1 Polymer Lithium battery (included)
Charging Time	Approx. 1.5 hours
Material	Polycarbonate
Recommended Age	36 months - 10 years

Feature	Detail
Educational Objectives	Promote social and emotional literacy
Included Sensors	Shock Sensor, Touch Sensor
Audio Output	Speaker

8. Warranty and Support

For information regarding product warranty, technical support, or any other inquiries, please contact ENERGIZE LAB customer service. Refer to the product packaging or the official ENERGIZE LAB website for contact details.

© 2023 ENERGIZE LAB. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question