

[manuals.plus](#) /

› [JYX](#) /

› [JYX 66PRO Karaoke Machine Instruction Manual](#)

JYX 66PRO

JYX 66PRO Karaoke Machine Instruction Manual

Model: JYX-66PRO

[Battery](#) [Introduction](#) [Package Contents](#) [Setup](#) [Operating Instructions](#) [Charging & Troubleshooting](#) [Specifications](#) [Warranty & Support](#) [Portability](#) [Usage Scenarios](#) [Maintenance](#)

1. INTRODUCTION

The JYX 66PRO Karaoke Machine is a versatile PA system designed for various entertainment needs. It features 2 wireless microphones, vibrant RGB lighting, and comprehensive sound controls including treble and bass adjustments. This Bluetooth speaker supports live broadcasting, monitoring, and various sound effects, making it suitable for both adults and children.

Key Features:

- Spectacular Light Display:** Captivating and vibrant light ring for an electrifying ambiance.
- Portable Entertainment:** Lightweight design with a handle and shoulder strap for easy transport.
- Precise Sound Control:** Sensitive microphones with background noise filtering, plus extra microphone input holes.
- Extended Playtime:** Powerful 5200mAh battery provides up to 12 hours of use and recharges in 6 hours. Features a 5.25-inch subwoofer and 2-inch tweeter.
- Stereo Sound Bliss:** TWS (True Wireless Stereo) capability to connect two 66Pro machines for immersive stereo sound. Supports AUX, TF, and USB audio inputs.

2. PACKAGE CONTENTS

Please ensure all items are present upon unboxing:

- JYX 66PRO Karaoke Machine (Main Unit)
- 2 x Wireless Microphones
- Shoulder Strap
- Charging Cable (USB-C)
- Auxiliary Cable

- Remote Control
- User Manual



Image: The JYX 66PRO Karaoke Machine, two wireless microphones, and a remote control are displayed on a wooden table.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the karaoke machine and both wireless microphones. Use the provided charging cable for the main unit. Microphones are typically charged by inserting them into designated slots on the main unit or via separate charging ports if available.

3.2 Powering On/Off

- **Main Unit:** Locate the power button on the control panel and press and hold it to turn the unit on or off.
- **Microphones:** Press and hold the power button on each wireless microphone to turn it on or off. The microphones will automatically attempt to pair with the main unit.



Image: A close-up of the JYX 66PRO's top control panel, highlighting the power button, USB, TF card, AUX, microphone inputs, and various control knobs for mic volume, echo, bass, and treble.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Pairing

1. Turn on the JYX 66PRO Karaoke Machine. The display should show "BLUE" indicating Bluetooth mode.
2. Activate Bluetooth on your smartphone, tablet, or other audio device.
3. Search for "JYX-66PRO" in the list of available Bluetooth devices and select it to pair.
4. Once connected, you can stream music wirelessly from your device to the karaoke machine.

4.2 Microphone Usage

- **Power:** Press and hold the power button on the microphone to turn it on/off.
- **Volume:** Use the '+' and '-' buttons on the microphone to adjust its individual volume.
- **Echo/Effects:** The main unit's control panel has an "Echo" knob to adjust the echo effect for the microphones.
- **Vocal Cut/Accompaniment:** Some models feature a "5/Accompany" button to remove vocals from a

song, allowing you to sing along to the instrumental track.

4.3 Sound Control

The main unit features dedicated knobs for fine-tuning your audio:

- **Mic Vol:** Adjusts the overall volume of the microphones.
- **Echo:** Controls the intensity of the echo effect on the vocals.
- **Bass:** Adjusts the low-frequency audio output.
- **Treble:** Adjusts the high-frequency audio output.
- **Master Vol:** Controls the overall output volume of the karaoke machine.

4.4 Light Modes

The JYX 66PRO features a spectacular RGB light ring. Use the "O/LED" button on the control panel to cycle through different light modes or turn the lights off.



Image: The JYX 66PRO Karaoke Machine showcasing its vibrant, multi-colored RGB light display on the speaker grille.

4.5 Other Connectivity Options

- **USB/TF Card:** Insert a USB drive or TF card into the respective slots to play audio files directly.
- **AUX In:** Connect external audio devices using the provided auxiliary cable.

- **Mic In:** Additional 6.35mm input for wired microphones.
- **Guitar In:** Connect a guitar for live accompaniment.
- **Live/Monitor:** Dedicated ports for live broadcasting or monitoring your audio output.

5. CHARGING AND BATTERY LIFE

The JYX 66PRO is equipped with a powerful 5200mAh battery, offering up to 12 hours of continuous playback on a single charge. A full recharge takes approximately 6 hours.

- Connect the provided USB-C charging cable to the DC 5V port on the unit and to a suitable USB power adapter (not included).
- Ensure microphones are charged regularly.



Image: The JYX 66PRO Karaoke Machine with text overlays indicating its 12-hour playing time, 6-hour charging time, and 5200mAh battery capacity.

6. PORTABILITY

Designed for on-the-go entertainment, the 66PRO is lightweight and includes both a sturdy handle and a convenient shoulder strap. This allows for easy transport to any location, from friend's houses to outdoor

events.



Image: A woman carrying the JYX 66PRO Karaoke Machine using its shoulder strap, demonstrating its portability.

7. USAGE SCENARIOS

The JYX 66PRO is versatile for various occasions:

- **Karaoke Parties:** Enjoy singing with friends and family.
- **Live Broadcast/Monitoring:** Use dedicated ports for live streaming or audio monitoring.
- **Public Speaking/Meetings:** Use as a PA system for clear announcements.
- **Outdoor Events:** Its portability and long battery life make it ideal for picnics, beach trips, or outdoor gatherings.

Your browser does not support the video tag.

Video: A seller-provided video demonstrating a karaoke machine's features and usage in various settings. While the video title mentions Ikara, the content is relevant to general karaoke machine functionality and features like those found in the JYX 66PRO.

8. MAINTENANCE

- Keep the device clean by wiping it with a soft, dry cloth.
- Avoid exposing the unit to extreme temperatures, direct sunlight, or moisture.
- Store in a cool, dry place when not in use.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support for assistance.

9. TROUBLESHOOTING

- **No Power:** Ensure the unit is fully charged. Check the charging cable and power source.
- **No Sound:** Check volume levels on both the karaoke machine and your connected device. Ensure microphones are powered on and paired.
- **Microphone Not Working:** Ensure microphones are charged and powered on. Re-pair if necessary. Check microphone volume.
- **Bluetooth Disconnection:** Ensure your device is within range (typically 10 meters) and there are no obstructions. Try re-pairing the device.
- **Distorted Sound:** Reduce volume levels on both the unit and connected device. Check for proper cable connections if using AUX.

10. SPECIFICATIONS

Model	66Pro
Brand	JYX
Output Wattage	60 Watts
Number of Channels	2
Connectivity Technology	AUX, Bluetooth, USB
Compatible Devices	Guitar, Laptop, Smartphone, Television, iPhone
Material	Aluminum, Plastic
Item Weight	3.2 Kilograms
Product Dimensions	18.5 x 28.95 x 29.7 cm
UPC	730756414607

11. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your package or visit the official JYX website. Each item is verified by Transparency with a unique code for authenticity.

Manufacturer: JYX