

[Manuals.plus](#) /

> [Armitron](#) /

> Armitron Women's 75/5887 Crystal Accented Date Function Bracelet Watch User Manual

## Armitron 75/5887

# Armitron Women's 75/5887 Crystal Accented Date Function Bracelet Watch User Manual

Model: 75/5887

## INTRODUCTION

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Armitron Women's 75/5887 Crystal Accented Date Function Bracelet Watch. Please read this guide thoroughly to ensure proper use and care of your timepiece.

## PRODUCT OVERVIEW

The Armitron 75/5887 is a women's bracelet watch featuring a gold-tone finish, genuine crystal accents on the bezel, a mother-of-pearl dial, and a date calendar window. It is designed for everyday wear with a focus on style and functionality.





Image: Front view of the Armitron 75/5887 watch, showcasing the mother-of-pearl dial, crystal-accented bezel, and gold-tone bracelet.

## SETUP

### 1. Initial Inspection

Upon unboxing, carefully inspect the watch for any visible damage. Ensure the crown is pushed in against the watch case to prevent moisture entry and to ensure the watch is running.



Image: The Armitron watch presented in its original box, ready for unboxing and initial inspection.

## 2. Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch) out to the second position. You may feel two clicks.
2. **Adjust the hands:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back in completely against the watch case.

## 3. Setting the Date

Your watch features a date calendar window. To set the date:

1. **Pull out the crown:** Gently pull the crown out to the first position (one click).

2. **Adjust the date:** Turn the crown counter-clockwise to advance the date. Avoid setting the date between 9 PM and 3 AM, as this is when the watch's internal mechanism is engaged in changing the date, and manual adjustment during this period can cause damage. If the current time falls within this window, first advance the time past 3 AM, then set the date.
3. **Push in the crown:** Once the date is set, push the crown back in completely against the watch case.

#### 4. Bracelet Adjustment

The watch features an adjustable link bracelet. For proper fit, it may be necessary to remove or add links. This procedure typically requires specialized tools and is best performed by a qualified jeweler or watch repair professional to avoid damaging the bracelet or watch.





Image: Side view of the Armitron 75/5887 watch, highlighting the crown for time and date adjustments.

## OPERATING THE WATCH

### Reading the Time and Date

Once set, the watch will display the current time with its hour, minute, and second hands. The date will be visible in the date calendar window on the dial.

### Water Resistance

This watch is water resistant to 165 feet (50 meters). This rating means the watch is suitable for short periods of recreational swimming, but not for diving or snorkeling. Avoid operating the crown while the watch is wet or submerged to prevent water intrusion.

## MAINTENANCE

### Cleaning

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. For the bracelet, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish, crystals, or seals.

### Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the watch stops running, it indicates the battery needs replacement. Battery replacement should be performed by a qualified watch technician to ensure the correct battery type is used and the water resistance seal is properly maintained.

### Crystal Care

The watch features a mineral crystal lens. While durable, it is not scratch-proof. Avoid contact with abrasive surfaces to prevent scratches. The bezel is set with genuine crystals; handle with care to prevent dislodging them.

### Water Resistance Precautions

- Do not operate the crown or pushers (if any) while the watch is submerged or wet.
- Avoid exposing the watch to extreme temperature changes, which can affect the water resistance seals.

- Have the water resistance seals checked periodically, especially after battery replacement, to ensure continued protection.

## TROUBLESHOOTING

| Problem                       | Possible Cause                                                      | Solution                                                                                                                                               |
|-------------------------------|---------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Watch not running             | Dead battery; crown not pushed in; internal movement issue.         | Ensure crown is fully pushed in. If not, replace battery by a professional. If still not running, seek professional repair.                            |
| Date not changing at midnight | Time set incorrectly (e.g., AM/PM confusion); date mechanism issue. | Advance the time by 12 hours. If the date changes, the watch was set to PM instead of AM. Reset the time. If issue persists, seek professional repair. |
| Condensation under crystal    | Water intrusion; sudden temperature change.                         | Immediately take the watch to a professional for inspection and drying to prevent internal damage.                                                     |

## SPECIFICATIONS

- **Model Number:** 75/5887
- **Brand:** Armitron
- **Movement:** Quartz
- **Case Material:** Base Metal (Gold-tone finish)
- **Bezel:** Set with multicolored genuine crystals
- **Dial:** Mother-of-pearl with date calendar window, gold-tone hands and markers, black outer minute track
- **Crystal:** Mineral
- **Bracelet:** Gold-tone adjustable link bracelet with fold-over clasp and double push-button safety
- **Water Resistance:** 165 feet (50 meters)
- **Approximate Package Dimensions:** 4.13 x 3.11 x 2.87 inches
- **Approximate Item Weight:** 7.58 ounces





Image: Back view of the Armitron 75/5887 watch, showing the stainless steel case back and bracelet clasp.

## WARRANTY AND SUPPORT

Armitron watches typically come with a limited warranty covering manufacturing defects. For specific warranty details, claims, or service inquiries, please refer to the warranty card included with your purchase or visit the official Armitron website. You can also find more information and contact options on the [Armitron Brand Store](#).

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0C1HQMBWJ>

More documents and user manuals: <https://manuals.plus/>