TCL 43S450G

TCL 43-Inch Class S4 4K LED Smart TV

Model: 43S450G User Manual

1. Introduction and Overview

This manual provides essential information for setting up, operating, and maintaining your TCL 43-Inch Class S4 4K LED Smart TV. This television offers stunning 4K HDR picture quality, Google TV Smart OS, and advanced audio features for an immersive entertainment experience.




Figure 1: Front view of the TCL 43-Inch Class S4 4K LED Smart TV.

2. What's in the Box

Carefully unpack the box and ensure all items are present:

- TCL TV with Google TV
- TV Stands (2)
- TV Remote + Batteries (2 AA batteries included)
- Power Cord
- Quick Start Guide



Figure 2: Illustration showing the TV dimensions, remote control, and included accessories.

3. Setup

Follow these steps to set up your new TCL TV:

1. **Attach the Stands:** Place the TV face down on a soft, clean surface. Align the TV stands with the screw holes on the bottom of the TV and secure them with the provided screws.
2. **Connect Power:** Plug the power cord into the TV's power input, then into a wall outlet.
3. **Connect Devices:** Connect your external devices (e.g., cable box, gaming console, Blu-ray player) to the HDMI ports on the back of the TV.

4. **Insert Batteries into Remote:** Open the battery compartment on the back of the remote control and insert the two AA batteries, observing polarity.
5. **Initial Setup:** Power on the TV using the remote. Follow the on-screen instructions to connect to your Wi-Fi network, sign in with your Google account, and complete the initial setup process.



Figure 3: Front view of the TV, ready for setup.

4. Operating Instructions

Your TCL TV features the Google TV Smart OS, providing a user-friendly interface for accessing content and apps.

4.1. Power On/Off

Press the **Power** button on the remote control to turn the TV on or off.

4.2. Remote Control and Voice Assistant

The included voice remote allows for easy navigation and voice commands. Press the**Google Assistant** button to

activate the voice assistant and search for content, control smart home devices, or get information.



Figure 4: The Google TV interface with the voice remote control.

4.3. Navigating Google TV

Use the directional pad and **OK** button on the remote to navigate through menus, select apps, and browse content. The **Home** button returns you to the main Google TV screen.

5. Key Features

5.1. 4K Ultra HD Resolution

Experience incredible detail and clarity with four times the resolution of Full HD, bringing your favorite movies and shows to life.



Figure 5: Visual representation of 4K Ultra HD Resolution.

5.2. Motion Rate 240 with MEMC Frame Insertion

This technology combines multiple motion enhancement techniques to deliver exceptional motion clarity, reducing blur in fast-paced scenes like sports and action movies.



Figure 6: Depiction of Motion Rate 240 technology in action.

5.3. HDR PRO (Dolby Vision, HDR10, & HLG)

Enjoy enhanced contrast, accurate colors, and fine details across a wider range of brightness levels, supported by leading HDR formats.



Figure 7: Screen displaying content with HDR PRO.

5.4. FullView Metal Bezel-less Design

The elegant edge-to-edge design minimizes bezels, providing a more immersive viewing experience and a modern aesthetic that blends seamlessly into any home decor.




Figure 8: Close-up of the FullView Metal Bezel-less Design.

6. Connectivity

The TV offers various connectivity options for your devices:

- **3 HDMI Inputs (One with eARC):** Connect multiple high-definition devices such as gaming consoles, set-top boxes, and AV receivers. The eARC (enhanced Audio Return Channel) port allows for high-quality audio transmission to compatible sound systems.
- **Wi-Fi:** Built-in Wi-Fi for seamless internet access and streaming.
- **Chromecast Built-in:** Wirelessly cast content from your compatible smartphone, tablet, or computer directly to the TV.
- **USB Port:** For media playback from USB storage devices.
- **Ethernet Port:** For a wired internet connection.
- **Optical Digital Audio Output:** For connecting to external audio systems.



Figure 9: Rear view of the TV showing HDMI, USB, Ethernet, and other input/output ports.

7. Audio Features

Enhance your listening experience with advanced audio technologies:

- **DTS Virtual:X:** Provides advanced audio post-processing to create an immersive, virtualized 3D sound experience using only the TV's built-in speakers.
- **Bluetooth Personal Audio:** Easily pair your favorite Bluetooth headphones or speakers to the TV for a private listening experience without disturbing others.



Figure 10: TV screen displaying the Bluetooth logo, indicating personal audio connectivity.

8. Gaming Features

Optimized for a responsive gaming experience:

- **Auto Game Mode (ALLM):** Automatically enables game mode when a compatible gaming console is detected, ensuring the lowest possible input lag and latency for smooth gameplay.



Figure 11: TV screen showing a game, highlighting Auto Game Mode.

9. Maintenance

To ensure the longevity and optimal performance of your TV, follow these maintenance guidelines:

- **Cleaning the Screen:** Gently wipe the screen with a soft, dry microfiber cloth. For stubborn smudges, lightly dampen the cloth with water or a screen-cleaning solution specifically designed for electronics. Avoid using harsh chemicals or abrasive materials.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Do not use water or other liquids directly on the TV.
- **Ventilation:** Ensure proper ventilation around the TV. Do not block the ventilation openings on the back or sides of the TV. Allow sufficient space for air circulation.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, discontinue use and contact customer support for a replacement.
- **Unplug When Not in Use:** If the TV will not be used for an extended period, it is advisable to unplug it from the power outlet.

10. Troubleshooting

If you encounter issues with your TV, try the following common troubleshooting steps:

- **No Power:** Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Try plugging another device into the same outlet to confirm it has power.
- **No Picture/Sound:** Verify that the correct input source is selected. Check all cable connections between the TV and external devices. Try power cycling the TV by unplugging it for 60 seconds and then plugging it back in.
- **Remote Not Working:** Check the batteries in the remote control and replace them if necessary. Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Poor Picture Quality:** Adjust picture settings (brightness, contrast, color) in the TV's menu. Ensure your content source is high-quality (e.g., 4K content for 4K display).
- **Network Connection Issues:** Restart your Wi-Fi router. On the TV, go to Network Settings and try reconnecting to your Wi-Fi network.

For more detailed troubleshooting, refer to the complete User Manual PDF available online:TCL 43S450G User Manual (PDF)

11. Specifications

Feature	Description
Brand Name	TCL
Model Number	43S450G
Screen Size	43 Inches
Display Technology	LED
Resolution	4K Ultra HD (3840 x 2160)
Refresh Rate	60 Hz
HDR Support	Dolby Vision, HDR10, HLG
Smart OS	Google TV
Audio Technology	DTS Virtual:X
Connectivity	3 HDMI (1 eARC), Wi-Fi, Ethernet, USB
Special Features	Chromecast Built-in, Auto Game Mode (ALLM), Bluetooth Personal Audio, FullView Metal Bezel-less Design
Product Dimensions (D x W x H)	3.1" x 37.7" x 22" (without stand)
Item Weight	21 Pounds

12. Warranty and Support

Your TCL TV comes with a limited manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical support, service, or warranty claims, please visit the official TCL support website or contact their customer service line.
For additional information and resources, including the full user manual, visit the TCL support page or the product's Amazon listing.

© 2023 TCL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question