

[Manuals.plus](#) /

› [DICKIE TOYS](#) /

› DICKIE TOYS Parkin G Garage 203339000 Instruction Manual

DICKIE TOYS 203339000

DICKIE TOYS Parkin G Garage 203339000 Instruction Manual

Model: 203339000

1. INTRODUCTION

Thank you for choosing the DICKIE TOYS Parkin G Garage. This instruction manual provides essential information for the safe assembly, operation, and maintenance of your new toy. Please read this manual thoroughly before use and retain it for future reference.



Image 1.1: The DICKIE TOYS Parkin G Garage, showcasing its multi-level structure, ramps, and included vehicles.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Adult supervision is recommended during assembly and play.
- Keep packaging materials away from children to prevent suffocation.
- Do not modify the product. Use only original parts and accessories.
- Ensure all parts are securely connected before play to prevent detachment.
- Batteries should be inserted with the correct polarity. Do not mix old and new batteries, or different types of batteries. Remove exhausted batteries promptly.

3. PACKAGE CONTENTS

Please check the package to ensure all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.



Image 3.1: Product packaging illustrating the main components and features.

The package typically includes:

- Multi-level garage structure components (pillars, parking decks)
- Connecting ramps and tracks
- Base playmat
- Manual lift mechanism
- Light and sound module
- Assorted toy vehicles (e.g., cars, helicopter)
- Small accessories (e.g., flags, signs)
- Instruction Manual (this document)

4. ASSEMBLY AND SETUP

Assembly should be performed by an adult. Follow these steps carefully:

1. **Prepare the Base:** Unfold the base playmat on a flat, stable surface.
2. **Assemble the Main Tower:** Connect the vertical pillars and parking deck sections according to the numbered slots. Ensure each piece clicks securely into place.
3. **Attach Ramps:** Connect the various ramps and tracks to their designated levels and the main tower. Pay attention to the direction of the ramps for smooth vehicle movement.
4. **Install Light and Sound Module:** Locate the light and sound module. Open the battery compartment using a small screwdriver (not included). Insert 2 AAA batteries, ensuring correct polarity (+/-). Close the compartment. Attach the module to the top of the main tower.
5. **Attach Manual Lift:** Secure the manual lift mechanism to its designated position on the garage structure.
6. **Add Accessories:** Place flags, signs, and other small accessories into their respective slots on the garage and playmat.
7. **Final Check:** Verify that all connections are firm and stable before allowing children to play.

5. OPERATING INSTRUCTIONS

The Parkin G Garage offers various interactive features for engaging play:

- **Using the Manual Lift:** Place a toy car onto the lift platform. Rotate the knob or crank (if applicable) to raise or lower the car between parking levels.
- **Light and Sound Features:** Press the button on the light and sound module (located at the top of the main tower) to activate realistic garage sounds and flashing lights.
- **Ramp Play:** Place toy cars at the top of the ramps and release them to watch them descend through the garage levels. The garage features ramps that allow cars to change directions.

LIGHT & SOUND

WITH LIFT



Image 5.1: Close-up view highlighting the light and sound module and the manual lift mechanism.




Image 5.2: Illustrates the multi-directional ramps for dynamic vehicle movement.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the garage and accessories with a soft, damp cloth. Do not immerse electronic components (light and sound module) in water. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the toy in a clean, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Replacement:** Replace batteries when lights dim or sounds become faint. Always use new, identical batteries.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lights/Sounds not working	Batteries are dead or inserted incorrectly. Battery compartment is not closed properly.	Replace batteries with new ones, ensuring correct polarity. Ensure the battery compartment cover is securely fastened.
Parts do not connect securely	Incorrect alignment. Obstruction in the connection point.	Re-align the parts and apply gentle, firm pressure until they click. Check for any debris or foreign objects in the connection points.
Cars get stuck on ramps	Ramps are not fully connected or aligned. Using non-compatible vehicles.	Ensure all ramp sections are securely attached and properly aligned. Use only the included vehicles or other small, compatible toy cars.

8. SPECIFICATIONS

- **Model Number:** 203339000
- **Brand:** DICKIE TOYS
- **Product Dimensions (Assembled):** Approximately 3.74 x 29.92 x 16.34 inches (9.5 x 76 x 41.5 cm)
- **Item Weight:** Approximately 5.5 pounds (2.5 kg)
- **Recommended Age:** 3+ years (Note: Always supervise younger children due to small parts.)
- **Batteries Required:** 2 x AAA (not included)

9. WARRANTY AND SUPPORT

DICKIE TOYS products are manufactured to high-quality standards. For warranty information, product support, or to inquire about replacement parts, please contact your local DICKIE TOYS distributor or visit the official DICKIE TOYS website.

Contact Information:

- **Website:** www.dickietoys.de/en/ (or relevant regional website)
- Refer to product packaging for specific regional contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C1LNWWCK>

More documents and user manuals: <https://manuals.plus/>