

[Manuals.plus](#) /

> [usikey](#) /

> [usikey 67-inch Tall Bathroom Cabinet Instruction Manual](#)

usikey cabinet

usikey 67-inch Tall Bathroom Cabinet Instruction Manual

Model: cabinet | Brand: usikey

INTRODUCTION

Thank you for choosing the usikey 67-inch Tall Bathroom Cabinet. This versatile storage unit is designed to provide ample storage space with its adjustable shelves and two doors, suitable for various rooms including bathrooms, living rooms, and home offices. This manual contains important information regarding the assembly, safe operation, and maintenance of your new cabinet. Please read it thoroughly before beginning assembly and retain it for future reference.





This image shows the usikey 67-inch Tall Bathroom Cabinet in its assembled, closed state, highlighting its sleek white finish and compact design.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always assemble the cabinet on a clean, flat, and soft surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Use the provided anti-tip kit to secure the cabinet to a wall. This is crucial to prevent tipping, especially in households with children or pets.
- Do not overload shelves. Refer to the specifications for weight limits.

- Keep small parts and packaging materials away from children.
- Periodically check all connections and fasteners to ensure they remain tight.



This image illustrates the anti-dumping device and reinforcement device located on the back of the cabinet, essential for securing it to a wall and enhancing stability.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact customer support.

- Cabinet panels (sides, top, bottom, back)
- Adjustable shelves (6 total)
- Doors (2 total)
- Drawer components
- Wooden legs (4 total)
- Hardware kit (screws, dowels, hinges, drawer slides, magnetic door catches, black knobs, anti-tip kit)
- Assembly instructions manual

ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the numbered steps in the included pictorial instruction manual carefully. A general overview of the assembly process is provided below.

1. **Prepare the Area:** Clear a spacious, flat, and soft area for assembly to prevent damage to the cabinet parts.
2. **Identify Parts:** Unpack all components and identify them using the parts list in your detailed manual.
3. **Assemble the Frame:** Connect the side panels to the base and top panels using the provided hardware.
4. **Install Shelves:** Insert shelf pins into the desired holes and place the adjustable shelves.
5. **Assemble Drawer:** Follow the specific instructions for assembling the drawer and installing its slides.
6. **Attach Doors:** Secure the hinges to the doors and then attach the doors to the cabinet frame. Adjust hinges as needed for proper alignment.
7. **Install Legs and Knobs:** Attach the four wooden legs to the bottom of the cabinet and the black knobs to the doors and drawer.
8. **Secure with Anti-Tip Kit:** Crucially, attach the anti-tip device to the top rear of the cabinet and secure it to a wall stud using appropriate wall anchors.



This image displays two assembled usikey tall storage cabinets, one with doors closed and another with doors open, revealing the internal adjustable shelves and a central drawer. This provides a visual reference for the completed assembly.



This diagram provides detailed dimensions of the cabinet, including overall height (67"), width (15.7"), depth (11.8"), and internal measurements for shelves and the drawer, aiding in assembly and placement planning.

OPERATING INSTRUCTIONS

Your usikey cabinet is designed for versatile storage. Here's how to utilize its features:

- **Adjustable Shelves:** The cabinet features adjustable shelves in both the upper and lower sections. To adjust, remove items from the shelf, lift the shelf, remove the shelf pins from their current holes, reinsert them into the desired holes, and then place the shelf back on the pins.
- **Doors:** The two doors provide concealed storage. Use the black knobs to open and close them. Magnetic catches ensure the doors remain securely closed.
- **Drawer:** The central drawer offers additional storage for smaller items. Pull the knob to open and push to close.



Adjustable shelf



Magnetic door



Black Knobs



Anti-dumping device

This detailed image highlights key features: the adjustable shelves with numbered positions, a magnetic door catch for secure closure, the black knobs for opening doors and drawer, and the anti-dumping device for wall attachment.

MAINTENANCE

Proper care will extend the life and appearance of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage to the particleboard.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Environment:** Avoid placing the cabinet in direct sunlight or near heat sources to prevent warping or fading.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Not properly secured to the wall; loose fasteners; uneven floor.	Ensure the anti-tip kit is correctly installed and secured to a wall stud. Tighten all assembly screws. Place shims under legs if the floor is uneven.
Doors do not close properly or are misaligned.	Hinges are loose or incorrectly adjusted; magnetic catches are misaligned.	Adjust the screws on the hinges to align the doors. Ensure magnetic catches are securely fastened and aligned with the door plates.
Drawer does not slide smoothly.	Drawer slides are misaligned or damaged; debris in the tracks.	Check that the drawer slides are installed correctly and are free of obstructions. Re-align if necessary.

SPECIFICATIONS

Brand: usikey

Model Name: cabinet

Color: White

Product Dimensions: 11.8"D x 15.7"W x 67"H

Material: Engineered Wood (Particle Board)

Number of Shelves: 6 (adjustable)

Number of Doors: 2

Weight Limit: 150 Pounds (total)

Mounting Type: Floor Mount (with anti-tip wall anchor)

Assembly Required: Yes

Item Weight: 39.9 pounds

WARRANTY AND SUPPORT

usikey is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, for any questions, concerns, or assistance with your product, please contact usikey customer support. We aim to reply to all inquiries within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official usikey website.