

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [SkyGive](#) /

> SkyGive Wireless Keyboard and Mouse Combo User Manual (Model: Retro Round Keycaps Combo)

SkyGive Retro Round Keycaps Combo

SkyGive Wireless Keyboard and Mouse Combo User Manual

Model: Retro Round Keycaps Combo

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your SkyGive Wireless Keyboard and Mouse Combo. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

2. SAFETY INFORMATION

- Keep the device away from water and other liquids.
- Avoid exposing the device to extreme temperatures.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if issues arise.
- Dispose of batteries according to local regulations.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Wireless Keyboard
- 1 x Wireless Mouse
- 1 x USB Receiver (stored inside the mouse battery compartment)
- 1 x USB to Type-C Adapter
- 2 x AA Batteries (1 for keyboard, 1 for mouse)
- 1 x User Manual (this document)



Image: The SkyGive Wireless Keyboard and Mouse Combo, showing the keyboard, mouse, and USB receiver with a Type-C adapter.

4. SETUP INSTRUCTIONS

4.1. Battery Installation

1. **For the Keyboard:** Locate the battery compartment on the underside of the keyboard. Open the cover and insert one AA battery, ensuring correct polarity (+/-). Close the cover.
2. **For the Mouse:** Locate the battery compartment on the underside of the mouse. Open the cover and insert one AA battery, ensuring correct polarity (+/-). The USB receiver is typically stored inside this compartment; remove it before inserting the battery. Close the cover.



Image: Underside of the wireless mouse, illustrating the battery compartment and the slot for the USB receiver.

4.2. Connecting to Your Device

1. Retrieve the USB receiver from the mouse's battery compartment.
2. **For Standard USB-A Ports:** Plug the USB receiver directly into an available USB-A port on your computer

(desktop, laptop, Chromebook, etc.).

3. **For USB-C Ports (e.g., newer MacBooks):** Attach the provided USB to Type-C adapter to the USB receiver, then plug the adapter into your computer's USB-C port.
4. Turn on the mouse using the power switch located on its underside. The keyboard does not typically have a separate power switch and activates upon key press once the receiver is connected.
5. Your computer should automatically detect and install the necessary drivers. No additional software is required.



Image: Demonstrates the USB receiver and Type-C adapter for broad compatibility with different computer ports.

5. OPERATING INSTRUCTIONS

5.1. Basic Usage

- Once connected, the keyboard and mouse are ready for immediate use.
- The keyboard features a full-size layout with a numeric pad for enhanced productivity.
- The mouse has a comfortable, ergonomic design for extended use.

5.2. Multimedia Hotkeys (Keyboard)

The keyboard is equipped with 15 multi-functional hotkeys accessible via the **Fn** key. Press and hold the **Fn** key, then press the corresponding F-key for the desired function:

Key Combination	Function
Fn + Esc	Music Player
Fn + F1	Play/Pause
Fn + F2	Previous Track
Fn + F3	Next Track
Fn + F4	Volume Up
Fn + F5	Volume Down
Fn + F6	Mute

Key Combination	Function
Fn + F7	Web Browser
Fn + F8	Search
Fn + F9	Favorites
Fn + F10	Email
Fn + F11	Lock Screen
Fn + F12	Windows Key



Image: Detailed view of the keyboard highlighting the 15 multi-functional hotkeys and their corresponding functions.

5.3. Power Saving Mode

- The optical mouse automatically enters power-saving mode after 20 seconds of inactivity.
- To awaken the mouse, simply move it.
- The keyboard also features an intelligent auto-sleep functionality to conserve power during periods of inactivity. Press any key to wake it up.




Image: Visual representation of the smart auto-sleep mode, which helps conserve battery life for both the keyboard and mouse.

5.4. Ergonomic Design

- The keyboard features built-in folding stands on the underside, allowing you to adjust the typing angle for improved ergonomics and comfort during long typing sessions.
- The mouse is designed with a comfortable pebble shape to effectively relieve wrist stress.



Image: Close-up view of the keyboard's underside, showing the sturdy folding stands that provide an ergonomic tilt.

6. MAINTENANCE

6.1. Cleaning

- To clean the keyboard, gently remove the keycaps. They are designed to be detachable for easy cleaning.
- Use a soft, dry cloth to wipe down the surfaces of both the keyboard and mouse.
- For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the internal components.



Image: Close-up view of the keyboard demonstrating removable keycaps, facilitating easy cleaning and maintenance.

6.2. Battery Replacement

- When the devices stop responding or the indicator light (if present) signals low power, replace the AA batteries in both the keyboard and mouse.
- Follow the battery installation steps in Section 4.1.

7. TROUBLESHOOTING

- **Device not responding:** Ensure batteries are correctly installed and charged. Verify the USB receiver is securely plugged into your computer's port. Try plugging the receiver into a different USB port.
- **Lag or Disconnection:** Ensure the devices are within the 10-meter operating range of the USB receiver. Avoid obstructions between the devices and the receiver. Check for potential interference from other wireless devices.
- **Mouse cursor erratic:** Clean the optical sensor on the underside of the mouse. Ensure you are using the mouse on a suitable surface.
- **Keys not typing correctly:** Ensure keycaps are properly seated. If issues persist, try removing and re-inserting the USB receiver.

8. SPECIFICATIONS

Feature	Detail
Brand	SkyGive
Model	Retro Round Keycaps Combo
Connectivity Technology	2.4GHz Wireless (USB Receiver)
Compatibility	Windows XP/Vista/7/8/10/X, Mac, PC, Laptops, Chromebooks
Special Feature	Ergonomic design, Retro Round Keycaps, Full-size keyboard with numeric pad, Intelligent Power Conservation
Power Source	AA Batteries (included)

Feature	Detail
Wireless Range	Up to 10 meters
Item Weight	2.07 pounds

9. WARRANTY AND SUPPORT

- **Warranty:** This product comes with a one-year warranty.
- **Return Policy:** A 30-day hassle-free return policy is available.
- **Customer Service:** 24/7 prompt and friendly customer service is provided.
- **USB Connector Replacement:** If the USB connector is broken, a new one can be re-sent for free.

For further assistance, please refer to the contact information provided with your purchase or visit the official SkyGive website.