Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

truke B141

truke BTG Storm Gaming Earbuds User Manual

Model: B141

Introduction

Welcome to the truke BTG Storm Gaming Earbuds user manual. These earbuds are designed to provide an immersive audio experience for gaming and music, featuring ultra-low latency, powerful titanium drivers, and environmental noise cancellation. Please read this manual carefully to ensure proper use and maintenance of your device.



Image: truke BTG Storm Gaming Earbuds and Charging Case. The earbuds are black with green LED accents, resting in their black charging case which features RGB lighting along the front edge.

Package Contents

Ensure all items are present in the package:

- Wireless Charging Case
- Type-C USB Cable
- 2 Pairs (S & L) extra Eartips
- Warranty Card
- User Manual (this document)

Setup

1. Initial Charging

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the Type-C USB cable to the charging port on the case and to a power source (e.g., USB wall adapter, computer USB port).
3. The LED indicators on the case will show charging status. Allow approximately 1.5-2 hours for a full charge.



Image: truke BTG Storm Earbuds in their charging case, illustrating the 50-hour playtime and fast charging capability. The case displays vibrant RGB lighting.

2. Pairing with Your Device

The truke BTG Storm earbuds feature Instant Pairing technology.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "truke BTG Storm" in the list of available Bluetooth devices.

4. Select "truke BTG Storm" to connect. Once connected, you will hear a confirmation tone.

Note: After initial pairing, the earbuds will automatically connect to the last paired device when removed from the case, provided Bluetooth is enabled on the device.



Image: truke BTG Storm Earbuds in their open charging case, highlighting the instant pairing feature. The case's RGB lights are visible.

Operating Instructions

Touch Controls

The truke BTG Storm earbuds feature intuitive touch controls:

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer/End Call

Action	Function
Double Tap (L)	Previous Track
Double Tap (R)	Next Track
Triple Tap (L/R)	Activate Gaming Mode / Deactivate Gaming Mode
Long Press (2s) (L/R)	Activate Voice Assistant
Long Press (3s) (L/R) during call	Reject Call

Gaming Mode (40ms Ultra-Low Latency)

Triple tap either earbud to switch between normal mode and gaming mode. Gaming mode provides ultra-low latency for a competitive edge in gaming.



Image: truke BTG Storm charging case, emphasizing its 40ms ultra-low latency feature for gaming. A game controller is visible in the

foreground.

Environmental Noise Cancellation (ENC)

The dual-mic ENC technology ensures clear communication during calls by filtering out ambient noise. This feature is active automatically during calls.



Image: A woman wearing a truke BTG Storm earbud, with visual effects suggesting environmental noise cancellation. This highlights the clarity of calls.

Maintenance and Care

- Clean the earbuds and charging case regularly with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents.
- Keep the charging contacts on both the earbuds and the case clean to ensure proper charging.
- Store the earbuds in the charging case when not in use to protect them and conserve battery.
- The earbuds are IPX5 water resistant, meaning they can withstand light splashes and sweat. Do not submerge

them in water.



Image: truke BTG Storm Earbuds partially submerged in water, demonstrating their IPX5 water resistance rating. This indicates protection against splashes and sweat.

Troubleshooting

Problem	Possible Solution
Earbuds not pairing	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "truke BTG Storm" from your device's Bluetooth list and re-pair. ◦ Place earbuds back in the case, close, wait 5 seconds, then open again.

Problem	Possible Solution
Only one earbud working	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the case, close, wait 5 seconds, then open again. ◦ Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if needed).
Low volume or poor sound quality	◦ Adjust volume on your device. ◦ Clean earbud mesh and eartips. ◦ Ensure eartips provide a good seal in your ear. ◦ Check for obstructions in the audio path.
Charging issues	◦ Ensure charging cable is securely connected. ◦ Clean charging contacts on earbuds and case. ◦ Try a different USB port or power adapter.

Specifications

Feature	Detail
Model Name	BTG Storm
Model Number	B141
Connectivity Technology	Wireless (Bluetooth 5.3)
Driver Size	13mm Titanium Speakers
Latency	Up to 40ms (Gaming Mode)
Playtime	Up to 10 hours (earbuds), Up to 50 hours (with charging case)
Noise Control	Environmental Noise Cancellation (ENC)
Water Resistance	IPX5 Water Resistant
Charging Port	Type-C USB
Item Weight	40 Grams
Product Dimensions	5.8 x 3 x 5.9 cm
Batteries	3 Lithium Polymer batteries (included)

Warranty and Support

The truke BTG Storm Gaming Earbuds come with a **12-month warranty** from the date of purchase. For warranty claims, technical support, or any inquiries, please contact truke customer care.

- **Customer Care Number:** +91 9354170767
- **Email ID:** support@eccentricindia.com
- **Service Centers:** Over 250 active service centers available for support.



Image: Information regarding the 12-month warranty, 250+ active service centers, and customer care contact details (phone number and email ID).

Safety Information

- Do not expose the earbuds or case to extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or modify the earbuds or charging case. This will void the warranty.
- Keep out of reach of children and pets.

- Dispose of the product responsibly according to local regulations.

© 2024 truke. All rights reserved.
For more information, visit truke Official Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C1P3C5QQ

More documents and user manuals: **https://manuals.plus/**