

[Manuals.plus](#) /

› [MOMOHO](#) /

› MOMOHO Mini Bluetooth Speaker BTS0053 Instruction Manual

MOMOHO BTS0053

MOMOHO Mini Bluetooth Speaker

MODEL: BTS0053 - INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the MOMOHO Mini Bluetooth Speaker. This compact and portable speaker is designed to deliver clear audio with convenient features like Bluetooth 5.2, TWS pairing, a built-in microphone for hands-free calls, and TF card playback. Please read this manual carefully to ensure proper use and optimal performance.

2. What's in the Box

- 1 x MOMOHO Mini Bluetooth Speaker
- 1 x USB-C Charging Cable
- 1 x Lanyard
- 1 x User Manual



Image: Package contents of the MOMOHO Mini Bluetooth Speaker.

3. Product Features

- **Bluetooth 5.2 Technology:** Provides stable and extended wireless range up to 56 feet for various Bluetooth-enabled devices.
- **True Wireless Stereo (TWS) Pairing:** Connect two speakers simultaneously for a 360° surround sound experience.
- **Powerful Sound:** Despite its small size, the speaker delivers loud and clear audio with enhanced bass.
- **Built-in Microphone:** Enables convenient hands-free calling.
- **TF Card Playback:** Supports music playback directly from a TF (MicroSD) card.
- **Long Playtime:** Up to 8 hours of continuous playback (when using a memory card).
- **Ultra-Portable Design:** Lightweight (less than 3 oz) with an included lanyard for easy carrying.
- **Durable Construction:** Features a special silicone coating for a silky feel and is designed to be wearable and dustproof.



Image: The MOMOHO Mini Bluetooth Speaker demonstrating Bluetooth 5.0 and TWS connectivity with a laptop and phone.

MOMOHO



Image: Internal view highlighting the Bluetooth 5.0 TWS chip.

4. Setup and Basic Operation

4.1 Power On/Off

- To power on, press and hold the power button (usually located on the bottom or side) until you hear an audible prompt or see an indicator light.
- To power off, press and hold the power button again until the speaker shuts down.

4.2 Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (indicated by a flashing LED light).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "BTS0053" from the list of devices.
4. Once connected, the speaker will provide an audible confirmation, and the LED light will become solid.

4.3 True Wireless Stereo (TWS) Pairing

To connect two MOMOHO Mini Bluetooth Speakers for stereo sound:

1. Ensure both speakers are powered off.
2. Power on both speakers simultaneously. They will automatically attempt to pair with each other.
3. Once paired, one speaker will act as the master and the other as the slave. The master speaker's LED will flash, indicating it's ready to pair with your device.
4. On your device, enable Bluetooth and search for available devices.
5. Select the master speaker (e.g., "BTS0053") from the list.
6. Both speakers will now play audio in stereo.



Image: Detailed view of the speaker's control buttons.

5. Advanced Operations

5.1 Hands-Free Calling

When connected to your smartphone via Bluetooth, the built-in microphone allows you to answer calls directly through the speaker:

- **Answer Call:** Press the power button once to answer an incoming call.
- **End Call:** Press the power button once during a call to end it.
- **Reject Call:** Press and hold the power button to reject an incoming call.

5.2 TF Card Playback

Insert a TF (MicroSD) card with your music files into the designated slot. The speaker will automatically switch to TF card mode. If it doesn't, double-click the power button to toggle between Bluetooth and TF card modes.



charged



Support TF card
playback



8 hours
continuous play time



multifunction
button



Image: Speaker demonstrating TF card playback and charging capabilities.

6. Charging

To charge your MOMOHO Mini Bluetooth Speaker:

- Connect the provided USB-C charging cable to the speaker's charging port.
- Connect the other end of the cable to a USB power source (e.g., computer, wall adapter).
- The LED indicator will show charging status (e.g., red for charging, off when fully charged).
- A full charge typically takes approximately 1-2 hours.

7. Maintenance

- Keep the speaker away from extreme temperatures, direct sunlight, and moisture.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping or subjecting the speaker to strong impacts.
- When not in use for extended periods, charge the speaker at least once every three months to maintain battery

health.

8. Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the speaker is charged. Connect it to a power source using the USB-C cable.
Cannot pair with device.	Ensure the speaker is in pairing mode (flashing LED). Turn off and on Bluetooth on your device. Move the speaker closer to your device.
No sound or low volume.	Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired.
TWS pairing fails.	Ensure both speakers are powered off before attempting TWS pairing. Try resetting both speakers.
TF card not playing.	Ensure the TF card is inserted correctly and contains compatible audio files. Double-click the power button to switch to TF card mode.

9. Specifications

Feature	Detail
Model Name	BTS0053
Brand	MOMOHO
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	56 Feet
Speaker Maximum Output Power	3 Watts
Battery Capacity	8 Hours (playback with TF card)
Control Method	Touch
Material	Plastic
Item Weight	3.2 ounces (0.09 Kilograms)
Product Dimensions	2.2"D x 2.72"W x 2.1"H
Included Components	Bluetooth Speaker, Lanyard, USB-C Cable, User Manual

10. Warranty and Support

The MOMOHO Mini Bluetooth Speaker comes with a limited warranty. For detailed warranty information, please refer to the warranty card included in your package or contact MOMOHO customer support. Our after-sales team is ready to assist you with any issues or questions.

Thanks for Choosing us

Our after-sales team is ready to solve after-sales problems for you, Sincerely hope that such shopping experience can give you a happy memory.




Image: Thank you message from MOMOHO, emphasizing customer support.

11. Product Videos

Your browser does not support the video tag.

Video: An official MOMOHO video showcasing the Mini Waterproof Bluetooth Speaker, highlighting its features and portability.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C1R8BPLS>

More documents and user manuals: <https://manuals.plus/>