

[Manuals.plus](#) /

> [waitley](#) /

> waitley 4 Pack 20V 6A Replacement Battery User Manual for Dewalt Cordless Tools (Model WTL200)

waitley WTL200

waitley 4 Pack 20V 6A Replacement Battery User Manual

Model: WTL200 | Brand: waitley

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the waitley 4 Pack 20V 6A Lithium-Ion Replacement Batteries. These high-capacity batteries are designed to provide long-lasting performance and durability for your compatible 20V MAX cordless tools. This manual provides essential information for safe and effective use, charging, maintenance, and troubleshooting.

2. PRODUCT FEATURES

- **High Capacity:** Each battery offers 6.0Ah (6000mAh) for extended runtime.
- **Power Display:** Built-in 4 smart LED indicator lights allow real-time monitoring of battery levels.
- **Broad Compatibility:** Compatible with 20V DCD/DCF/DCG/DCS series tools and DCB102/DCB107/DCB115/DCB118 chargers.
- **Safety Features:** CE, FCC, RoHS certified, preventing incorrect voltage, over-charging, over-discharging, over-current, and short-circuit.



Figure 1: waitley 20V 6.0Ah Lithium-Ion Replacement Battery showing button, delicate buckle, and LED display.

Enough for your drilling, cutting use



Figure 2: Visual representation of waitley 20V 6.0Ah Lithium-Ion battery capacity, voltage, and type.

MULTIPLE PROTECTION



Over-discharging
Protection



Short-circuit
Protection



Over-heating
Protection



Over-charging
Protection

Figure 3: Diagram illustrating the multiple protection features of the waitley 20V 6.0Ah battery, including over-discharging, short-circuit, over-heating, and over-charging protection.

3. SAFETY INFORMATION

WARNING: Battery charging should always be done in the presence of someone. Keep batteries away from flammable materials.

- Do not incinerate batteries.
- Do not charge if damaged.
- Avoid exposure to extreme temperatures.
- Do not short-circuit the battery terminals.
- Use only compatible chargers as specified in this manual.

4. SETUP AND CHARGING

4.1 Initial Charge

Before first use, fully charge the battery using a compatible charger.

4.2 Charging Procedure

1. Ensure the battery is clean and dry before placing it on the charger.
2. Align the battery with the charger (compatible with DCB102, DCB107, DCB115, DCB118, etc.) and push firmly until it clicks into place.
3. Monitor the charger's indicator lights for charging status.
4. Once fully charged, remove the battery from the charger.

4.3 Troubleshooting Charging Issues

Q: What should I do if the battery is not charging?

A: Push the battery firmly into the charger to ensure it is fully seated for a successful charge.



Figure 4: waitley 20V 6.0Ah battery being charged on a compatible charger, illustrating proper connection.

Your browser does not support the video tag.

Video 1: Official waitley video demonstrating the features and compatibility of the 4-pack 20V 6A replacement battery, including its use with various cordless tools and charging process.

5. OPERATION

5.1 Installing the Battery

Slide the fully charged battery into the battery slot of your compatible 20V MAX cordless tool until it locks securely in place. Ensure a firm connection before operating the tool.

5.2 Checking Battery Level

Press the 'PUSH' button on the battery to activate the 4 smart LED indicator lights, which display the current charge level. This helps prevent unexpected power depletion during use.



Figure 5: waitley 20V 6.0Ah battery installed and in use with a cordless drill, demonstrating practical application.



Figure 6: Overview of waitley 20V 6.0Ah battery compatibility with a range of 20V MAX cordless tools, including impact wrenches, drills, circular saws, jigsaws, planers, and reciprocating saws.

6. MAINTENANCE AND STORAGE

- Keep batteries clean and dry.
- For long-term storage, store batteries at approximately 50% charge in a cool, dry place, away from direct sunlight and extreme temperatures.
- Avoid fully discharging batteries before recharging to prolong their lifespan.
- Do not store batteries near heat sources or in environments with high humidity.

7. TROUBLESHOOTING

- **Battery not powering tool:** Ensure the battery is fully charged and properly seated in the tool. Check tool contacts for debris.
- **Reduced runtime:** Battery capacity may decrease over time with repeated use. Ensure proper charging and storage practices.

- **Overheating during use/charge:** Discontinue use or charging immediately. Allow the battery to cool down. If the issue persists, contact customer service.

8. SPECIFICATIONS

Specification	Detail
Model Name	WTL200
Quantity	4 Pack
Voltage	20V
Capacity	6.0Ah (6000mAh)
Battery Type	Lithium Ion
Compatibility (Tools)	Dewalt 20V DCD/DCF/DCG/DCS series cordless tools
Compatibility (Chargers)	DCB102/DCB107/DCB115/DCB118 etc.
Certifications	CE, FCC, RoHS
Protections	Incorrect voltage, over-charging, over-discharging, over-current, short-circuit
Battery Weight (each)	600 Grams
Item Dimensions (each)	4.53 x 3.07 x 2.44 inches

9. WARRANTY AND SUPPORT

waitley products come with a **12-month quality issue resolution period**. If you have any concerns or questions about this item, please feel free to contact our Customer Service for assistance. We are committed to ensuring your satisfaction.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question