

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BRASQ](#) /

› [BRASQ Metal Storage Shelf 180x90x40cm - 5 Tiers Instruction Manual](#)

BRASQ 8752601 / SU175

BRASQ Metal Storage Shelf Instruction Manual

Model: 8752601 / SU175

1. INTRODUCTION

Thank you for choosing the BRASQ Metal Storage Shelf. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new storage unit. Please read these instructions carefully before assembly and retain them for future reference.

This robust metal shelving unit is designed for various storage needs in environments such as workshops, garages, pantries, warehouses, and archives. It features five adjustable shelves, each capable of holding up to 175 kg, with a total maximum capacity of 875 kg.

2. SAFETY INSTRUCTIONS

- **Read all instructions:** Ensure you understand all assembly steps and safety warnings before proceeding.
- **Wear protective gear:** Gloves are recommended during assembly to prevent cuts from sharp edges.
- **Assembly location:** Assemble the unit on a flat, stable surface.
- **Heavy components:** Some parts may be heavy. Consider assembling with assistance.
- **Pinch points:** Be aware of potential pinch points during assembly, especially when connecting beams and uprights.
- **Weight limits:** Do not exceed the maximum weight capacity of 175 kg per shelf or 875 kg total for the entire unit. Distribute weight evenly.
- **Stability:** For maximum stability and safety, especially in areas with children or seismic activity, it is highly recommended to anchor the shelving unit to a wall using appropriate hardware (not included).
- **Children and pets:** Keep children and pets away from the assembly area. Do not allow children to climb on the shelves.
- **Maintenance:** Regularly inspect the unit for loose connections or damage. Tighten fasteners as needed.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Upright posts (vertical supports)
- Horizontal beams (long and short)
- Shelf panels (5 pieces)
- Plastic feet/caps for uprights
- *Note: Wall anchoring hardware is not included and must be purchased separately based on your wall type.*

Tools Recommended (not included):

- Rubber mallet (for securing beams)
- Spirit level (for ensuring level assembly)
- Measuring tape
- Protective gloves

4. SETUP AND ASSEMBLY

Follow these steps carefully to assemble your BRASQ metal storage shelf. Assembly is typically tool-free for the main structure, requiring only a rubber mallet to secure connections.

Step 1: Prepare the Upright Posts

Attach the plastic feet/caps to the bottom ends of the upright posts. These protect your floor and provide stability.

Step 2: Assemble the Base Frame

Connect two upright posts using two long horizontal beams and two short horizontal beams to form a rectangular base. Ensure the beams are inserted securely into the slots on the uprights. Use a rubber mallet to gently tap the connections until they are fully seated and firm. Repeat this for the top frame.

Step 3: Connect the Frames

Stand the two assembled frames upright. Connect them using additional long and short horizontal beams at the desired shelf heights. Start with the bottom and top shelves to create a stable structure, then add the intermediate shelves. Ensure all connections are fully engaged and secure with the rubber mallet.

Step 4: Insert Shelf Panels

Once the frame is fully assembled and stable, place the shelf panels onto the horizontal beams. Ensure they sit flush and are evenly supported. The shelf height can be adjusted by repositioning the horizontal beams in the upright slots before placing the panels.

Step 5: Check Stability and Anchor (Recommended)

After assembly, gently shake the unit to check for stability. Use a spirit level to ensure it is level. For enhanced safety, especially with heavy loads or in active environments, anchor the shelving unit to a wall. Mark the desired wall mounting points, drill pilot holes, and secure the unit using appropriate wall anchors and screws (not supplied).



This image illustrates the overall dimensions of the BRASQ metal storage shelf. It stands 180 cm tall, is 90 cm wide, and 40 cm deep, featuring five adjustable shelves.

5. OPERATING INSTRUCTIONS (USAGE)

- **Loading:** Place heavier items on lower shelves to improve stability. Distribute weight evenly across each shelf.
- **Weight Capacity:** Do not exceed 175 kg per shelf or a total of 875 kg for the entire unit. Overloading can cause structural failure and injury.
- **Shelf Adjustment:** To adjust shelf height, unload the shelf, gently tap the horizontal beams upwards with a rubber mallet to disengage them from the upright slots, reposition them to the desired height, and then re-secure them by tapping downwards. Ensure all four beam ends are fully seated before reloading.
- **Clearance:** Ensure adequate clearance around the shelf for safe loading and unloading of items.

6. MAINTENANCE

- **Cleaning:** Wipe down metal surfaces with a damp cloth and mild detergent. Avoid abrasive cleaners or solvents that could damage the finish.
- **Inspection:** Periodically check all connections to ensure they remain tight and secure. Re-tap with a rubber mallet if any beams feel loose.
- **Damage:** If any part of the shelving unit becomes bent, cracked, or otherwise damaged, discontinue use immediately and replace the affected components or the entire unit.

7. TROUBLESHOOTING

- **Shelf is wobbly:**
 - Ensure all horizontal beams are fully seated into the upright slots. Use a rubber mallet to tap them firmly into place.
 - Verify the unit is on a level surface. Adjust feet or use shims if necessary.
 - Consider anchoring the unit to a wall for added stability.
- **Difficulty inserting beams:**
 - Ensure the beam ends are correctly aligned with the slots.
 - Apply gentle, even pressure. A rubber mallet can help seat the connections.
- **Shelf panels do not fit:**
 - Double-check that the frame dimensions match the shelf panel size.
 - Ensure the frame is square and level.

8. SPECIFICATIONS

Feature	Detail
Brand	BRASQ
Model Number	8752601 / SU175
Dimensions (L x W x H)	90 x 40 x 180 cm

Number of Shelves	5
Shelf Material	Wood composite
Frame Material	Metal
Weight Capacity per Shelf	175 kg
Total Weight Capacity	875 kg
Color	Black (Schwarz)
Installation Type	Freestanding (Wall anchoring recommended)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

If you have questions regarding the assembly or operation of your BRASQ Metal Storage Shelf, please contact the manufacturer or your local distributor for assistance.