

[Manuals.plus](#) /

› [Outsunny](#) /

› Outsunny Portable Camping Windbreak A20-270V01MX User Manual

Outsunny A20-270V01MX

Outsunny Portable Camping Windbreak User Manual

Model: A20-270V01MX

1. INTRODUCTION

Thank you for choosing the Outsunny Portable Camping Windbreak. This windbreak is designed to provide shelter from wind, sand, and light breezes, offering privacy and comfort in various outdoor settings such as beaches, campsites, and gardens. Please read this manual carefully before assembly and use to ensure proper setup and safe operation.

Key Features:

- **Generous Size:** Measures 540 cm (L) x 150 cm (H) to create a substantial sheltered area.
- **Durable Construction:** Features sturdy steel poles and a robust fabric shell.
- **Portable Design:** Folds compactly and includes a carry bag for easy transport and storage.
- **Enhanced Stability:** Comes with guy ropes and pegs to secure the windbreak firmly in place.

2. SAFETY INSTRUCTIONS

Please observe the following safety guidelines to prevent injury or damage to the product:


- Always assemble the windbreak on level ground.
- Ensure all poles are securely connected and pegs are firmly anchored into the ground.
- Do not use the windbreak in extreme weather conditions, such as strong winds, heavy rain, or thunderstorms.
- Keep children and pets away from the windbreak during assembly and disassembly.
- Regularly check the stability of the windbreak, especially after prolonged use or changes in weather.
- Avoid placing the windbreak near open flames or heat sources.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Windbreak fabric panel (540 cm x 150 cm)
- Steel poles (multiple sections for assembly)
- Guy ropes
- Ground pegs
- Carry bag

PORTABLE POUR UN TRANSPORT FACILE



Pliable, compact, et un sac de transport inclus pour un rangement facile

Image 3.1: Illustration of the windbreak fabric, steel poles, and included carry bag, highlighting its portability.

4. SETUP AND ASSEMBLY

Follow these steps to set up your Outsunny Portable Camping Windbreak:

1. **Unpack Components:** Remove all items from the carry bag and lay them out on a clear, flat surface.
2. **Assemble Poles:** Connect the individual steel pole sections to form the full-length support poles. Ensure each section is firmly inserted into the next.
3. **Insert Poles into Fabric:** Slide the assembled steel poles through the designated sleeves or loops along the

edges of the windbreak fabric. The poles should extend slightly beyond the fabric at the top and bottom.

4. **Position the Windbreak:** Stand the windbreak upright in your desired location. You can arrange it in an 'L' shape, 'I' shape, or 'U' shape depending on your needs.
5. **Secure with Pegs:** Drive the ground pegs through the loops at the base of each pole and into the ground. Ensure they are angled away from the windbreak for maximum hold.
6. **Attach Guy Ropes:** Connect the guy ropes to the attachment points on the upper part of the poles. Extend the ropes outwards and secure them to the ground using additional pegs. Adjust the tension of the ropes to ensure the windbreak is taut and stable.



Image 4.1: Detail showing the steel poles with ferrules for ground insertion and the use of pegs and guy ropes for enhanced stability.



Image 4.2: A close-up view of the pole base, illustrating how the strap and ground peg secure the windbreak to the ground.



Image 4.3: A detailed shot of a guy rope connected to a ground peg, demonstrating how to tension the windbreak for stability.

5. OPERATING INSTRUCTIONS


Once assembled, the windbreak provides a versatile shelter. Consider the following for optimal use:

- **Wind Direction:** Position the windbreak to block the prevailing wind direction for maximum effectiveness.
- **Privacy:** Utilize the windbreak to create a private area for relaxation or dining.
- **Shaping:** The flexible design allows for various configurations (L, I, U shapes) to suit your space and needs.

PROTECTION OPTIMALE

- Fournit un abri contre le vent et le sable
- Protection de l'intimité
- Protection contre les rayons UV nocifs

FORME DE L



FORME DE I

FORME DE U




Image 5.1: Visual guide demonstrating the different possible configurations (L-shape, I-shape, U-shape) for the windbreak to adapt to various outdoor setups.



Image 5.2: The windbreak providing shelter and privacy in a garden setting, demonstrating its practical application.

6. MAINTENANCE

Proper care will extend the life of your windbreak:

- **Cleaning:** Wipe the fabric clean with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Ensure the fabric is completely dry before folding and storing to prevent mildew.
- **Storage:** Store the windbreak in its carry bag in a cool, dry place away from direct sunlight when not in use.
- **Inspection:** Periodically check poles, ropes, and pegs for any signs of wear or damage. Replace damaged components as needed.

7. TROUBLESHOOTING

If you encounter issues with your windbreak, refer to these common solutions:

- **Windbreak is unstable:**
 - Ensure all pole sections are fully connected.
 - Check that pegs are driven deeply and angled correctly into the ground.
 - Tighten guy ropes to provide adequate tension.
 - Consider repositioning the windbreak to a less exposed area or adding extra anchoring points in very soft ground.
- **Poles are difficult to assemble/disassemble:**
 - Apply a small amount of silicone spray to the pole joints if they are stiff.
 - Ensure no sand or dirt is obstructing the connections.
- **Fabric appears loose:**
 - Re-tension the guy ropes and adjust the position of the poles.
 - Ensure the fabric is correctly threaded through all pole sleeves.

8. SPECIFICATIONS

| | |
|-----------------------------|-----------------------------------|
| Model Number | A20-270V01MX |
| Overall Dimensions | 540 cm (Length) x 150 cm (Height) |
| Material | Polyester fabric, Steel poles |
| Weight | 5.9 kg |
| Color | Grey and White |
| Included Accessories | Carry bag, Guy ropes, Ground pegs |




Image 8.1: Dimensional drawing of the windbreak, indicating its total length of 540 cm and height of 150 cm.

9. WARRANTY AND SUPPORT

Warranty Information: Information regarding specific warranty terms for this product is not available in the provided

data. Please refer to your purchase receipt or contact the retailer for warranty details.

Customer Support: For further assistance, product inquiries, or to report any issues, please contact Outsunny customer service or visit the official Outsunny brand store:

[Visit the Outsunny Store](#)