

[Manuals.plus](#) /

> [Beyution](#) /

> Beyution Universal Remote Control Fit for LG Samsung Sony Philips VIZIO Westinghouse RCA Sansui Funai TCL Hisense Toshiba TV, DVD, TV/DVD Combo, Blu-ray, VCR, Soundbar, Home Theater

Beyution Universal

Beyution Universal Remote Control User Manual

Model: Universal

INTRODUCTION

This user manual provides comprehensive instructions for the Beyution Universal Remote Control. Designed for ease of use, this infrared remote control is a replacement unit that requires no complex setup or programming. It is compatible with a wide range of devices including TVs, DVDs, TV/DVD Combos, Blu-ray players, VCRs, Soundbars, and Home Theater systems from various brands such as LG, Samsung, Sony, Philips, VIZIO, Westinghouse, RCA, Sansui, Funai, TCL, Hisense, and Toshiba.

PRODUCT OVERVIEW

The Beyution Universal Remote Control is engineered for convenience and durability. Its lightweight and ergonomic design ensures a comfortable grip, while the responsive buttons provide excellent tactile feedback. This remote operates via infrared technology, offering a stable performance and a responsive range of up to 10 meters.

Key Features:

- **Universal Compatibility:** Works with numerous brands and device types including TVs, DVDs, Blu-ray players, VCRs, Soundbars, and Home Theater systems.
- **No Setup Required:** Functions as a direct replacement remote, eliminating the need for complex programming.
- **Optimal Performance:** Offers a stable and responsive connection with a maximum distance of 10 meters.
- **Ergonomic Design:** Lightweight and comfortable to hold, with highly responsive buttons.
- **Durable Material:** Constructed from ABS plastic for longevity.

Package Contents:

- 1 x Beyution Universal Remote Control







Figure 1: Front view of the Beyution Universal Remote Control, showcasing its silver finish and button layout.

SETUP AND INITIAL USE

The Beyution Universal Remote Control is designed for immediate use without the need for complex programming. Simply install the batteries, and it will be ready to operate your compatible devices.

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open the compartment.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment. **Note:** Batteries are not included with the remote control.
4. Replace the battery cover by sliding it back into place until it clicks securely.

Once the batteries are installed, the remote control is ready for use. No additional setup or programming is required for most compatible devices.





Figure 2: Back view of the remote control with the battery compartment open, showing where to insert AAA batteries.






Figure 3: Back view of the remote control with the battery compartment closed, ready for use.

OPERATING INSTRUCTIONS

This universal remote control provides intuitive access to common functions for various entertainment devices. Point the remote directly at the device you wish to control for optimal performance.

Button Functions:

Button	Function
Power ()	Turns the selected device On or Off.

Button	Function
Input	Cycles through available input sources (HDMI, AV, etc.).
TV / CBL / DVD / AUX	Selects the device mode to control (Television, Cable Box, DVD Player, Auxiliary Device).
Playback Controls (◀◀, ▶▶, ⏮, ⏭, ⏹)	Rewind, Play/Pause, Fast Forward, Stop, Record (for compatible devices).
Setup	Accesses the setup menu of the selected device.
A, B, C, D (Color Buttons)	Functions vary by device and context, often used for interactive menus or special features.
Home (△)	Returns to the home screen or main menu.
Menu	Opens the device's main menu.
Navigation Pad (Up, Down, Left, Right, OK)	Navigates through menus and confirms selections.
Back (↶)	Goes back to the previous screen or menu.
Asterisk (*)	May function as a star button, favorites, or other special features depending on the device.
Volume (+ / -)	Adjusts the volume level.
Mute ()	Mutes or unmutes the audio.
Channel (▲ / ▼)	Changes the channel up or down.
Number Pad (0-9)	Directly enters channel numbers or other numerical inputs.
Enter	Confirms input or selection.



Figure 4: Angled view of the remote control, highlighting the ergonomic design and button layout for easy operation.

MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your Beyution Universal Remote Control.

Cleaning the Remote:

- Wipe the surface of the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the remote's finish or internal components.

Battery Replacement:

- Replace batteries when the remote's response becomes sluggish or it stops functioning.
- Always replace both batteries at the same time with new AAA alkaline batteries.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

If you encounter issues with your Beyution Universal Remote Control, please refer to the following common solutions:

Problem	Possible Cause / Solution
Remote is not responding.	• Check if the batteries are inserted correctly with the correct polarity. • Replace old or depleted batteries with new AAA alkaline batteries. • Ensure there are no obstructions between the remote and the device's infrared sensor. • Make sure you are pointing the remote directly at the device.
Remote range is short or inconsistent.	• Batteries may be low; replace them. • Ensure there are no strong light sources (like direct sunlight or fluorescent lights) interfering with the infrared signal. • Confirm you are within the effective operating range (up to 10 meters).
Specific buttons are not working.	• This remote is a replacement and does not require programming. However, some advanced functions may not be universally supported across all device models. • Ensure the remote is set to the correct device mode (TV, DVD, etc.) if applicable. • Clean the remote's surface, especially around the buttons, to remove any debris that might be preventing proper contact.
Remote is damaged or completely non-functional.	• If the remote control you receive is damaged or does not work, please contact customer support for assistance.

SPECIFICATIONS

Feature	Detail
Model Number	Universal
Connectivity Technology	Infrared
Material	ABS Plastic
Color	Silver
Maximum Distance	10 Meters (approx. 33 feet)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	6.3 x 1.57 x 0.39 inches (16 x 4 x 1 cm)
Item Weight	2.82 ounces (80 grams)
Compatible Devices	Television, DVD, TV/DVD Combo, Blu-ray, VCR, Soundbar, Home Theater (various brands)

Warranty Information:

This Beyution Universal Remote Control comes with a**6-month warranty period** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

Customer Support:

For any questions, concerns, or assistance with your Beyution Universal Remote Control, please do not hesitate to contact our customer service team. We are committed to providing a satisfactory solution within 24 hours.
If you cannot find your device model in our compatibility list, or if the remote control you received is damaged or not working as expected, please reach out to us via email. Our dedicated support staff will be happy to assist you.

Contact Information: Please refer to your purchase documentation or the seller's contact details on the platform where you purchased the product for specific email addresses or support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I just bought a Beyution remote (model 0628C3245103) that is supposedly compatible with my RCA TV (model RLED2845A), but it did not come with instructions and does not work. How do I set it up?

According to the manufacturer, the Beyution Universal Remote Control is designed as a direct replacement that

requires no programming or setup for compatible devices. If it is not operating your RCA TV (model RLED2845A)...
[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0C1VGYRTB>

More documents and user manuals: <https://manuals.plus/>