

Manuals.plus /

› Terry /

› Terry Armoire 680 Ardoise: Instruction Manual

Terry 1103202

Terry Armoire 680 Ardoise: Instruction Manual

Model: 1103202

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembling and using the Terry Armoire 680 Ardoise. Keep this manual for future reference.

- **Wall Mounting:** For enhanced stability and safety, it is strongly recommended to fix the cabinet to a wall. This is crucial, especially when loading the shelves to their maximum capacity.
- **Weight Limit:** Do not exceed the maximum load capacity of 20 kg per shelf, uniformly distributed. Exceeding this limit can compromise the cabinet's stability and structural integrity.
- **Children and Pets:** Keep children and pets away from the assembly area. Do not allow children to climb on or play with the cabinet.
- **Placement:** Place the cabinet on a flat, stable, and level surface.
- **Tools:** Use appropriate tools for assembly as indicated in the assembly instructions.

2. SETUP AND ASSEMBLY

The Terry Armoire 680 Ardoise requires assembly. Detailed assembly instructions are included with the product. Follow these instructions carefully for proper setup.

2.1 Components Overview

Before starting assembly, ensure all components are present and undamaged. Refer to the included assembly guide for a complete list of parts.



Image 2.1: Interior view of the cabinet with the adjustable shelf installed. This illustrates the internal structure and shelf placement.

2.2 Assembly Steps

1. **Unpack:** Carefully unpack all parts and lay them out on a clean, soft surface to prevent scratches.
2. **Base Assembly:** Assemble the base structure, ensuring the adjustable feet are correctly installed.
3. **Side Panels:** Attach the side panels to the base.
4. **Back Panel:** Secure the back panel.
5. **Shelf Installation:** Insert the adjustable shelf at your desired height. Ensure it is securely seated in the designated slots.
6. **Door Attachment:** Attach the doors using the plastic hinges. Ensure they swing freely and close properly.
7. **Adjustable Feet:** Once assembled, adjust the feet to level the cabinet on uneven surfaces.
8. **Wall Mounting (Recommended):** Secure the cabinet to a wall using appropriate hardware (not included) to prevent tipping. Refer to the specific wall mounting instructions in the included guide.




Image 2.2: Detail of an adjustable foot. These feet allow for leveling the cabinet on uneven floors.

3. OPERATING INSTRUCTIONS

The Terry Armoire 680 Ardoise is designed for organized storage in various home environments, including garages and utility rooms.

3.1 Opening and Closing Doors

- To open, gently pull the door handles.
- To close, push the doors firmly until they engage with the wind-proof closing system.

3.2 Adjusting Shelves

The cabinet features one adjustable shelf. To change its height:

1. Empty the shelf completely.
2. Carefully lift the shelf and remove it from its current position.

3. Re-insert the shelf into the desired slots, ensuring it is level and securely seated on all four supports.

3.3 Security Features

The cabinet is designed with a wind-proof closing system to keep doors securely shut. For added security, the doors are compatible with a padlock (not included).



Image 3.1: The Terry Armoire 680 Ardoise shown in a typical home storage environment, demonstrating its practical application.

4. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your Terry Armoire 680 Ardoise.

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth and a mild detergent. Avoid abrasive cleaners or solvents, as these can damage the plastic.
- **Inspection:** Periodically check all connections and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Adjustable Feet:** Ensure the adjustable feet are still correctly positioned and the cabinet remains level.

- **Wall Fixings:** If wall-mounted, regularly check the wall fixings for security.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your cabinet.

Problem	Possible Cause	Solution
Cabinet is unstable or wobbly.	Uneven floor; adjustable feet not properly set; cabinet not wall-mounted.	Adjust the feet to level the cabinet. Ensure the cabinet is wall-mounted for maximum stability.
Doors do not close properly or are misaligned.	Hinges are loose; cabinet is not level; obstruction.	Check and tighten hinge screws. Ensure the cabinet is level. Remove any obstructions.
Shelf sags or is not secure.	Overloaded shelf; shelf not properly seated in supports.	Reduce the load on the shelf (do not exceed 20 kg). Re-seat the shelf firmly into its supports. Ensure the cabinet is wall-mounted.

6. SPECIFICATIONS

Key technical specifications for the Terry Armoire 680 Ardoise.

Feature	Detail
Model Number	1103202
Dimensions (W x D x H)	68 cm x 39 cm x 93.5 cm
Material	Plastic (90% recycled)
Color	Grey / Black (Ardoise effect)
Number of Doors	2
Number of Shelves	1 (adjustable)
Shelf Load Capacity	20 kg (uniformly distributed, with cabinet fixed to wall)
Special Features	Adjustable feet, wind-proof closing system, padlock compatible (padlock not included), ecological material.
Assembly Required	Yes
Country of Origin	Italy



Image 6.1: Dimensional drawing of the cabinet, indicating its width (68 cm), depth (39 cm), and height (93.5 cm).

7. WARRANTY AND SUPPORT

For warranty claims or technical support, please refer to the information below.

- **Spare Parts Availability:** Spare parts for this product are available for 2 years from the date of purchase.
- **Warranty Information:** For specific warranty terms and conditions, please consult the documentation provided with your purchase or visit the official Terry website.
- **Customer Support:** If you require further assistance or have questions not covered in this manual, please contact Terry customer service through their official website or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C1WLD5D7>

More documents and user manuals: <https://manuals.plus/>