

[Manuals.plus](#) /

› [Huuger](#) /

› Huuger Nightstand with Charging Station, Fabric Drawers, End Table with Open Shelf, Bedside Table with USB Ports and Outlets, Night Stand for Bedroom, Walnut 11.8"D x 15.7"W x 23.6"H (2 Drawers) Walnut 1

Huuger 11.8"D x 15.7"W x 23.6"H (2 Drawers) Walnut 1

Huuger Nightstand with Charging Station Instruction Manual

Brand: Huuger | Model: 11.8"D x 15.7"W x 23.6"H (2 Drawers) Walnut 1

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Caution:** Drawers may pose pinch points. Keep fingers away during operation.
- **Warning:** Exceeding the maximum weight recommendation of 22 pounds may cause damage to the product or result in injury.
- **Stability Notice:** Ensure the nightstand is placed on a level and stable surface to prevent tipping.
- **Installation Advice:** For added safety, consider securely anchoring the nightstand to a wall, especially in households with children or pets, to prevent accidental tipping.
- **Electrical Safety Warning:** Only use approved and compatible chargers and cables with the integrated charging station. Do not overload the outlets. Disconnect power before cleaning or if any electrical issue is suspected.

PACKAGE CONTENTS

Verify all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

1. Metal Frame Components
2. Wooden Top Shelf (1)
3. Wooden Middle Shelf (1)
4. Fabric Drawers (2)
5. Integrated Power Strip with 2 AC Outlets, 1 USB Port, 1 Type-C Port
6. Assembly Hardware (screws, bolts, nuts, etc.)
7. Installation Tool (Screwdriver, Allen Wrenches)
8. Assembly Guide
9. Adjustable Feet (4)



Image: All components of the Huuger Nightstand, including metal frame parts, wooden shelves, fabric drawers, and hardware, are laid out on a floor, ready for assembly.

ASSEMBLY INSTRUCTIONS

Follow the numbered steps in the included Assembly Guide for detailed instructions. The following is a general overview.

- Step 1: Assemble the Metal Frame.** Connect the vertical and horizontal metal bars using the provided screws and the installation tool. Ensure all connections are secure.
- Step 2: Attach the Wooden Shelves.** Secure the top wooden shelf and the middle wooden shelf to the assembled metal frame using the designated hardware. The top shelf is where the charging station will be integrated.
- Step 3: Install the Integrated Power Strip.** Carefully place the power strip into the pre-cut opening on the top wooden shelf. Secure it in place according to the guide. Ensure the power cord is routed safely.
- Step 4: Insert Fabric Drawers.** Fold and assemble the two fabric drawers. Slide them into their designated slots within the metal frame.
- Step 5: Attach and Adjust Feet.** Screw the four adjustable feet into the bottom of the metal frame. Adjust them as needed to ensure the nightstand is level and stable on your floor.



Image: The fully assembled Huuger Nightstand, featuring a walnut top and two gray fabric drawers, positioned next to a bed in a bedroom.



Image: A close-up view of the adjustable feet at the base of the nightstand, designed to protect the floor and ensure stability.

SETUP AND OPERATION

Charging Station Setup

The Huuger Nightstand features a convenient integrated charging station on its top surface.

1. **Power Connection:** Plug the nightstand's power cord into a standard 120V AC wall outlet.
2. **AC Outlets:** Use the two 125V/12A AC outlets for powering lamps, alarm clocks, or other small appliances.
3. **USB Ports:** Utilize the 5V-2A USB-A port and the 5V-2A Type-C port to charge your smartphones, tablets, smartwatches, and other USB-powered devices.



Image: A detailed view of the recessed power strip on the nightstand's top, showing 2 AC outlets, 1 USB-A port, and 1 Type-C port in use with various devices charging.

Drawer and Shelf Usage

- **Fabric Drawers:** The two fabric drawers provide enclosed storage for personal items, books, or accessories. Gently pull the handles to open and push to close.
- **Open Shelf:** The open shelf below the top surface offers additional space for frequently accessed items, decorative pieces, or books.



Image: The nightstand with its two fabric drawers partially open, revealing ample storage space for various items.

MAINTENANCE

Proper care will ensure the longevity of your Huuger Nightstand.

- **Cleaning:** Wipe the wooden surfaces and metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Fabric Drawers:** For minor spills on fabric drawers, spot clean with a mild detergent and damp cloth. Allow to air dry completely. Do not machine wash.
- **Electrical Components:** Ensure the nightstand is unplugged before cleaning the area around the power strip. Do not spray liquids directly onto the electrical outlets or ports.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your nightstand, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Nightstand is wobbly or unstable.	Uneven floor surface; loose connections.	Adjust the leveling feet at the bottom of the nightstand until it is stable. Check and tighten all assembly screws.
Charging station not providing power.	Nightstand not plugged in; wall outlet not active; faulty device cable.	Ensure the nightstand's power cord is securely plugged into a working wall outlet. Test the wall outlet with another device. Try a different charging cable for your device.
USB-powered devices flicker or charge inconsistently.	Device requires specific voltage (e.g., 3V) not optimally supported by the 5V USB output.	The USB ports are designed for 5V devices. For devices requiring lower voltages (e.g., 3V decorative lights), consider using a compatible adapter plugged into one of the AC outlets instead of the USB port.
Drawers do not slide smoothly.	Drawer not assembled correctly; obstruction.	Ensure the fabric drawers are fully and correctly assembled. Check for any items obstructing the drawer's path.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Huuger
Model	11.8"D x 15.7"W x 23.6"H (2 Drawers) Walnut 1
Product Dimensions (D x W x H)	11.8"D x 15.7"W x 23.6"H
Maximum Weight Recommendation	22 Pounds
Color	Walnut (Top), Gray (Drawers), Black (Frame)
Material Type	Engineered Wood, Metal, Fabric
Number of Drawers	2
Charging Station	2 AC Outlets (125V/12A), 1 USB-A Port (5V-2A), 1 Type-C Port (5V-2A)
Power Cord Length	Approx. 4.9 ft
Style Name	Modern
Indoor/Outdoor Usage	Indoor
UPC	747607959149




Image: A diagram illustrating the precise dimensions of the nightstand, including overall height, width, depth, shelf height, and drawer dimensions.

WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the manufacturer directly. Huuger is committed to providing quality products and customer satisfaction.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Huuger customer support through their official channels or the retailer from whom you purchased the product.

You can visit the official Huuger store for more information: [Huuger Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question