

YESHOMY YH-TS2012

YESHOMY Modern LED TV Stand YH-TS2012 User Manual

Model: YH-TS2012

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Ensure all electronic devices and cables are securely connected and kept away from water or other liquids.
- Assembly is required. Risk of injury if not assembled correctly.
- Do not exceed the maximum load capacity of 150 lbs for the tabletop.
- Keep small parts and packaging materials away from children to prevent choking hazards.

2. PRODUCT OVERVIEW

The YESHOMY Modern LED TV Stand (Model YH-TS2012) is designed to accommodate televisions up to 70 inches. It features a sleek, high-gloss white finish, integrated LED lighting, two tempered glass shelves, and two spacious drawers for organized storage.

Key Features:

- **Modern Design:** High-gloss finish for a contemporary aesthetic.
- **LED Lighting:** Equipped with LED lights offering 20 colors and multiple dynamic RGB modes, controllable via remote.
- **Ample Storage:** Two tempered glass shelves and two large drawers provide versatile storage for media devices, accessories, and decorative items.

- **Sturdy Construction:** Made from high-quality wood materials for durability and stability.
- **TV Compatibility:** Suitable for televisions ranging from 32 to 70 inches.

Product Dimensions:

Overall Dimensions: 60.99" W x 13.77" D x 17.71" H

Item Weight: Approximately 69 pounds




Figure 2.1: Product Dimensions and TV Compatibility. This diagram illustrates the overall dimensions of the TV stand and indicates its suitability for TVs from 32 to 70 inches.



Figure 2.2: Spacious Design. This image emphasizes the large tabletop, two open storage areas, and the 150 lbs weight capacity of the stand.



Figure 2.3: Front View of Assembled TV Stand. This image displays the TV stand with a television and various decorative items, showcasing its modern appearance.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- TV Stand Panels (various sizes)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- 2 x Tempered Glass Shelves
- LED Light Strip with Remote Control
- Basic Assembly Instructions (diagrams)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the YESHOMY LED TV Stand requires careful attention to detail. While basic instructions are provided, it is recommended to proceed methodically.

General Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided diagrams.
2. **Hardware Check:** Verify that all necessary hardware is present.
3. **Panel Assembly:** Begin assembling the main frame of the TV stand by connecting the panels using the designated hardware. Ensure all locking screws are turned in the correct direction to secure connections firmly. Incorrect tightening can lead to instability.
4. **Drawer Installation:** Assemble the two drawers according to the instructions. Install the drawer slides smoothly.
5. **Glass Shelf Placement:** Insert the two tempered glass shelves into their designated slots. These shelves are adjustable and removable.
6. **LED Light Installation:** Attach the LED light strip to the designated areas. If the strip does not adhere well, additional double-sided adhesive tape may be used for better security. Note that the LED cord length may be limited, so plan your power source accordingly.
7. **Final Placement:** Once fully assembled, carefully move the TV stand to its desired location.



Figure 4.1: Adjustable Glass Shelves. This image highlights the tempered glass shelves, which can be adjusted or removed to suit your storage needs.



Large capacity space for storing more things



Slide rail material

Figure 4.2: Spacious Drawers. This image demonstrates the ample storage space provided by the two large drawers.

Tip: For optimal stability, ensure all connections are tight and secure. If you encounter difficulty, re-check the diagrams and ensure parts are oriented correctly.

5. OPERATING INSTRUCTIONS

LED Lighting System:

The integrated LED lighting system enhances the ambiance of your living space. It is controlled by a dedicated remote control.

- **Power On/Off:** Use the power button on the remote to turn the LED lights on or off.
- **Color Selection:** Choose from 20 available colors using the color buttons on the remote.
- **Dynamic Modes:** Select from multiple dynamic RGB modes to create various lighting effects.
- **Brightness Adjustment:** Adjust the brightness of the lights using the designated buttons.



Figure 5.1: LED Remote Control and Color Options. This image illustrates the remote used to control the LED lights and their various color settings.

Storage Drawers:

The two large drawers operate on smooth slide rails, providing convenient access to stored items. Simply pull the drawer front to open and push to close.

Tempered Glass Shelves:

The glass shelves can be used to display decorative items or store media devices. They are designed to be adjustable and removable, allowing for customization of the storage space.

Your browser does not support the video tag.

Video 5.1: YESHOMY Modern LED TV Stand Features. This video demonstrates the features of the TV stand, including its high-gloss surface, tempered glass shelves, two large drawers, and LED lighting system.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your TV stand, follow these care guidelines:

- **Cleaning:** Wipe the high-gloss surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood and electrical components.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Keep the stand away from excessive moisture or direct sunlight to prevent warping or discoloration.
- **LED Lights:** If LED strips become loose, re-secure them with strong double-sided adhesive tape.

7. TROUBLESHOOTING

If you encounter any issues with your YESHOMY LED TV Stand, refer to the following common problems and solutions:

- **LED Lights Not Working:**
 - Check if the LED strip is properly connected to the power source.
 - Ensure the remote control has working batteries.
 - Verify that the LED strip itself is not damaged.
- **Stand Feels Unstable:**
 - Re-check all assembly hardware (screws, cam locks) to ensure they are fully tightened and correctly engaged.
 - Ensure the stand is placed on a flat, level surface.
- **Drawers Do Not Slide Smoothly:**
 - Verify that the drawer slides are installed correctly and are free of obstructions.
 - Ensure the drawers are properly aligned within their compartments.

8. SPECIFICATIONS

Feature	Detail
Brand	YESHOMY
Model Name	Modern LED TV Stand
Item Model Number	YH-TS2012
Product Dimensions	13.77"D x 60.99"W x 17.71"H
TV Compatibility	Up to 70 inches
Material	Wood (Frame & Top)
Finish Type	High-Gloss
Number of Shelves	2 (Tempered Glass)
Storage Options	Shelves, Drawers

Special Features	Adjustable Shelf, Lightweight, LED lighting (20 colors, dynamic RGB modes)
Item Weight	69 Pounds
Assembly Required	Yes

9. WARRANTY INFORMATION

Specific warranty details for the YESHOMY Modern LED TV Stand are not provided in the product information. Please retain your proof of purchase. For warranty claims or inquiries, contact the retailer or manufacturer directly.

10. CUSTOMER SUPPORT

For further assistance, questions, or to report missing/damaged parts, please contact your retailer or the YESHOMY customer service department. Refer to your purchase documentation for contact details.