

ONN 55-Inch Series 1 4K 2160p Smart LED TV

ONN 55-Inch Series 1 4K 2160p Smart LED TV Instruction Manual

Model: 55-Inch Series 1 4K 2160p Smart LED TV | **Brand:** ONN

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your ONN 55-Inch Series 1 4K 2160p Smart LED TV. Please read these instructions thoroughly before using your television and retain them for future reference. This high-definition smart TV offers an exceptional viewing experience with its 55-inch LED screen and 4K 2160p resolution, displaying sharp, vibrant images in stunning detail. It features a 60Hz refresh rate for smooth content playback and comes equipped with smart features like WiFi connectivity and a wide selection of streaming applications.



Figure 1: Front view of the ONN 55-Inch Series 1 4K Smart LED TV, showcasing its sleek design and on-screen smart TV interface.

2. SAFETY INFORMATION

Always follow basic safety precautions when using this television to reduce the risk of fire, electric shock, and injury. Keep the television away from moisture, direct sunlight, and heat sources. Ensure proper ventilation and do not block any ventilation openings. Use only attachments/accessories specified by the manufacturer. Refer all servicing to qualified service personnel.

- **Power Source:** Connect the TV only to the type of power source indicated on the marking label.
- **Ventilation:** Do not install the TV in a confined space. Allow adequate space around the TV for proper airflow.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Cleaning:** Unplug the TV from the wall outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Wall Mounting:** If wall mounting, ensure the wall mount is securely installed and capable of supporting the TV's weight. Professional installation is recommended.

3. WHAT'S IN THE Box

Carefully unpack the box and ensure all items are present and in good condition. The package should contain:

- ONN 55-Inch Series 1 4K 2160p Smart LED TV
- Remote Control
- Power Cable
- Free Wall Mount (Note: This renewed product is specified as not including traditional tabletop stands, focusing on wall-mounting.)
- Quick Start Guide (not included in this manual)

4. SETUP

4.1 Wall Mounting

This television is designed for wall mounting, and a free wall mount is included. Follow the instructions provided with the wall mount for secure installation. Ensure the wall can support the weight of the television and the mount. Professional installation is highly recommended for safety.

4.2 Connecting Devices

Your ONN Smart LED TV features multiple connectivity options. Locate the input ports on the back and side of the television (see Figure 2 for port locations).




Figure 2: Rear view of the ONN 55-Inch Series 1 4K Smart LED TV, highlighting the various input ports including HDMI and USB.

- **HDMI Ports:** Connect devices such as game consoles (e.g., PlayStation 5, Nintendo Switch), Blu-ray players, or cable/satellite boxes using HDMI cables. This TV offers multiple HDMI inputs.
- **USB Ports:** Use USB ports for connecting storage devices to play media or for powering compatible accessories.
- **Power:** Connect the power cable to the TV and then to a wall outlet.

4.3 Network Connection (Wi-Fi)

To access smart features and streaming apps, connect your TV to your home Wi-Fi network:

1. Turn on the TV using the remote control.
2. Navigate to the "Settings" menu.
3. Select "Network" or "Network Settings".
4. Choose "Wireless" and select your home Wi-Fi network from the list.
5. Enter your Wi-Fi password if prompted.
6. Once connected, the TV will have access to online features and streaming services.

5. OPERATING THE TV

5.1 Remote Control Functions

The included remote control provides easy navigation and control over your TV's features. It includes dedicated buttons for popular streaming services and essential functions.



Figure 3: Angled view of the ONN 55-Inch Series 1 4K Smart LED TV, with the remote control visible in the foreground, illustrating its user-friendly design.

- **Power Button:** Turns the TV on or off.
- **Navigation Pad (OK button):** Use the directional arrows to move through menus and the OK button to confirm selections.
- **Volume Buttons:** Adjust the volume up or down. A mute button is also available.
- **Home Button:** Returns to the main smart TV interface.
- **Dedicated App Buttons:** Quick access to streaming services like Netflix, Hulu, Disney+, and others.

5.2 Smart TV Features

Your ONN Smart LED TV provides access to a wide range of smart features:

- **Streaming Apps:** Enjoy instant access to popular streaming services such as Netflix, Disney+, YouTube, and many more.
- **Voice Assistants:** Compatible with Alexa and Google Assistant. Use voice commands to turn on the TV, change channels, control volume, and more.
- **Live TV:** Access live television channels through compatible services or an antenna (if connected).
- **App Store:** Download and install additional applications from the TV's streaming store.

6. PICTURE & SOUND SETTINGS

Customize your viewing and listening experience through the TV's settings menu.

- **Picture Settings:** Adjust brightness, contrast, color, sharpness, and picture mode (e.g., Standard, Movie, Sport) to suit your preferences.

- **Sound Settings:** Modify bass, treble, balance, and sound mode (e.g., Standard, Music, Movie). The TV features surround sound technology for an enhanced audio experience.
- **Accessibility:** Options for closed captions, screen reader, and other accessibility features are available in the settings.

7. MAINTENANCE

Proper care and maintenance will extend the life of your television.

- **Screen Cleaning:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Never spray liquid directly onto the screen.
- **Cabinet Cleaning:** Wipe the TV cabinet with a soft, dry cloth.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked by dust or debris.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, discontinue use and contact customer support.

8. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions:

Problem	Solution
No Power	Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Try a different outlet.
No Picture/Sound	Check all cable connections (HDMI, etc.). Ensure the correct input source is selected on the TV.
Poor Picture Quality	Adjust picture settings (brightness, contrast, sharpness). Ensure the input source is providing a high-quality signal.
Remote Control Not Working	Check and replace batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot Connect to Wi-Fi	Verify your Wi-Fi password. Restart your router and modem. Ensure the TV is within range of your Wi-Fi signal.

9. SPECIFICATIONS




Figure 4: Diagram illustrating the dimensions of the ONN 55-Inch Series 1 4K Smart LED TV.

- **Screen Size:** 55 Inches
- **Display Technology:** LED
- **Resolution:** 4K (2160p)
- **Refresh Rate:** 60 Hz
- **Product Dimensions (D x W x H):** 3.1" x 48.7" x 28.1"
- **Aspect Ratio:** 1.77:1
- **Connectivity Technology:** HDMI, USB, Wi-Fi
- **Special Feature:** Flat screen, Smart TV functionality, Voice Assistant compatibility (Alexa, Google Assistant)
- **Color:** Black

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official ONN product support website. Keep your proof of purchase for any warranty claims.