

Manxrtod FX801R

Manxrtod FX801R Replacement Blades Instruction Manual

For FX870, FXF880, FX810, FX825, FX673N Clippers

INTRODUCTION

This manual provides essential instructions for the installation, operation, and maintenance of your Manxrtod FX801R Replacement Blades. These blades are designed for compatibility with specific professional clippers, ensuring optimal performance when properly installed and cared for.

The Manxrtod FX801R replacement blades are compatible with Barberology FX870, FXF880, FX810, FX825, and FX673N clippers.

PRODUCT FEATURES

- **Professional Precision:** Designed for Barberology FX870, FXF880, FX810, FX825, and FX673N clippers.
- **Durable Construction:** Made from 440C carbon steel with a DLC (Diamond-Like Carbon) surface treatment for enhanced sharpness and longevity.
- **Optimized Performance:** Engineered for cooler operation and superior cutting efficiency compared to standard blades.
- **Easy Installation:** Designed for straightforward replacement of existing clipper blades.

MANXRTOD

EXCELLENT PERFORMANCE

*Upgrade cutting technology runs cooler
Performs 3x sharper than regular blade*



Image: The Manxrtod FX801R replacement blade highlighting its excellent performance characteristics, including cooler operation and enhanced sharpness.

INSTALLATION GUIDE

Before beginning, ensure your clipper is turned off and unplugged for safety. Handle blades carefully to avoid injury.

- 1. Remove Old Blades:** Using a screwdriver, carefully unscrew the two screws holding the existing blades to the clipper head. Remove both the fixed and moving blades.
- 2. Clean Clipper Head:** Clean any hair or debris from the clipper head area using a small brush.
- 3. Position New Blades:** Place the new Manxrtod FX801R fixed blade onto the clipper head, aligning the screw holes. Then, place the moving blade on top of the fixed blade, ensuring it sits correctly within the guides.
- 4. Secure Blades:** Insert the screws and gently tighten them. Ensure the blades are aligned properly, with the cutting edge of the moving blade slightly behind the fixed blade to prevent skin nicks. The blades should be parallel and centered.
- 5. Test Alignment:** Turn on the clipper briefly to check for proper blade movement and alignment. Adjust screws if necessary to achieve optimal alignment and smooth operation.




Image: The Manxrtod FX801R replacement blade set, showing the fixed and moving blade components ready for installation.

OPERATING INSTRUCTIONS

Once installed, the Manxrtod FX801R replacement blades operate identically to the original blades of your compatible clipper. Ensure the blades are always clean and lightly oiled before each use for best cutting performance and to prolong blade life.

- Always use the clipper on clean, dry hair.
- Apply light pressure and move the clipper smoothly against the direction of hair growth.
- Regularly check blade temperature during extended use to prevent overheating.

CARE AND MAINTENANCE

Proper maintenance is crucial for the longevity and performance of your replacement blades.


- **Cleaning:** After each use, brush off any loose hair from the blades. For a deeper clean, you may use a blade cleaning spray or carefully wipe with a damp cloth (ensure clipper is unplugged). Allow blades to dry completely before oiling.

- **Oiling:** Apply 1-2 drops of clipper oil to the teeth of the blades before and after each use. Turn on the clipper for a few seconds to distribute the oil evenly. This reduces friction, heat, and wear.
- **Storage:** Store the clipper with the blades attached in a clean, dry place, protected from dust and moisture.

MANXRTOD SUPERIOR CRAFTSMANSHIP



*Shear Cutting Blade
Cooler Sharper Safer*



*440C Carbon Steel
DLC Surface Finish*

DLC Comb Blade

Shear Cutting Blade

Image: Illustration of the Manxrtod FX801R blade's superior craftsmanship, highlighting its 440C carbon steel and DLC surface finish for durability.

TROUBLESHOOTING

Refer to the table below for common issues and their potential solutions.

Problem	Possible Cause	Solution
Blades pulling or snagging hair	Blades are dull, dirty, or not properly oiled.	Clean and oil blades. If issue persists, blades may need replacement.
Blades not cutting effectively	Improper blade alignment or loose screws.	Ensure blades are securely fastened and correctly aligned. Refer to Installation Guide.

Problem	Possible Cause	Solution
Excessive noise or vibration	Blades are loose or misaligned.	Tighten blade screws and check alignment. Ensure no debris is lodged between blades.
Blades getting hot quickly	Lack of lubrication or prolonged use without cleaning.	Apply clipper oil generously. Clean blades thoroughly. Allow clipper to cool if used for extended periods.

PRODUCT SPECIFICATIONS

- **Model:** FX801R
- **Material:** 440C Carbon Steel with DLC Surface Treatment
- **Dimensions (Fixed Blade):** Approximately 4.5 cm (1.77 inches) width x 3.7 cm (1.45 inches) height
- **Dimensions (Moving Blade):** Approximately 4.0 cm (1.57 inches) width x 2.1 cm (0.8 inches) height
- **Weight:** 1.6 ounces (total product weight)
- **Compatibility:** Barberology FX870, FXF880, FX810, FX825, FX673N Clippers




Image: Detailed diagram showing the dimensions of the Manxrtod FX801R fixed and moving blades.

COMPATIBLE CLIPPER MODELS

These replacement blades are specifically engineered to fit the following professional clipper models:

- Barberology FX870
- Barberology FXF880
- Barberology FX810
- Barberology FX825
- Barberology FX673N

MANXRTOD

PERFECTLY MATCH ORIGIN

*Perfectly Compatible with All Barberology
FX870/FXF880/FX810/FX825/FX673N Clippers*



FX870G

FX870N

FX870RG

FX870S

FX825

Image: A visual representation of several Barberology clipper models (FX870G, FX870N, FX870RG, FX870S, FX825) that are compatible with the Manxrtod FX801R replacement blades.

CUSTOMER SUPPORT

For any questions, concerns, or issues regarding your Manxrtod FX801R Replacement Blades, please contact our customer support team. We are committed to providing assistance and will respond to inquiries within 12 hours.

Please ensure that the blade fits your machine before purchase. If you encounter any problems, do not hesitate to reach out.

Warranty Information: Specific warranty details are not provided in this manual. Please refer to the product packaging or contact customer support for warranty-related inquiries.