Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TESSAN TS-161-EU-C

TESSAN European Travel Plug Adapter USB C (3 Pack) Instruction Manual

Model: TS-161-EU-C

Brand: TESSAN

1. Introduction

Thank you for choosing the TESSAN European Travel Plug Adapter. This manual provides essential information for the safe and efficient use of your adapter. Please read it thoroughly before use and retain it for future reference.

The TESSAN European Travel Plug Adapter is designed to provide convenient power access for your electronic devices when traveling from the US to most European countries. It features multiple outlets and USB charging ports in a compact design.



Image 1: TESSAN European Travel Plug Adapter (3-Pack)

2. Product Overview

The TESSAN European Travel Plug Adapter (Model TS-161-EU-C) is a 7-in-1 power solution, offering:

- **4 AC Outlets:** For connecting standard US plugs (2500W Max).
- **1 USB-C Charging Port:** (15W Max, 3A Max) for fast charging compatible devices.
- **2 USB-A Charging Ports:** (2.4A Max per port) for standard USB charging.

This adapter allows you to charge up to 7 devices simultaneously, making it ideal for travel.



Image 2: Adapter in use, demonstrating 7-in-1 functionality.

3. Setup and Usage

3.1 Compatibility

This Type C adapter is compatible with most European countries, including:

- Italy, Spain, France, Portugal, Iceland, Germany, Finland, Korea, Greece, Austria, Belgium, Croatia, Denmark, Netherlands, Norway, Poland, Sweden, Switzerland, and many more.

Important Note: This adapter **does NOT work** in the UK, Ireland, Scotland, or South Africa, as these regions

typically use Type G plugs.



Image 3: Geographic compatibility of the Type C adapter.

3.2 Connecting the Adapter

1. Ensure your devices are compatible with the local voltage (see Section 4).
2. Plug the TESSAN adapter firmly into a Type C European wall socket.
3. Connect your US-standard plugs into the AC outlets on the adapter.
4. Connect your USB-C or USB-A cables into the corresponding charging ports.

3.3 Charging Performance

The USB-C port provides up to 15W (5V/3A Max) for faster charging of compatible smartphones, tablets, and other devices. The USB-A ports deliver up to 2.4A (5V/2.4A Max) per port, suitable for most standard USB-powered devices.



Image 4: USB-C charging speed demonstration.

4. Important Safety Information: Not a Voltage Converter

This adapter is NOT a voltage converter.

It only adapts the plug shape from US to European Type C. It does not convert the voltage from 110V (US standard) to 220-240V (European standard) or vice-versa.
Before using any device with this adapter, you MUST ensure that your device supports 100-250V dual voltage. Check your device's power adapter or label for input voltage specifications. If your device is 110V-only, you will need a separate voltage converter.
Devices that typically require a voltage converter if they are not dual voltage include:

- Hair dryers
- Hair straighteners/curling irons
- Coffee makers
- CPAP machines

Using a 110V-only device with this adapter in a 220-240V outlet without a voltage converter can damage your device and pose a safety risk.



Image 5: Voltage compatibility and warning.

5. Specifications

Feature	Specification
Model Number	TS-161-EU-C
Input Voltage	100-250V~, 50/60Hz, 10A Max
AC Outlet Rating	2500W Max

USB-C Output	5V/3A Max (15W)
USB-A Output	5V/2.4A Max per port
Total DC Output	15W
Product Dimensions	3.07 x 2.2 x 2.56 inches
Item Weight	3.48 ounces
Color	Gray&White

6. Additional Information

6.1 Compact and Portable Design

The TESSAN adapter is designed for travel convenience. Its compact size and lightweight construction make it easy to pack in your luggage without taking up much space.



Image 6: Compact design for easy packing.

6.2 Cruise Ship Friendly

This adapter features no surge protection and no extension cord, making it suitable for use on most cruise ships which often prohibit devices with surge protectors.



Image 7: Suitable for cruise travel.

7. Official Product Videos

7.1 How to Choose a Travel Plug Adapter

Video 1: This video from Tessan Direct provides guidance on selecting the correct travel plug adapter for various regions worldwide, detailing different plug types and their corresponding countries.

7.2 TESSAN European Travel Plug Adapter USB C (3 Pack) Overview

Video 2: A brief overview from Tessan Direct showcasing the features and benefits of the 3-pack European Travel Plug Adapter with USB-C ports.

8. Troubleshooting

- **Device not charging:** Ensure the adapter is firmly plugged into the wall socket. Verify that your device's charging cable is securely connected to the adapter's port. Check if your device supports the local voltage (100-250V).
- **Adapter feels warm:** It is normal for the adapter to feel slightly warm during operation, especially when multiple devices are charging. If it becomes excessively hot, disconnect all devices and the adapter from the wall immediately.
- **No power:** Check the wall socket with another device to ensure it is functional. If the socket works, the adapter may be faulty.

9. Warranty and Support

TESSAN products come with a standard manufacturer's warranty. For specific warranty details, please refer to the product packaging or contact TESSAN customer service. If you encounter any issues or have questions, please reach out to our customer support team for assistance. They typically reply within 24 hours.
Tessan Direct Customer Service: Contact Seller

© 2025 TESSAN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C23JV7CP

More documents and user manuals: **https://manuals.plus/**