

oneisall BM1

oneisall Dog Grooming Vacuum & Dryer User Manual

Model: BM1 | Brand: oneisall

1. INTRODUCTION

The oneisall Dog Grooming Vacuum & Dryer is an 8-in-1 multi-functional pet grooming kit designed to simplify pet care at home. It combines vacuuming, drying, and clipping functionalities to manage shedding, wash, dry, and trim pet hair efficiently. This manual provides essential information for safe and effective use, maintenance, and troubleshooting.

Key Features:

- **3-in-1 Functionality:** Combines vacuum, dryer, and clippers for comprehensive grooming.
- **Adjustable Dryer:** 7 heat settings (95°F-149°F) and 3 flow speeds with 3 nozzle attachments for quick and fluffy drying.
- **Effective Hair Collection:** Vacuum suction captures hair during grooming, minimizing mess.
- **Precision Clippers:** Can be used independently or with vacuum suction for mess-free trimming.
- **Low Noise Operation:** Operates under 60dB to ensure a calm grooming experience for pets.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the oneisall Dog Grooming Vacuum & Dryer to prevent injury or damage to the device.

- Always unplug the device before cleaning or storing.
- Keep the blades away from your eyes and face while trimming.
- Do not use on infants or children without adult supervision.
- Avoid using near water sources.
- Always follow the recommended cleaning and maintenance procedures to prevent skin irritation or injury.
- If you experience any discomfort or injury, discontinue use immediately and consult a healthcare professional.

3. PRODUCT COMPONENTS



Figure 3.1: Overview of the oneisall Dog Grooming Vacuum & Dryer and its various attachments.

The oneisall Dog Grooming Vacuum & Dryer comes with the main unit, a flexible hose, and multiple interchangeable attachments for different grooming tasks:

- **Main Unit:** Houses the motor, dust cup, and controls for vacuum and dryer functions.
- **Flexible Hose:** Connects attachments to the main unit for suction or airflow.
- **Pet Clippers:** Cordless clippers with metal blades, can be attached to the vacuum hose for hair collection. Comes with multiple guide combs (1/8", 1/4", 3/8", 1/2", 3/4", 1").
- **Slicker Brush:** For general brushing and de-shedding, with vacuum suction.
- **De-shedding Brush:** Curved blades designed to fit the pet's back and head, with vacuum suction.
- **Round Nozzle:** A general-purpose drying nozzle suitable for most breeds.
- **Flat Nozzle:** Ideal for flat-coated and sporting breeds.
- **Finger Nozzle:** Helps to pick through the undercoat and keep hair fluffy.
- **Roller:** For effectively removing pet hair from sofas and clothes.
- **Long Nozzle:** For cleaning carpets, sofas, and hard-to-reach corners.

- **Storage Bag:** For convenient storage of all tools.

4. SETUP INSTRUCTIONS

Follow these steps to set up your oneisall Dog Grooming Vacuum & Dryer:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Connect Hose:** Attach the flexible hose to the main unit's intake port. Ensure it clicks securely into place.
3. **Select Attachment:** Choose the desired grooming attachment (e.g., slicker brush, clippers, dryer nozzle) and connect it to the other end of the flexible hose. For clippers, ensure they are charged via the provided USB cable if using wirelessly, or attach directly to the hose for vacuum function.
4. **Power On:** Plug the main unit into a standard 110-130V power outlet.

Your browser does not support the video tag.

Video 4.1: Demonstrates the setup and basic operation of the oneisall Dog Grooming Vacuum & Dryer, including connecting the hose and attachments.

5. OPERATING INSTRUCTIONS

5.1 Using the Vacuum & Brushing Functions

The vacuum function is ideal for de-shedding and collecting loose hair directly into the dust cup, keeping your grooming area clean.

1. **Attach Brush:** Connect the slicker brush or de-shedding brush to the hose.
2. **Select Vacuum Mode:** On the main unit, switch the mode selector to "Cleaner" (vacuum) mode.
3. **Adjust Suction:** Use the speed control knob to adjust the suction power. Start with a low setting to acclimate your pet, then increase as needed.
4. **Brush Pet:** Gently brush your pet's coat. The vacuum will draw in loose hair as you brush.

No Hair Escapes to the Floor

Keep the shedding under control



Figure 5.1: A dog being groomed with the vacuum brush attachment, illustrating how hair is collected directly into the unit's dust cup.

Your browser does not support the video tag.

Video 5.2: A short preview demonstrating the vacuum brushing function, showing hair being pulled into the device.

5.2 Using the Dryer Function

The dryer function provides adjustable heat and airflow to quickly dry your pet's coat after bathing.

1. **Attach Nozzle:** Connect the round, flat, or finger nozzle to the hose.
2. **Select Dryer Mode:** On the main unit, switch the mode selector to "Dryer" mode.
3. **Adjust Temperature & Speed:** Use the temperature control knob (95°F-149°F) and speed control knob (3 levels) to set the desired heat and airflow.
4. **Dry Pet:** Direct the airflow over your pet's coat, moving the nozzle continuously to ensure even drying and prevent overheating.

Adjustable Blower Cuts Drying Time in Half



Gentle to High
Speed Airflow



Cold to
Heated Air

Save Time

50%



Figure 5.2: A dog being dried with the oneisall dryer, highlighting the adjustable airflow feature for efficient drying.

Your browser does not support the video tag.

Video 5.3: A short preview demonstrating the dryer function, showing the various nozzles and temperature settings.

5.3 Using the Pet Clippers

The pet clippers can be used independently or connected to the vacuum for a mess-free trimming experience.

1. **Charge Clippers:** Ensure the clippers are fully charged if using wirelessly.
2. **Select Guide Comb:** Choose the appropriate guide comb for the desired hair length and attach it to the clipper blade.
3. **Connect to Vacuum (Optional):** For mess-free trimming, connect the clippers to the vacuum hose and switch the main unit to "Cleaner" mode.
4. **Trim Hair:** Gently guide the clippers through your pet's hair, moving in the direction of hair growth for a smooth cut.

Won't Get Stuck in the Coats

Metal Blades



Figure 5.3: The onesall pet clippers with different guide combs, allowing for various hair lengths.

6. MAINTENANCE

Regular cleaning and maintenance ensure optimal performance and longevity of your grooming kit.

1. **Empty Dust Cup:** After each grooming session, or when the dust cup is full, detach it from the main unit and empty the collected hair.

2. **Clean Filter:** The main unit contains a filter that should be cleaned regularly. Remove the filter and tap out any trapped hair or debris. For thorough cleaning, the filter can be rinsed with water and allowed to air dry completely before reinserting.
3. **Clean Attachments:** Remove any hair or debris from the brushes, nozzles, and clipper blades. Use the provided cleaning brush for hard-to-reach areas. Clipper blades may require occasional oiling for smooth operation (clipper oil not included).
4. **Store Properly:** Store all tools and the main unit in the provided storage bag in a dry, safe place.




Figure 6.1: The dust cup filled with pet hair after a grooming session, demonstrating the effective hair collection.

Your browser does not support the video tag.

Video 6.2: A short preview demonstrating the process of emptying the dust cup and cleaning the filter.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Suction Power	Dust cup full; Filter clogged; Hose or attachment blocked.	Empty dust cup; Clean filter; Check hose and attachments for blockages.
Device Not Turning On	Not plugged in; Power switch off; Power outlet issue.	Ensure device is properly plugged in; Turn power switch on; Test power outlet with another device.
Excessive Noise	Blockage in hose/attachment; Motor issue.	Check for and remove any blockages; If problem persists, contact customer support.
Clippers Not Cutting Smoothly	Blades dull or dirty; Hair tangled in blades.	Clean and oil blades; Ensure hair is detangled before clipping.

8. SPECIFICATIONS

Feature	Detail
Model Name	BM1
Brand	oneisall
Item Weight	10.63 pounds
Product Dimensions	8.7 x 5 x 12.8 inches
Power Source	Corded Electric
Working Voltage	110-130 V
Hose Length	59 inches
Dust Cup Capacity	84.5 oz
Noise Level	Under 60dB
Material	Metal

9. WARRANTY AND SUPPORT

The oneisall Dog Grooming Vacuum & Dryer comes with a 2-Year Manufacturer Warranty. For any inquiries or support, please contact oneisall customer service via mail or hotline. They aim to respond immediately to all customer concerns. For further assistance, please visit the official oneisall store:[oneisall Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question