

[Manuals.plus](#) /

› [Alohappy](#) /

› Alohappy Mid-Century Modern TV Stand (Model B0C2471DPS) Instruction Manual

Alohappy B0C2471DPS

Alohappy Mid-Century Modern TV Stand (Model B0C2471DPS) Instruction Manual

Your guide to assembly, operation, and care.

1. INTRODUCTION

Thank you for choosing the Alohappy Mid-Century Modern TV Stand. This entertainment center is designed to accommodate TVs up to 65 inches, featuring a stylish design with clean lines, a rustic brown finish, and practical storage solutions. It includes a spacious tabletop, adjustable side shelves, a central open shelf, and a storage drawer, complemented by convenient sliding doors. This manual provides essential information for safe assembly, proper use, and maintenance of your new TV stand.

2. SAFETY INFORMATION

- **Read all instructions carefully:** Before assembly and use, ensure you understand all steps and warnings.
- **Two-person assembly recommended:** Due to the weight and size of the components, assembly and moving the unit should be performed by two adults to prevent injury and damage.
- **Weight capacity:** Do not exceed the maximum weight capacity of 150 lbs (68 kg) for the top surface. Distribute weight evenly across shelves and the top.
- **Secure placement:** Place the TV stand on a flat, level, and stable surface. Avoid placing it near heat sources or in direct sunlight.
- **Tip-over prevention:** For added safety, especially in homes with children, consider securing the TV stand to the wall using appropriate anti-tip hardware (not included).
- **Cable management:** Utilize the cable management hole at the back to organize and hide

wires, reducing tripping hazards and improving ventilation.

3. PACKAGE CONTENTS

Please verify that all parts listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- TV Stand components (numbered parts)
- Assembly hardware (screws, dowels, etc.)
- Metal handles
- Solid wood legs with foot pads
- Assembly manual

4. SETUP AND ASSEMBLY

The Alohappy Mid-Century Modern TV Stand is designed for straightforward assembly. An estimated assembly time is approximately 30 minutes. All necessary tools and numbered parts are included. For optimal safety and ease, **two people are recommended for assembly**.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all numbered parts and hardware according to the included assembly manual.
3. Follow the step-by-step instructions in the assembly manual to construct the frame of the TV stand.
4. Attach the solid wood legs securely to the base of the unit.
5. Install the center drawer and ensure it slides smoothly on its metal guide rails.
6. Insert the adjustable shelves into the desired positions within the side compartments.
7. Attach the metal handles to the sliding doors.
8. Carefully place the sliding doors onto their tracks, ensuring they move freely.
9. Once assembled, gently lift and move the TV stand to its final desired location. Avoid dragging the unit to prevent damage to the legs or floor.



Image: The Alohappy Mid-Century Modern TV Stand fully assembled in a living room environment, showcasing its design and functionality.



Image: Detailed dimensions of the TV stand, indicating a width of 59 inches, height of 20 inches, and depth of 16 inches.

5. OPERATING AND FEATURES

The Alohappy TV Stand offers versatile storage and a sleek aesthetic for your living space.

Key Features:

- **Spacious Desktop:** The top surface is designed to hold TVs up to 65 inches, providing a stable platform for your entertainment system.
- **Adjustable Shelves:** Both side compartments feature 3 adjustable levels, allowing you to customize storage space for various items like media players, game consoles, or decorative objects.
- **Central Storage Drawer:** A convenient pull-out drawer in the center is ideal for storing smaller items such as remote controls, charging cables, or gamepads, keeping them organized and out of sight.
- **Sliding Doors:** The modern sliding doors with metal handles move smoothly along their tracks, allowing you to conceal or display items in the side compartments as desired.
- **Cable Management Hole:** A dedicated hole at the back of the central open shelf helps manage and hide cables, ensuring a tidy appearance and good ventilation for electronic devices.
- **Durable Construction:** Made from eco-friendly MDF board with solid wood legs, ensuring stability and longevity. The waterproof surface is easy to clean.



Image: The sliding door design allows for various display modes, revealing adjustable shelves and a central drawer.

Environmental Friendly Material

Cable Management Hole for
Good Ventilation

Metal Handle Design
simple and Aesthetic

Adjustable Shelves for
Different Size Things



Image: Highlights of the TV stand's features: environmental-friendly material, cable management hole, metal handle design, and adjustable shelves.



Spacious&Smooth Surface

Made of high density particleboard,
smooth finish for easy clean

Smooth Guide Rail

Drawer with Metal Guide Rail,
Open and close the drawers easily



Stable Support Structure

Rubber wood legs ,
Durable and stylish,
support up to 150lbs

Image: Details showing the smooth surface, metal guide rail for the drawer, and solid wood legs with foot pads for stability.



Image: The central storage drawer open, illustrating its capacity for organizing small accessories.

Product Overview Video:

Your browser does not support the video tag.

Video: An overview of the Alohappy Mid-Century Furniture set, including the TV stand, demonstrating its features and aesthetic in a living room setting.

6. MAINTENANCE

To ensure the longevity and appearance of your Alohappy TV Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surface with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining or water damage.
- **Avoid direct sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood finish.
- **Check hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your TV stand, please refer to the following common solutions:

- **Wobbly unit:** Ensure the TV stand is placed on a level surface. Check that all legs are securely attached and all assembly screws are tightened.
- **Drawer not sliding smoothly:** Verify that the metal guide rails are properly aligned and free of obstructions. Ensure the drawer is correctly inserted into the rails.
- **Sliding doors sticking:** Check the door tracks for any debris or misalignment. Ensure the doors are properly seated in their grooves.
- **Missing or damaged parts:** If you received the product with missing or damaged components, please contact customer support immediately for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	Alohappy
Model Number	B0C2471DPS
Color	Brown
Material	Engineered Wood
Product Dimensions (D x W x H)	16"D x 59"W x 20"H
Item Weight	77 Pounds
Recommended TV Size	Up to 65 inches

Number of Drawers	1
Number of Shelves	7 (including adjustable levels)
Number of Doors	2 (sliding)
Handle Material	Metal
Installation Type	Freestanding
Required Assembly	Yes
Product Care Instructions	Wipe with Damp Cloth

9. WARRANTY AND SUPPORT

Alohappy is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this document, if you have any questions regarding your Alohappy Mid-Century Modern TV Stand, including assembly, missing parts, or general inquiries, please do not hesitate to contact our customer support team. We are always ready to help you. For assistance, please refer to the contact information provided with your purchase or visit the official Alohappy website.