

SOAR NCAA-BTH6-BAY

SOAR NCAA XL Shockbox Wireless Bluetooth Speaker User Manual

Model: NCAA-BTH6-BAY

WELCOME

Thank you for purchasing the SOAR NCAA XL Shockbox Wireless Bluetooth Speaker. This manual provides important information regarding the setup, operation, and maintenance of your new speaker. Please read it thoroughly before use to ensure optimal performance and safety.

IMPORTANT SAFETY INSTRUCTIONS

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Keep the speaker away from water or other liquids. This product is not waterproof.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty.
- Use only the provided charging cable or a certified equivalent.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping or subjecting the speaker to strong impacts.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- SOAR NCAA XL Shockbox Wireless Bluetooth Speaker
- Micro-USB Charging Cable
- User Manual (this document)



BLUETOOTH

WIRELESS SPEAKER

WITH LED LIGHTS



SYNC 2 TOGETHER!



LED LIGHTS



BLUETOOTH
SPEAKER

COLORFUL LED SPECTRUM WHEN SPEAKER IS ON!

Image: The retail packaging for the SOAR NCAA XL Shockbox Wireless Bluetooth Speaker, showing the speaker inside the box.

PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your SOAR Shockbox XL speaker.



Image: Front view of the SOAR NCAA XL Shockbox Wireless Bluetooth Speaker, showcasing the speaker grille with the Baylor Bears logo and the control panel at the top.



Image: Angled view of the SOAR NCAA XL Shockbox Wireless Bluetooth Speaker, highlighting its robust design, top handle, and illuminated Baylor Bears logo on the speaker grille.

Controls and Ports

- **Power Button:** Press and hold to turn the speaker on or off.
- **Mode (M) Button:** Press to switch between Bluetooth, FM Radio, USB, and AUX modes.
- **Previous Track/Volume Down Button (<<):** Press to go to the previous track. Press and hold to decrease volume.
- **Play/Pause Button (||):** Press to play or pause audio. In FM mode, press to auto-scan stations.
- **Next Track/Volume Up Button (>>):** Press to go to the next track. Press and hold to increase volume.
- **USB Port:** For playing audio from a USB flash drive.
- **AUX Input:** For connecting external audio devices via a 3.5mm audio cable.
- **Micro-USB Charging Port:** For charging the speaker's internal battery.

SETUP

Charging the Speaker

Before first use, fully charge the speaker. A full charge provides over 5 hours of playback time.

1. Connect the micro-USB end of the charging cable to the speaker's charging port.

2. Connect the USB-A end of the charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will illuminate during charging and turn off when fully charged.

Powering On/Off

1. To power on, press and hold the Power button until you hear an audible prompt and the LED lights activate.
2. To power off, press and hold the Power button again until the speaker shuts down.

OPERATING INSTRUCTIONS

Bluetooth Pairing

Connect your device to the speaker wirelessly via Bluetooth 5.0.

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by a flashing blue LED). If not, press the 'M' button to switch modes.
2. Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
3. Search for available Bluetooth devices and select "SOAR Shockbox XL" from the list.
4. Once paired, the LED indicator will stop flashing, and you will hear a connection confirmation sound.

Playing Music (USB/AUX)

The speaker supports audio playback from USB drives and external devices via AUX input.

- **USB Playback:** Insert a USB flash drive containing MP3 audio files into the USB port. The speaker will automatically switch to USB mode and begin playing.
- **AUX Input:** Connect one end of a 3.5mm audio cable (not included) to the speaker's AUX input and the other end to your audio device's headphone jack. Press the 'M' button to switch to AUX mode.

FM Radio

Listen to your favorite FM radio stations.

1. Press the 'M' button to switch to FM Radio mode.
2. Press the Play/Pause button (⏮) to automatically scan and save available FM stations.
3. Use the Previous Track (⏮) and Next Track (⏭) buttons to navigate between saved stations.

Volume and Track Control

- **Volume Up:** Press and hold the Next Track (⏭) button.
- **Volume Down:** Press and hold the Previous Track (⏮) button.
- **Next Track:** Press the Next Track (⏭) button.
- **Previous Track:** Press the Previous Track (⏮) button.

LED Light Modes

The speaker features dynamic multicolor LED lights that pulse to the rhythm of the music.

- The LED lights activate automatically when the speaker is powered on.
- Specific controls for changing LED light patterns or turning them off are not detailed in the product description, but they are designed to enhance the audio experience.

Syncing Two Speakers (TWS Function)

The SOAR Shockbox XL speaker supports True Wireless Stereo (TWS) function, allowing you to pair two speakers together for a stereo sound experience.

1. Ensure both SOAR Shockbox XL speakers are powered on and in Bluetooth mode, but not yet paired to any device.
2. On one of the speakers (this will be your primary speaker), double-press the Play/Pause button (⏮). You will hear a prompt indicating it is searching for another speaker.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation sound.
4. Now, connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.
5. Audio will now play through both speakers in stereo.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the speaker surface with a soft, dry, lint-free cloth. Do not use liquid cleaners or sprays.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

TROUBLESHOOTING

If you encounter any issues with your speaker, please refer to the following table for common problems and solutions.

Problem	Solution
Speaker does not turn on.	Ensure the speaker is charged. Connect it to a power source using the micro-USB cable.
Cannot pair with Bluetooth device.	Ensure the speaker is in Bluetooth pairing mode (flashing blue LED). Make sure Bluetooth is enabled on your device and it is within range (up to 33 feet). Forget previous pairings on your device and try again.

Problem	Solution
No sound or low volume.	Increase the volume on both the speaker and your connected device. Ensure the correct input mode (Bluetooth, USB, AUX) is selected.
FM radio reception is poor.	Reposition the speaker to improve signal reception. Ensure no strong interference sources are nearby.
LED lights are not working.	Ensure the speaker is powered on. If the issue persists, contact customer support.

TECHNICAL SPECIFICATIONS



Image: Diagram showing the dimensions of the SOAR NCAA XL Shockbox Wireless Bluetooth Speaker: 9.46 inches (height), 6.71 inches (width), and 3.95 inches (depth).

Feature	Detail
Model Name	Shockbox Wireless Bluetooth Speaker
Speaker Type	Subwoofer



[NCAA Championships Speaker User Manual - Features, Setup, and Operation](#)

Comprehensive user manual for the NCAA Championships Speaker (Breakaway Speaker model). Learn about its features, Bluetooth pairing, TWS mode, AUX and SD card usage, music controls, maintenance, and FCC compliance.



[2023-24 Creighton Men's Basketball NCAA Tournament Game Notes vs. Akron](#)

Official game notes for the 2023-24 Creighton Men's Basketball NCAA Tournament game against Akron, featuring team statistics, player profiles, and historical data.




[SOAR SR-HFBL Wireless Headphones User Manual](#)

User manual for the SOAR SR-HFBL Wireless Headphones, detailing pairing, auxiliary mode, TF card/USB drive mode, FM radio mode, and product specifications. Includes warranty information and FCC compliance.



[Ivy League Manual 2022-2023: A Comprehensive Guide to Athletic Policies and Procedures](#)

The official Ivy League Manual for the 2022-2023 academic year, detailing principles, organization, eligibility rules, athletic administration, and financial matters for member institutions.



[2023-24 Pitt Men's Basketball Media Guide](#)

Official media guide for the 2023-24 Pitt Panthers men's basketball season, featuring player profiles, coaching staff, schedule, media information, and historical data.