

[manuals.plus](#) /› [Funistree](#) /› [Funistree Modern Candle Warmer Lamp RLD-HS User Manual](#)

Funistree RLD-HS

Funistree Modern Candle Warmer Lamp RLD-HS User Manual

Model: RLD-HS

Brand: Funistree

1. INTRODUCTION

Thank you for choosing the Funistree Modern Candle Warmer Lamp. This innovative device allows you to enjoy the fragrance of your favorite jar candles without an open flame, providing a safer and cleaner alternative to traditional candle burning. Its adjustable height, dimmable light, and integrated timer offer convenience and enhance your home's ambiance.



Image 1.1: The Funistree Modern Candle Warmer Lamp in a home setting.

2. SAFETY INSTRUCTIONS

- This product operates without an open flame, significantly reducing fire hazards.
- Always place the candle warmer lamp on a stable, flat, and heat-resistant surface.
- Keep the device out of reach of children and pets.
- Do not touch the bulb or the area directly beneath it when the lamp is in operation, as it can become hot.
- Ensure the power cord is not pinched or placed under heavy objects.
- Unplug the lamp from the power outlet when not in use or before cleaning.
- Do not immerse the lamp in water or any other liquid.
- Use only the specified 50W GU10+C halogen bulbs.

SAFE AND ECO-FRIENDLY

Candle Warmer Lamp



<ul style="list-style-type: none">• No Open Flame• Timer & Dimmer• Enhance Aroma• Make Candles Last Longer		<ul style="list-style-type: none">• Risk of Causing Fire• Soot or Residue• Burn Unevenly• Waste Candle's Fuel
---	---	--

Image 2.1: Flameless operation for enhanced safety.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Funistree Modern Candle Warmer Lamp
- 2 x Halogen bulbs (GU10+C, 120V 50W)
- 1 x Instruction Manual

4. SETUP

1. **Insert the Bulb:** Carefully insert one of the provided 50W halogen bulbs into the lamp holder located under the lampshade. Twist gently to secure it.
2. **Place the Lamp:** Position the candle warmer lamp on a stable, flat surface.
3. **Place the Candle:** Place your desired jar candle onto the wooden base of the lamp.
4. **Adjust Height:** Loosen the knob on the vertical arm to adjust the height of the lampshade. Ensure the bulb is positioned directly above the candle, with sufficient clearance to avoid contact but close enough for effective warming. Tighten the knob to secure the height.
5. **Connect Power:** Plug the power cord into a standard 110V AC electrical outlet.



Image 4.1: Key components and adjustable features of the lamp.

5. OPERATING INSTRUCTIONS

- Power On/Off:** Press the power button on the inline controller to turn the lamp on or off.
- Adjust Brightness (Dimmer):** Use the '+' and '-' buttons on the controller to adjust the brightness of the halogen bulb. There are four dimmable levels (e.g., 15W, 30W, 43W, 51W) to control the melting speed of the candle and the intensity of the fragrance release. A brighter setting will melt the wax faster and release a stronger scent.
- Set Timer:** Press the timer button to select an automatic shut-off time. Options include 2 hours, 4 hours, or 8 hours. This feature helps prevent accidental prolonged operation.

Melt and release fragrance within a few minutes.



(2/4/8H) Timer & Brightness Adjustable



Image 5.1: Timer and dimmable control for customized use.



Image 5.2: The lamp provides a cozy environment for relaxation.

6. MAINTENANCE

- Cleaning:** Ensure the lamp is unplugged and completely cool before cleaning. Wipe the metal and wood surfaces with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Bulb Replacement:** If the bulb burns out, ensure the lamp is unplugged and cool. Carefully remove the

old bulb by twisting it out. Insert a new GU10+C 50W halogen bulb, twisting gently to secure.

7. TROUBLESHOOTING

- **Lamp Not Turning On:** Check if the power cord is securely plugged into the outlet and the lamp. Verify that the bulb is correctly installed and not burnt out.
- **Candle Not Melting / Scent Not Strong:** Ensure the lampshade height is adjusted appropriately, allowing the bulb's heat to reach the candle wax effectively. Increase the brightness setting using the dimmer control.
- **Intermittent Operation:** Check the power cord for any damage or loose connections. Ensure the bulb is securely seated.

8. SPECIFICATIONS

Feature	Detail
Model Number	RLD-HS
Color	A1-black
Material	Metal, Wood
Product Dimensions	5.3" L x 5.3" W x 10.5" H (Adjustable height: 10.5" - 13.7")
Item Weight	1.81 Pounds
Finish Type	Powder Coated
Bulb Type	Halogen (GU10+C)
Wattage	50 watts (Dimmable)
Voltage	110 Volts (AC)
Special Features	Dimmable, Height Adjustable, Timer (2H, 4H, 8H)
Power Source	Corded Electric

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or reach out to Funistree customer service directly.