Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Goeco 30928205

Goeco Modern Ceiling Fan with Lights

User Manual

1. Introduction

Thank you for choosing the Goeco Modern Ceiling Fan with Lights. This product combines a stylish design with practical functionality, offering adjustable lighting and fan speeds to enhance your living space. This manual provides essential information for safe installation, operation, and maintenance of your new ceiling fan.



Figure 1: Goeco Modern Ceiling Fan with Lights in operation, highlighting its unique design and airflow.

2. Safety Information

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- **Electrical Safety:** Always cut off the main power supply at the circuit breaker before installing, cleaning, or performing any maintenance on the fan. Ensure the voltage (110V) matches your household electrical supply.
- **Installation:** Installation should be performed by a qualified electrician or a person with sufficient knowledge of electrical wiring. Ensure the mounting surface can support the weight of the fan.
- **Blade Clearance:** Ensure there is adequate clearance between the fan blades and any obstacles (walls, furniture, etc.) to prevent injury or damage.

- **Cleaning:** Always disconnect power before cleaning. Use a soft, dry cloth for cleaning. Do not use abrasive cleaners or solvents.
- **Children and Pets:** Keep children and pets away from the fan during operation and installation.

3. Package Contents

Carefully unpack the box and ensure all items are present and undamaged. If any items are missing or damaged, please contact customer support.

- 1 x Goeco Ceiling Fan with Lights
- 1 x Remote Control
- 1 x User Manual (this document)
- 1 x Installation Package (screws, anchors, wiring connectors)





Figure 2: All components included in the Goeco Ceiling Fan package.

4. Specifications

Feature	Specification
Type	Ceiling Fan with Lights
Color	Black
Style	Modern, Minimalism
Wattage	53W

Voltage	110V
Control Method	Remote Control / APP Control
Color Temperature	3000K - 6500K (Stepless Dimming)
Brightness	0% - 100%
Fan Speeds	6 Speeds
Functions	Memory Lighting, 2H Timer, Reversible Wind
Product Dimensions	L 29.52" x W 29.52" x H 2.75" (75cm x 75cm x 7cm)
Material	Acrylic, Aluminum
Recommended Room Size	150-300 ft²



Product Details

Color: Black	Timing： 2H
Type: Ceiling Fan with Lights	Wattage: 53W
Style: Modern, Minimalism	Voltage: 110V
Light Source： LED Dimmable	Room Size: 150-300 ft²

Figure 3: Product dimensions and key specifications.

5. Setup and Installation

Follow these steps for proper installation. It is highly recommended to have a second person assist during installation.

1. **Prepare for Installation:** Ensure the main power supply to the installation area is turned off at the circuit breaker.
2. **Open Back Base:** According to the instructions, carefully open the back base of the ceiling lamp by hand.
3. **Fix Base to Ceiling:** Fix the back base of the ceiling light securely to the ceiling using the provided screws and appropriate anchors.
4. **Wire Connections:** Connect the live wire and neutral wire from your household electrical supply to the corresponding wires on the fan. This model does not require an earth wire connection. Ensure all connections are secure.
5. **Close Ceiling Lamp:** Carefully close the ceiling lamp, ensuring it is properly aligned and secured according to the correct direction.

Important: If you are unsure about any step, consult a qualified electrician.

6. Operating Instructions

Your Goeco Ceiling Fan can be controlled via the included remote control or a smart APP.

6.1 Remote Control Operation

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed Adjustment:** Use the fan speed buttons (1-6) to select your desired airflow. 1-2 for soft air supply, 3-4 for natural wind, and 5-6 for strong wind.
- **Light Color Temperature:** Adjust the light color temperature from 3000K (Warm White) to 6500K (Cold White) using the dedicated buttons.
- **Brightness Adjustment:** Increase or decrease the light brightness from 0% to 100%.
- **Timer Function:** Activate the 2-hour timer function to automatically turn off the fan after 2 hours.
- **Memory Function:** The fan light will restore to the last used color and brightness settings when turned on again.
- **Reversible Wind:** Use the reversible function to change the direction of airflow. In summer, the fan rotates counter-clockwise to create a cooling breeze. In winter, it rotates clockwise to circulate warm air downwards, reducing temperature differences.



Figure 4: Fan speed settings and their effects.



Figure 5: Reversible wind function for year-round comfort.




Figure 6: Adjustable color temperature and brightness via remote or app.

6.2 Smart APP Control

To use the smart APP control, scan the QR code provided in the manual or on the product packaging to download the application. Follow the in-app instructions to pair your device.

- **Pairing:** Long press the "PAIR CODE" button on the remote control within 5 seconds of turning on the light. If it beeps 2 times, the code is successfully matched.
- The APP offers similar controls to the remote, including fan speed, light color, brightness, timer, and reversible wind functions, with an intuitive graphical interface.



Figure 7: Instructions for using the smart APP control, including pairing and app download.

7. Maintenance

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Before cleaning, always cut off the power supply. Use a soft, lint-free cloth to wipe down the fan and light fixture. Do not use water or harsh chemicals, as they may damage the finish or electrical components.
- **Dust Removal:** Periodically remove dust from the fan blades and light cover to maintain airflow and light output.
- **Inspection:** Occasionally check all screws and connections to ensure they are tight and secure.

8. Troubleshooting

If you encounter any issues with your Goeco Ceiling Fan, please refer to the following common problems and solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Fan does not turn on	No power supply; Loose wiring; Remote control battery low	Check circuit breaker; Verify wiring connections; Replace remote control batteries.
Light does not turn on	No power supply; Loose wiring; Light setting is off	Check circuit breaker; Verify wiring connections; Ensure light is turned on via remote/app.
Fan makes unusual noise	Loose screws; Obstruction; Improper installation	Tighten all mounting screws; Check for any objects interfering with blades; Re-check installation steps.
Remote control not working	Battery low/dead; Not paired correctly	Replace batteries; Re-pair remote control with the fan (refer to section 6.2).

9. Warranty and Support

Goeco is committed to customer satisfaction. Your product comes with the following:

- **30-Day Full Refund:** If you are not satisfied with your purchase within 30 days, you are eligible for a full refund.
- **48-Month Warranty:** We offer a 48-month (4-year) warranty on new replacement products for any manufacturing defects or malfunctions.

If you have any questions, concerns, or require technical assistance, please do not hesitate to contact our customer support team. We aim to respond to all inquiries within 12 hours.

Contact Information: Please refer to the contact details provided on your purchase receipt or our official website.

© 2024 Goeco. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C27RRBQG

More documents and user manuals: **https://manuals.plus/**