

Exquisit KS116-0-041E

Exquisit KS116-0-041E Refrigerator Instruction Manual

Model: KS116-0-041E

1. IMPORTANT SAFETY INSTRUCTIONS

Please read this instruction manual carefully before using the appliance and keep it for future reference. Incorrect use may result in damage to the appliance or injury to the user.

- Ensure the appliance is properly grounded.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not damage the refrigerant circuit.
- This appliance is intended for household use only.
- Unplug the appliance before cleaning or maintenance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

2. PRODUCT OVERVIEW

The Exquisit KS116-0-041E is a compact refrigerator designed for efficient food storage. It features a 90-liter capacity, an integrated freezer compartment, and a reversible door hinge for flexible placement.



Image: The Exquisit KS116-0-041E refrigerator with its door open, showcasing the interior layout including shelves and compartments.

Key Features:

- **Integrated LED Lighting with Thermostat:** The temperature control is seamlessly integrated into the

bright LED interior lighting.

- **Spacious Vegetable Compartment:** Designed to keep fruits and vegetables fresh and crisp.
- **Adjustable Glass Shelves:** The height of the glass shelves can be configured to suit your storage needs.
- **0-Degree Compartment:** Provides dedicated space for items requiring colder storage, such as ice-cooled products.
- **Reversible Door Hinge:** Allows for flexible installation by changing the door opening direction.
- **Practical Ice Cube Compartment:** A dedicated space for making or storing ice.



90 Liter
Nutzinhalt



Stufenlose
Temperaturregelung



Wechselbarer
Türanschlag



Einfach das, worauf es ankommt.

exquisit

Image: The refrigerator highlighting its 90-liter usable capacity, stepless temperature control, and reversible door hinge.

Überall platzierbar dank austauschbaren Türanschlag.



Einfach das, worauf es ankommt.

exquisit

Image: A close-up view of the stepless temperature control dial, integrated with the LED lighting, for easy operation.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove all packaging materials. Inspect the appliance for any damage during transit. Report any damage to your retailer immediately.

3.2 Placement

- Place the refrigerator on a firm, level surface.
- Ensure adequate ventilation around the appliance. Maintain a minimum clearance of 10 cm at the back and sides for proper air circulation.
- Avoid placing the appliance in direct sunlight or near heat sources such as stoves, heaters, or radiators, as this will increase energy consumption.
- The appliance is suitable for ambient temperatures between 16°C and 38°C (Climate Class N-ST).

3.3 Leveling

Adjust the leveling feet at the bottom front of the appliance to ensure it is stable and level. This prevents vibrations and ensures proper door closure.

3.4 Door Reversal

The door hinge is reversible, allowing you to change the opening direction from right to left or vice versa. Refer to the detailed instructions in the separate door reversal guide (if provided) or consult a qualified technician for this procedure.

Produktdatenblatt Haushalt-Kühlgeräte					
Name oder Handelsmarke:		Exquisit			
Anschrift des Lieferanten:		GGV Handelsgesellschaft mbH & Co. KG, August-Thyssen-Str. 8, 41564 Kaarst			
Modellkennung:		KS116-0-041E weiss			
Art des Kühlgeräts:		Kühlschrank			
Geräuscharmes Gerät		Nein	Bauart:		Freistehend
Weinlagerschrank		Nein	Anderes Kühlgerät:		Ja
Allgemeine Produktparameter:					
Parameter		Wert	Parameter		Wert
Gesamtabmessungen (in Millimeter)	Höhe	850	Gesamtrauminhalt (in dm ³ oder l)		90
	Breite	480			
	Tiefe	450			
EEI		99	Energieeffizienzklasse		E
Luftschallemissionen (dB(A) re 1 pW)		39	Luftschallemissionsklasse		C
Jährlicher Energieverbrauch (kWh/a)		85	Klimaklasse		N (gemässigte Zone) ST (subtropische Zone)
Mindestumgebungstemperatur (°C) für die das Kühlgerät geeignet ist		16	Höchstumgebungstemperatur (°C) für die das Kühlgerät geeignet ist		38
Winterschaltung		Nein			
Fachparameter:					
Fachtyp	ja / nein	Rauminhalt des Fachs (in dm ³ oder l)	Empfohlene Temperatur-einstellung für eine optimierte Lebensmittellagerung (in °C)	Gefriervermögen (kg/24h)	Entfrosterart (automatische Entfrosterung = A, manuelle Entfrosterung = M)
Speisekammerfach	-	-	-	-	-
Weinlagerfach	-	-	-	-	-
Kellerfach	-	-	-	-	-
Lagerfach für frische Lebensmittel	Ja	90.0	+4	-	M
Kaltlagerfach	-	-	-	-	-
0-Sterne- oder Eisbereiterfach	-	-	-	-	-
1-Sterne-Fach	-	-	-	-	-
2-Sterne-Fach	-	-	-	-	-
3-Sterne-Fach	-	-	-	-	-
4-Sterne-Fach	-	-	-	-	-
2-Sterne-Abteil	-	-	-	-	-
Fach mit variabler Temperatur	-	-	-	-	-
Schnelleinfrierfunktion			Nein		
Lichtquellenparameter:					
Art der Lichtquelle					
Energieeffizienzklasse					
Mindestlaufzeit der vom Hersteller angebotenen Garantie		24 Monate			
Weitere Angaben:					
Weblink zur Webseite des Herstellers		www.exquisit.de			
Normative Referenz		EN 62552-1:2020, EN 62552-2:2020, EN 62552-3:2020			
		EN 60704-1:2010 +A11:2012			
		EN 60704-2:2013 +A11:2015 +A1:2019			
Verordnung		EU 2019/2016, EU 2019/2019			

31.08.2022

Image: The interior of the refrigerator, illustrating the design that allows for the door hinge to be reversed for flexible

placement.

3.5 Electrical Connection

Connect the appliance to a properly installed and grounded power outlet (220-240 V ~ / 50 Hz). Ensure the power cord is not pinched or damaged. The power cable length is 160 cm.

3.6 Initial Startup

After installation, wait for at least 2-4 hours before plugging in the appliance to allow the refrigerant to settle. Once plugged in, set the temperature control to a medium setting and allow the refrigerator to cool for several hours before loading it with food.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

The refrigerator features a stepless manual temperature control dial, integrated with the LED lighting, located inside the appliance. Turn the dial to adjust the cooling intensity. Higher numbers typically indicate colder temperatures.

4.2 Food Storage Guidelines

- **Refrigerator Compartment:** Store fresh foods such as dairy products, cooked meals, and beverages. Utilize the adjustable glass shelves and door shelves for organized storage.
- **Vegetable Compartment:** Ideal for storing fruits and vegetables to maintain their freshness and crispness.
- **0-Degree Compartment:** Use this specialized compartment for items that benefit from slightly colder temperatures, such as certain meats or beverages.
- **Freezer Compartment:** The small freezer compartment with a flap door is suitable for short-term storage of frozen items or for making ice cubes.



Einfach das, worauf es ankommt.

exQUISIT

Image: The interior of the refrigerator filled with various food items, demonstrating storage capacity and organization.

Einfache Bedienung durch stufenlose Temperaturregelung.



Einfach das, worauf es ankommt.

exquisit

Image: A close-up view of the practical ice cube compartment located within the refrigerator.

5. MAINTENANCE AND CLEANING

5.1 General Cleaning

Always unplug the appliance before cleaning. Clean the interior and exterior surfaces regularly with a soft cloth and a mild detergent. Avoid abrasive cleaners or solvents. Dry all surfaces thoroughly.

5.2 Defrosting

- **Refrigerator Compartment:** The refrigerator compartment features automatic defrosting. Frost will melt and evaporate automatically.
- **Freezer Compartment:** The small freezer compartment requires manual defrosting when a layer of ice builds up to about 3-5 mm. To defrost, unplug the appliance, remove all frozen items, and allow the ice to melt naturally. Do not use sharp objects to remove ice. Clean and dry the compartment before restarting the appliance.

5.3 Care for Shelves and Drawers

Remove glass shelves and drawers for thorough cleaning. They can be washed with warm soapy water and dried completely before being placed back into the appliance.

6. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate	No power supply; Plug not inserted correctly	Check power connection; Check fuse
Temperature is not cold enough	Temperature setting too high; Door opened too frequently; Warm food placed inside; Poor ventilation	Adjust temperature setting; Minimize door openings; Allow food to cool before storing; Ensure adequate clearance around appliance
Excessive frost in freezer	Door not closed properly; High humidity	Ensure door seal is intact and door closes fully; Defrost manually as needed
Unusual noises	Appliance not level; Objects touching the back wall	Adjust leveling feet; Ensure nothing is touching the appliance

7. SPECIFICATIONS

Feature	Specification
Brand	Exquisit
Model	KS116-0-041E
Type	Freestanding Refrigerator
Total Usable Volume	90 Liters
Dimensions (H x W x D)	85.0 x 48.0 x 45.0 cm
Weight (Net)	21.45 kg
Energy Efficiency Class	E
Annual Energy Consumption	85 kWh/year
Noise Level	39 dB(A)
Noise Emission Class	C
Climate Class	N-ST (16°C to 38°C ambient temperature)
Refrigerant / Quantity	R600a (26 g)
Voltage / Frequency	220-240 V ~ / 50 Hz
Current Consumption	0.55 A

Feature	Specification
Power Consumption	90 W
Power Cable Length	160 cm
Cooling Compartment Shelves	2 (1 adjustable glass shelf)
Door Shelves	3 (1 bottle rack)
Vegetable Drawer	1
Egg Tray	1
Freezer Compartments	1 (with flap door)
Temperature Control	Manual, Stepless
Door Hinge	Reversible
Handle Type	Integrated Grip
Defrosting (Freezer)	Manual
Defrosting (Refrigerator)	Automatic




Image: The official EU energy label for the Exquisit KS116-0-041E refrigerator, indicating its energy efficiency class E and annual consumption.

For more detailed product information, please refer to the EPREL database: <https://eprel.ec.europa.eu/qr/1343641>

8. WARRANTY AND SUPPORT

This Exquisit appliance comes with a **24-month manufacturer's warranty** from the date of purchase. Please

retain your proof of purchase for warranty claims.

For technical support, spare parts, or warranty service, please contact your retailer or visit the official Exquisit website: www.exquisit.de

When contacting support, please have your model number (KS116-0-041E) and serial number (if applicable) ready.