

Generic T900

## Smartwatch T900 Pro Max L Series 8 User Manual

Model: T900 Pro Max L Series 8 | Brand: Generic

### 1. INTRODUCTION

Thank you for choosing the Smartwatch T900 Pro Max L Series 8. This device is designed to enhance your daily life with its versatile features and user-friendly interface. This manual will guide you through the setup, operation, and maintenance of your new smartwatch.



## 2. WHAT'S IN THE BOX

Upon unboxing your Smartwatch T900 Pro Max L Series 8, you should find the following items:

- Smartwatch T900 Pro Max L Series 8 (with pre-attached strap)
- Magnetic Charging Cable
- User Manual

## 3. PRODUCT OVERVIEW

The T900 Pro Max L Series 8 Smartwatch features a 1.92-inch HD screen, offering clear visuals and easy navigation. It includes a scroll crown for intuitive menu control and a comfortable, flexible strap that is also replaceable.

# Scroll Crown

## Control the menu easiliy ever



Switch watch face



Switch menu



Figure 3.1: Smartwatch with visible scroll crown and menu interface.

# BIG screen



Figure 3.2: The 1.92-inch HD display of the smartwatch.

## 4. CHARGING THE SMARTWATCH

To charge your smartwatch, connect the magnetic charging cable to the charging points on the back of the watch. Ensure the pins align correctly. Plug the USB end of the cable into a compatible USB power adapter (not included) or a computer USB port. The watch screen will indicate charging status.

## 5. INITIAL SETUP & APP CONNECTION

To unlock the full potential of your smartwatch, it is recommended to connect it to your smartphone via the dedicated application. Scan the QR code provided in the user manual or on the watch itself to download the companion app. Follow the in-app instructions to pair your device.

## 6. OPERATING THE SMARTWATCH

### 6.1. Navigation

The smartwatch features a touch-sensitive screen and a functional scroll crown for navigation:

- **Swipe Gestures:** Swipe left, right, up, or down on the screen to navigate through different menus, notifications, and watch faces.
- **Scroll Crown:** Rotate the scroll crown to scroll through lists or zoom in/out on certain interfaces. Press the crown to return to the home screen or confirm selections.

### 6.2. Key Features

The T900 Pro Max L Series 8 Smartwatch offers a range of features:

- **Bluetooth Call:** Make and receive calls directly from your watch when connected to your smartphone.
- **Phonebook:** Access your phone's contacts for quick dialing.
- **Message Notifications:** Receive alerts for SMS, WhatsApp, Facebook, and Twitter messages.
- **Heart Rate Monitor & ECG:** Track your heart rate and perform ECG measurements for health insights.
- **Sleep Tracker:** Monitor your sleep patterns to help improve sleep quality.
- **Steps Counter:** Track your daily steps and activity levels.
- **Fitness Modes:** Includes various sports modes such as Running, Sit-ups, Jumping Jack, Walking, Pingpong, Badminton, Rope Skipping, Basketball, and Riding to track your workouts.
- **Utility Functions:** Features like Alarm Clock, Stopwatch, Timer, and Flashlight are built-in for convenience.
- **Weather:** Get real-time weather updates.
- **Music Control:** Control music playback on your connected smartphone.
- **Camera Remote:** Use your watch as a remote shutter for your smartphone camera.
- **Custom Watch Faces:** Personalize your watch with custom watch faces, including using your own photos.
- **AI Voice Assistant:** Utilize voice commands for various tasks.

# Smart Voice Call

## HD original sound



Figure 6.1: Smart Voice Call feature with HD original sound.






Figure 6.2: AI Voice Assistant in action.

## Bodybuilding And help you do it,Fitness goals

Equipped with motion sensors,intelligent calculation of movement,walking distance, efficient and scientific guidance of exercise,to maximize the movement effect; support a variety of motion modes.Meet different sports needs,let you fall in love with sports in-stantly.



Figure 6.3: Fitness tracking modes for various activities.



# Many functions

Alarm clock, stopwatch, timer, flashlight...

Wear a wonderful smart life on your wrist.



Alarm clock  
Customizable



Stopwatch  
data is accurate



Timer  
Reminder

Figure 6.4: Alarm, Stopwatch, and Timer functions.

# CUSTOMIZE YOUR OWN WATCH FACE

Choose one of your favorite photo, select the component style, and change the component position to form your devila and exclusive watch face.



Figure 6.5: Customizing your watch face.

## 7. STRAP REPLACEMENT

The smartwatch strap is designed for easy replacement. To remove a strap, slide it out from the watch body. To attach a new strap, align it with the slot and slide it in until it clicks securely into place. This allows for personalization and easy cleaning.

# T900 Pro Max L



Figure 7.1: The T900 Pro Max L Series 8 Smartwatch in different colors, highlighting strap versatility.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	T900 Pro Max L Series 8
Screen Size	1.92 Inches
Operating System	Wear OS
Connectivity Technology	Bluetooth (4.2 + 3.0 Dual Mode)

Special Features	Camera Remote, Heart Rate Monitor, ECG, Sleep Tracker, Fitness Modes, AI Voice Assistant, Bluetooth Call
Battery Composition	Lithium Ion
Item Weight	0.08 Kilograms (2.89 ounces)
Manufacturer	Generic

## 9. MAINTENANCE

To ensure the longevity and optimal performance of your smartwatch, follow these maintenance guidelines:

- **Cleaning:** Wipe the screen and strap regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and dry thoroughly.
- **Avoid Water Exposure:** While the watch may have some splash resistance, it is not designed for swimming or showering. Avoid prolonged exposure to water.
- **Temperature:** Do not expose the watch to extreme temperatures (hot or cold) or direct sunlight for extended periods.
- **Charging:** Use only the provided charging cable. Avoid using damaged cables or chargers.

## 10. TROUBLESHOOTING

If you encounter any issues with your smartwatch, please refer to the following common solutions:

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the charger and wait a few minutes before attempting to power it on again.
- **Cannot connect to smartphone:** Make sure Bluetooth is enabled on your phone and the smartwatch app is open. Try restarting both devices. Ensure the watch is within Bluetooth range.
- **Inaccurate health data:** Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensors on the back of the watch.
- **Notifications not appearing:** Check your smartphone's app settings to ensure notifications are enabled for the smartwatch app and for individual applications (e.g., WhatsApp, Facebook).
- **Short battery life:** Reduce screen brightness, disable unnecessary features, and ensure the watch is fully charged before use.

If the issue persists, consider performing a factory reset via the watch settings (More > Reset). Please note that a factory reset will erase all data on the watch.

## 11. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the documentation included with your purchase or contact the retailer. For technical support or further assistance, please

reach out to the customer service provided by the seller.