

MPPD-12CRN1-BH9

Instruction Manual

Generic Replacement Remote Control for Garrison Portable Air Conditioners

Models: MPPD-12CRN1-BH9, 1028313, 1028315

INTRODUCTION

This manual provides comprehensive instructions for the proper use and maintenance of your Generic replacement remote control for Garrison Portable Air Conditioners. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity. This remote is designed to be compatible with specific Garrison models, including MPPD-12CRN1-BH9, 1028313, and 1028315.

Important Note:

- This is a replacement remote control; some advanced functions present on the original remote may not be supported.
- The estimated time displayed on the remote's screen may not be accurate.
- Ensure your air conditioner model number is listed in the compatible models before use.
- No separate instruction sheet is included with the remote. This manual serves as your guide.

PRODUCT OVERVIEW

Familiarize yourself with the remote control's layout and components.



Figure 1: Front view of the remote control. This image shows the main display screen at the top, the yellow ON/OFF button, and various control buttons for mode, fan, temperature adjustment, timer, sleep, swing, turbo, and LED functions.



Figure 2: Remote control display showing "74°F". This image highlights the remote's screen displaying a temperature setting of 74 degrees Fahrenheit, indicating active operation.



Figure 3: Back view of the remote control. This image displays the rear of the remote, including the battery compartment cover, which slides open for battery insertion.

SETUP

Battery Installation

The remote control requires **two (2) AAA batteries** (not included).

1. Locate the battery compartment on the back of the remote control (refer to Figure 3).
2. Slide the battery compartment cover downwards to open it.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use. No further programming is typically required for compatible models.

OPERATING INSTRUCTIONS

This remote control operates via infrared (IR) technology. Ensure there is a clear line of sight between the remote and the air conditioner's IR receiver.

Basic Functions

- **ON/OFF Button:** Press the yellow ON/OFF button to turn the air conditioner on or off.
- **MODE Button:** Press to cycle through available operating modes (e.g., Cool, Fan, Dry, Heat, Auto).
- **FAN Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TEMP Buttons (▲/▼):** Use these buttons to increase or decrease the desired temperature setting.
- **TIMER ON/OFF Buttons:** Set a timer for the air conditioner to turn on or off automatically. Consult your air conditioner's main manual for detailed timer programming.
- **SLEEP Button:** Activates the sleep mode, which typically adjusts temperature and fan speed for

comfortable sleep.

- **SWING/DIRECT Button:** Controls the louver swing function or directs airflow.
- **TURBO Button:** Activates a rapid cooling or heating function for quick temperature changes.
- **LED Button:** Controls the display light on the air conditioner unit.
- **SHORT CUT Button:** May recall a favorite setting or a specific function.

Changing Temperature Unit (Fahrenheit/Celsius)

The remote control's default temperature display is in Fahrenheit (°F).

To switch between Fahrenheit (°F) and Celsius (°C):

- Simultaneously press and hold both the **TEMP ▲ (Temperature Up)** and **TEMP ▼ (Temperature Down)** buttons for approximately 3-5 seconds.
- The display will switch to the alternate temperature unit. Repeat the process to switch back.

MAINTENANCE

Proper maintenance ensures the longevity and reliable operation of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the display fades. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and corrosion. Store in a cool, dry place.
- **Avoid Drops:** Protect the remote from physical impact. Dropping the remote can damage internal circuitry or the display.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries. Obstruction between remote and AC unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit.
Some functions do not work.	This is a replacement remote; not all original functions may be supported.	This is expected behavior for a replacement remote. Refer to the "Important Note" in the Introduction.
Temperature display is incorrect.	Display unit is set to Celsius instead of Fahrenheit, or vice versa.	Press and hold TEMP ▲ and TEMP ▼ simultaneously to switch units.
Estimated time on display is inaccurate.	Known limitation of this replacement remote.	This is a known characteristic and cannot be corrected.

SPECIFICATIONS

- **Product Type:** Replacement Remote Control

- **Brand:** Generic
- **Compatible Models:** Garrison MPPD-12CRN1-BH9, 1028313, 1028315 Portable Air Conditioners
- **Power Source:** 2 x AAA Batteries (not included)
- **Connectivity:** Infrared (IR)
- **Controller Type:** Button Control
- **Special Features:** Default display in Fahrenheit, switchable to Celsius by holding TEMP ▲ and TEMP ▼.

WARRANTY AND SUPPORT

As a replacement part, specific warranty details may vary. Please refer to the seller's return policy or contact the seller directly for information regarding warranty coverage or technical support for this product.

For issues related to your Garrison Portable Air Conditioner unit, please consult the original air conditioner's instruction manual or contact Garrison customer support.

Note: This product is manufactured by SZHKHXD.