

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Kyvol](#) /
- › [Kyvol E25 Robot Vacuum Cleaner User Manual](#)

## Kyvol E25

# Kyvol E25 Robot Vacuum Cleaner User Manual

Model: E25 | Brand: Kyvol

## 1. INTRODUCTION

Thank you for choosing the Kyvol E25 Robot Vacuum Cleaner. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new device. Please read this manual thoroughly before using the product and keep it for future reference.



The Kyvol E25 robot vacuum seamlessly integrates into your home, providing efficient cleaning while you enjoy time with your family.

## 2. SAFETY INSTRUCTIONS

To reduce the risk of injury or damage, read these safety instructions carefully and keep them handy when setting

up, using, and maintaining your robot.

- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children should be supervised to ensure they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Only use the power adapter supplied by the manufacturer.
- Do not use the robot in environments with open flames or fragile objects.
- Ensure the robot is not exposed to water or other liquids.
- The robot is equipped with fall prevention sensors. However, always ensure there are no significant drops or stairs without barriers where the robot operates.



The robot vacuum is equipped with sensors to detect drops and prevent falls from elevated surfaces.

### 3. PACKAGE CONTENTS

---

Please check the box for all the following items:

- Robot Vacuum Cleaner Body
- AAA Batteries for Remote Control
- Power Adapter (for Charging Station)
- Charging Station
- Remote Control
- Side Brushes (2 pairs)
- Instruction Manual
- App Usage Guide
- Cleaning Tool
- Magnetic Strip (6.6 ft/2m)
- HEPA Filter Set
- 3M Tape



All accessories and components included in the Kyvol E25 Robot Vacuum Cleaner package.

## 4. PRODUCT OVERVIEW

---

Familiarize yourself with the main components of your Kyvol E25 Robot Vacuum Cleaner.





The Kyvol E25 features a sleek design with intuitive controls and app connectivity.

## Robot Components

- **Top Panel:** Power button, Home button, Wi-Fi indicator.
- **Side:** Bumper, infrared sensors, charging contacts.
- **Bottom:** Driving wheels, side brushes, main brush, dust bin, cliff sensors.

## 5. SETUP

### 5.1 Charging Dock Placement

Place the charging dock on a hard, level surface against a wall. Ensure there is at least 1 meter (3 feet) of clear space to the sides and 2 meters (6 feet) in front of the charging dock. Plug in the power adapter.

## 5.2 Initial Charging

Place the robot on the charging dock. The indicator light will show charging status. Fully charge the robot before first use (approximately 5-6 hours).

## 5.3 App Installation & Wi-Fi Connection


Download the Kyvol app from your smartphone's app store. Follow the in-app instructions to connect your robot to your home Wi-Fi network. **Note: The robot only supports 2.4GHz Wi-Fi networks.**



Connect your robot vacuum to Wi-Fi for smart control via the app or voice commands with Alexa.

## 5.4 Boundary Strip Installation

Use the included magnetic boundary strip to create virtual walls, preventing the robot from entering specific areas. Place the strip flat on the floor in areas you want the robot to avoid.



The magnetic boundary strip allows you to define no-go zones for the robot vacuum.



The ultra-thin 7cm design allows the robot to clean under low-lying furniture where dust often accumulates.

## 6. OPERATING

---

### 6.1 Cleaning Modes

The Kyvol E25 offers four cleaning modes:

- **Auto Mode:** The robot automatically cleans the entire floor area.
- **Edge Mode:** The robot cleans along walls and furniture edges.
- **Spot Mode:** The robot intensely cleans a specific small area.
- **Manual Mode:** Control the robot's movement manually using the app or remote control.



Select from various cleaning modes to suit your specific cleaning needs.

### 6.2 Starting/Pausing/Stopping Cleaning

Press the power button on the robot, use the remote control, or the Kyvol app to start, pause, or stop a cleaning cycle.

### 6.3 Scheduling

Use the Kyvol app to set a cleaning schedule for your robot. It will automatically start cleaning at the programmed times.

### 6.4 Voice Control (Alexa)

The Kyvol E25 is compatible with Amazon Alexa. Enable the Kyvol skill in your Alexa app and link your account to



control the robot with voice commands (e.g., "Alexa, ask Kyvol to start cleaning").



Control your robot vacuum conveniently via the mobile app, remote control, or voice commands with Alexa.



The robot vacuum can easily navigate over small obstacles and transitions up to 1.5cm in height.

## 7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your robot vacuum.

### 7.1 Dust Bin & Filter Cleaning

Empty the dust bin after each use. The dust bin and filter are washable. Rinse them with water and allow them to air dry completely before reinserting.



The dustbin and filter are designed for easy washing to maintain hygiene.

## 7.2 Side Brushes

Check the side brushes regularly for tangled hair or debris. Use the cleaning tool to remove any obstructions. Replace worn brushes as needed.

## 7.3 Main Brush

Remove the main brush cover and lift out the main brush. Use the cleaning tool to cut and remove any hair or debris wrapped around the brush. Reinstall the brush and cover.

## 7.4 Sensors & Charging Contacts

Wipe the cliff sensors and charging contacts on the robot and charging dock with a clean, dry cloth to ensure proper function.

# 8. TROUBLESHOOTING

If you encounter issues with your Kyvol E25, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Robot does not turn on	Low battery; Power button not pressed	Charge the robot; Press and hold the power button for 3 seconds
Robot not charging	Charging contacts dirty; Charging dock not powered	Clean contacts; Ensure dock is plugged in
Robot gets stuck frequently	Too many obstacles; Low clearance areas	Clear obstacles; Use boundary strips for low areas
Poor cleaning performance	Dust bin full; Brushes tangled; Filter clogged	Empty dust bin; Clean brushes; Clean/replace filter
Cannot connect to Wi-Fi	Incorrect Wi-Fi band (5GHz); Wrong password	Ensure 2.4GHz network; Re-enter password; Restart router

# 9. SPECIFICATIONS

Feature	Specification
Model Name	E25



Feature	Specification
Brand	Kyvol
Suction Power	Up to 2800Pa
Battery Capacity	3200mAh Lithium-ion
Runtime	Up to 150 minutes
Charging Time	Approx. 5-6 hours
Dust Bin Capacity	700ml
Height	7.2 cm (2.83 inches)
Dimensions (L x W x H)	32.5 x 32.4 x 7.2 cm
Weight	4.59 kg (packaged)
Wi-Fi Compatibility	2.4GHz only
Voice Assistant	Alexa Compatible



The Kyvol E25 features a 3200mAh battery, providing up to 150 minutes of continuous cleaning.

## 10. WARRANTY AND SUPPORT





The Kyvol E25 Robot Vacuum Cleaner comes with a 1-year manufacturer's warranty from the date of purchase.



This warranty covers defects in materials and workmanship under normal use.

For technical support, warranty claims, or any questions regarding your product, please contact Kyvol customer service. Refer to the contact information provided in the App Usage Guide or visit the official Kyvol website for assistance.

**Note:** No official product videos from the seller were available for inclusion in this manual.

Related Documents - E25

	<p><a href="#">Kyvol Cybovac S31 LDS Robot Vacuum Cleaner User Manual</a></p> <p>This user manual provides comprehensive instructions for the Kyvol Cybovac S31 LDS Robot Vacuum Cleaner with Automatic Dust Emptying Base. It covers important safety information, product overview, getting started, operation guide, maintenance and care, troubleshooting, specifications, and regulatory compliance.</p>
	<p><a href="#">Kyvol L20 Robot Vacuum User Manual</a></p> <p>Comprehensive user manual for the Kyvol L20 Robot Vacuum Cleaner, detailing features, operation, safety instructions, and maintenance. Includes setup, charging, cleaning modes, and troubleshooting.</p>
	<p><a href="#">Kyvol Cybovac S31 Robot Vacuum Cleaner User Manual</a></p> <p>Comprehensive user manual for the Kyvol Cybovac S31 robot vacuum cleaner with automatic dust emptying base. Learn about setup, operation, maintenance, and troubleshooting.</p>
	<p><a href="#">Omni E25 Robot Vacuum Cleaner User Manual</a></p> <p>Comprehensive user manual for the Omni E25 (T2353) robot vacuum cleaner, covering setup, features, specifications, voice control, app integration, and support information.</p>

	<p><a href="#">Kyvol Cybovac E20 Robot Vacuum Cleaner User Manual</a></p> <p>Comprehensive user manual for the Kyvol Cybovac E20 robot vacuum cleaner, covering setup, operation, maintenance, troubleshooting, and technical specifications.</p>
	<p><a href="#">Eufy Robot Omni E25: Instruction for Use and Optimization Guide</a></p> <p>Comprehensive guide for the Eufy Robot Omni E25, covering cleaning performance optimization, mopping techniques, obstacle avoidance, carpet cleaning, and whole-house cleaning strategies. Includes contact information and troubleshooting tips.</p>

Documents - Kyvol – E25



[pdf] Guide

MV KYVOL E25S App V1 02 20220315 cdr Admin 7 giu 2023 — User Guide for Kyvol APP  
Control the Robot with Amazon Alexa turn on robot or name of your vacuum if you have changed the  
20082953 img mvideo ru ins |||  
...  
lang: score:19 filesize: 13.54 M page\_count: 1 document date: 2022-06-29





[pdf]

Bekijk de CE marking Kyvol E25 Robotstofzuiger Cybovac Nederlandse App Zwart Automatisch Opladen bol original media s xNZ3ANWMRxkJ |||

...

lang: score:12 filesize: 87.36 K page\_count: 1 document date: 2024-01-12