Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

IKEA IK.905.331.74

IKEA EKENÄSET Armchair User Manual

Model: IK.905.331.74 | Brand: IKEA

Introduction

Welcome to your new IKEA EKENÄSET Armchair. This manual provides essential information for safe assembly, proper use, and effective maintenance of your armchair. The EKENÄSET armchair offers clean lines and supportive comfort, suitable for various living spaces.

Safety Information

- Always follow assembly instructions carefully.
- Do not stand on the armchair.
- Ensure all fasteners are tightened securely before use and periodically check for tightness.
- Keep away from open flames and direct heat sources.
- Avoid placing the armchair in direct sunlight for prolonged periods to prevent fading.

Package Contents

Before assembly, verify that all components are present.

- Armchair frame components (wood)
- Seat cushion (Kilanda Light Beige)
- Back cushion (Kilanda Light Beige)
- Assembly hardware (screws, Allen key, etc.)
- Assembly instructions leaflet (this document)

Image: All components of the IKEA EKENÄSET Armchair, including the wooden frame parts, seat cushion, and back cushion, laid out on a floor, ready for assembly.

Setup and Assembly

Follow these steps to assemble your IKEA EKENÄSET Armchair. It is recommended to have two people for assembly.

1. Unpack all components and place them on a clean, soft surface to prevent scratches.
2. Attach the side frames to the backrest frame using the provided hardware. Do not overtighten.
3. Connect the front rail to the side frames.
4. Secure the seat support frame to the assembled base.
5. Place the seat cushion onto the seat support.
6. Position the back cushion against the backrest.
7. Once fully assembled, tighten all screws firmly.

Image: A partially assembled IKEA EKENÄSET Armchair, illustrating the wooden frame structure before cushions are added. This image helps visualize the assembly process.

Usage

The IKEA EKENÄSET Armchair is designed for indoor use as seating furniture.

- Place the armchair on a level surface.
- Use for sitting only. Avoid standing on the armchair or using it as a step stool.
- Do not exceed the recommended weight limit (refer to product packaging or IKEA website for specific details).

Image: The IKEA EKENÄSET Armchair, Kilanda Light Beige, shown in a modern living room setting, demonstrating its intended use and aesthetic.

Maintenance and Care

Frame Care

Wipe the wooden frame clean with a damp cloth and a mild cleaner. Dry thoroughly with a clean cloth.

Cushion Care

The fabric cover is not removable for washing.

- Vacuum clean regularly to remove dust and crumbs.
- For minor stains, dab gently with a clean, damp cloth and a mild fabric cleaner. Test on an inconspicuous area first.

- Do not use harsh chemicals or abrasive cleaners.
- Protect from direct sunlight to prevent fading.

Image: A close-up view of the Kilanda Light Beige fabric upholstery and the wooden armrest of the IKEA EKENÄSET Armchair, highlighting the texture and material for care reference.

Troubleshooting

Loose Connections

If the armchair feels wobbly, check all screws and tighten them securely using the provided Allen key. Do not overtighten.

Stains on Fabric

Refer to the "Cushion Care" section for instructions on how to clean stains. Act quickly to prevent stains from setting.

Squeaking Noises

Squeaking can sometimes occur due to loose connections. Re-tighten all assembly hardware. If the issue persists, disassemble and reassemble carefully, ensuring all parts are correctly aligned.

Specifications

Feature	Detail
Brand	IKEA
Model Number	IK.905.331.74
Color	Kilanda Light Beige
Material	Engineered wood frame, Fabric upholstery
Backrest Height	46 cm (18 1/8")
Width	64 cm (25 1/4")
Depth	78 cm (30 3/4")
Height	76 cm (29 7/8")
Height Under Furniture	22 cm (8 5/8")
Armrest Height	63 cm
Seat Width	56 cm
Seat Depth	50 cm (19 5/8")
Seat Height	45 cm (17 3/4")



Image: A technical diagram illustrating the precise dimensions of the IKEA EKENÄSET Armchair, including height, width, depth, and seat measurements.

Warranty and Support

For information regarding warranty coverage, please refer to the purchase documentation or contact IKEA customer service directly.

For further assistance or spare parts, please visit the official IKEA website or your local IKEA store.

© IKEA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C2C5CFV1

More documents and user manuals: **https://manuals.plus/**