Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

IKEA SOMMARLÅNKE (IK.605.443.29)

IKEA SOMMARLÅNKE LED Decorative Table Lamp User Manual

Model: SOMMARLÅNKE (IK.605.443.29)

Introduction

This manual provides essential information for the safe and efficient use of your IKEA SOMMARLÅNKE LED Decorative Table Lamp. Please read these instructions carefully before assembly, operation, or maintenance. Keep this manual for future reference.
The IKEA SOMMARLÅNKE is a modern-styled LED table lamp designed to create a cozy ambiance, suitable for outdoor use. Its battery-operated design offers flexibility in placement.

Safety Information

- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- This product is designed for outdoor use but should be protected from extreme weather conditions.
- Do not attempt to modify or disassemble the lamp beyond what is described in this manual.
- Use only the specified battery type and ensure correct polarity during installation.
- Keep batteries out of reach of children.
- Clean the lamp with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.

Package Contents

Verify that all components are present before proceeding with setup:

- IKEA SOMMARLÅNKE LED Decorative Table Lamp unit
- User Manual (this document)
- *(Batteries are typically sold separately, or if included, specify type and quantity)*

Setup

1. Battery Installation

1. Locate the battery compartment on the underside of the lamp base.
2. Open the battery compartment cover.
3. Insert the required batteries (e.g., 3 x AA batteries, not included) ensuring correct polarity (+/-) as indicated inside the compartment.
4. Securely close the battery compartment cover.



Figure 1: Lamp base with the "ON" button. The battery compartment is located on the underside.

2. Placement

Place the lamp on a flat, stable surface. While designed for outdoor use, consider placing it in a sheltered area to prolong its lifespan, especially during adverse weather.



Figure 2: The SOMMARLÅNKE lamp enhancing an outdoor setting.

Operating Instructions

Turning On/Off

To turn the lamp on or off, locate the push button switch on the top surface of the lamp base (refer to Figure 1). Press the button once to turn the light on, and press it again to turn the light off.



Figure 3: The SOMMARLÅNKE lamp providing warm ambient lighting.

Maintenance

Cleaning

To clean the lamp, wipe it with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by a dry cloth. Do not use harsh chemicals, abrasive cleaners, or immerse the lamp in water.

Battery Replacement

When the light dims or stops working, it's time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section. Always dispose of used batteries responsibly according to local regulations.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	Batteries are dead or low. Batteries are inserted incorrectly. Battery compartment cover is not fully closed.	Replace with new batteries. Check battery polarity (+/-). Ensure battery compartment cover is securely closed.
Light is dim.	Batteries are low.	Replace with new batteries.
Lamp flickers.	Loose battery connection or low batteries.	Check battery connection; replace batteries if necessary.

Specifications

Attribute	Detail
Model Name	SOMMARLÅNKE
Manufacturer Reference	IK.605.443.29
ASIN	B0C2C5LKW7
Brand	IKEA
Lamp Type	LED
Power Source	Battery Powered
Shade Material	Glass
Shade Colour	White
Product Colour	Yellow (accents)
Switch Type	Push Button
Dimensions	33 cm height (approx.)
Intended Use	Decorative Outdoor Lighting

Warranty and Support

For information regarding warranty, returns, or technical support, please refer to the official IKEA website or contact IKEA customer service directly. Keep your proof of purchase for warranty claims.

IKEA Official Website: www.ikea.com

Note: Warranty terms may vary by region.

© 2023 IKEA. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C2C5LKW7

More documents and user manuals: **https://manuals.plus/**