

[Manuals.plus](#) /

› [IKEA](#) /

› IKEA IDANÄS Desk with Add-on Unit User Manual

IKEA IDANÄS a01bf61c-3f9d-411b-8af8-635535f6b4c2

IKEA IDANÄS Desk with Add-on Unit User Manual

Model: IDANÄS (a01bf61c-3f9d-411b-8af8-635535f6b4c2)

INTRODUCTION

This manual provides essential information for the assembly, use, maintenance, and troubleshooting of your IKEA IDANÄS desk with add-on unit. Please read these instructions carefully before beginning assembly or using the product to ensure safe and proper operation.



Figure 1: The IKEA IDANÄS desk with its integrated add-on unit, presented in a clean white finish. This image shows the overall design, including the central drawer, two side cabinets, and the elevated shelf unit.

SAFETY INFORMATION

Always follow these safety guidelines to prevent injury or damage to the product:

- Ensure all components are present and undamaged before assembly. Do not proceed with assembly if parts are missing or damaged.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Always use the recommended tools for assembly. For this product, a screwdriver is recommended.
- Tighten all fasteners securely, but do not overtighten, as this may strip threads or damage components.
- Periodically check all fasteners and re-tighten if necessary to maintain stability.
- Do not stand or sit on the desk.
- Distribute weight evenly on the desk surface and shelves. Avoid placing heavy items on the edges or in a way that could cause tipping.
- Keep small parts and packaging materials away from children to prevent choking hazards.

PACKAGE CONTENTS

The IKEA IDANÄS desk with add-on unit package typically includes the following main components:

- Desk frame and panels
- Drawer components
- Add-on unit components (shelf and supports)
- Hardware pack (screws, dowels, cam locks, etc.)
- Assembly instructions (separate document, if not integrated)

Please verify that all listed components and hardware are present before beginning assembly.

SETUP AND ASSEMBLY

Assembly of the IKEA IDANÄS desk with add-on unit is required. It is recommended that **one person** performs the assembly. The primary tool required is a **screwdriver**.

Preparation:

- Clear a spacious area for assembly.
- Lay out all components and hardware, organizing them for easy access.
- Have a screwdriver readily available.

Assembly Steps (General Overview):

1. Begin by assembling the main desk frame, attaching the side panels and back panel.
2. Install the drawer slides and assemble the drawer box. Insert the completed drawer into its designated slot.
3. Attach the cabinet doors to the side units.
4. Assemble the add-on unit by connecting the shelf to its support structures.
5. Securely attach the add-on unit to the top of the desk.
6. Ensure all screws and fasteners are tightened.

Refer to the detailed graphical instructions provided with your product for step-by-step guidance.




Figure 2: Detailed dimensions of the IKEA IDANÄS desk. The desk measures 152 cm (59 7/8") in width, 70 cm (27 1/2") in depth, and 75 cm (29 1/2") in height. The drawer measures 65 cm (25 5/8") wide, 38 cm (15") deep, and 8 cm (3 1/8") high.




Figure 3: Detailed dimensions of the IKEA IDANÄS add-on unit. The add-on unit measures 152 cm (59 7/8") in width, 30 cm (11 3/4") in depth, and 13.6 cm (5 1/2") in height.

OPERATING AND USAGE

The IKEA IDANÄS desk is designed for home office use, providing a spacious work surface, integrated storage, and an elevated add-on unit for additional organization.

- **Work Surface:** Use the main desk surface for your computer, documents, and other work essentials.
- **Drawer:** The central drawer is suitable for storing smaller office supplies, pens, and personal items.
- **Side Cabinets:** The two side cabinets offer concealed storage for larger items, files, or equipment.
- **Add-on Unit:** The elevated add-on unit provides extra shelving space for books, decorative items, or monitors, helping to keep your main desk clear.



Figure 4: The IKEA IDANÄS desk integrated into a home office environment, showcasing its functionality with a computer setup, office chair, and various organizational items on the desk and add-on unit.

MAINTENANCE AND CARE

To keep your IKEA IDANÄS desk in optimal condition, follow these care instructions:

- **Cleaning:** Wipe clean with a damp cloth and a mild cleaner. Wipe dry with a clean cloth. Avoid abrasive cleaners or harsh chemicals.
- **Dusting:** Regularly dust the surfaces with a soft, dry cloth.
- **Fasteners:** Periodically check all assembly fasteners (screws, bolts) and re-tighten them if they have loosened over time. This ensures the desk remains stable and safe.
- **Avoid Moisture:** Protect the desk from excessive moisture and direct heat sources.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.

TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Desk feels wobbly or unstable.	Loose fasteners; uneven floor.	Check and tighten all screws and bolts. Use furniture glides or shims under legs if the floor is uneven.
Drawer does not slide smoothly.	Improperly installed drawer slides; debris in tracks.	Ensure drawer slides are correctly aligned and securely fastened. Clean tracks of any dust or debris.
Cabinet doors are misaligned.	Hinges not adjusted correctly.	Adjust the screws on the hinges to align the doors. Refer to the assembly instructions for hinge adjustment details.
Missing parts after unboxing.	Packaging error or lost during transit.	Contact IKEA customer service with your product details and a list of missing parts.

If you encounter issues not listed here or require further assistance, please contact IKEA customer support.

SPECIFICATIONS

Feature	Detail
Brand	IKEA
Model Name	IDANÄS
Model Number	a01bf61c-3f9d-411b-8af8-635535f6b4c2
Color	White
Style	Modern
Base Material	Metal
Top Material Type	Wood
Finish Type	Painted

Feature	Detail
Special Feature	Add-on Unit
Room Type	Office
Recommended Uses	Working
Mounting Type	Freestanding
Included Components	Desk, Drawer
Required Assembly	Yes
Recommended People for Assembly	1
Tools Recommended For Assembly	Screw Driver
Number of Drawers	1 (central drawer)
Number Of Shelves	2 (on add-on unit)
Number Of Cabinets	2 (side cabinets)

Note: Dimensions are provided in the "Setup and Assembly" section.

WARRANTY AND SUPPORT

The IKEA IDANÄS desk with add-on unit comes with a**Limited Warranty**. The manufacturer's warranty covers parts and labor as specified by IKEA's standard warranty terms.

For detailed warranty information, claims, or technical support, please visit the official IKEA website or contact IKEA customer service directly. Keep your proof of purchase for warranty purposes.

IKEA Official Website: www.ikea.com

Customer Service: Refer to the IKEA website for local contact numbers and support options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C2C7XR52>

More documents and user manuals: <https://manuals.plus/>