JADEMALL 1201VL

JADEMALL Keyboard Case User Manual

Model: 1201VL

1. Introduction

Thank you for choosing the JADEMALL Keyboard Case. This product is designed to enhance your tablet experience by providing a protective case and a versatile Bluetooth keyboard, transforming your tablet into a portable laptop. This manual provides instructions for setup, operation, and maintenance to ensure optimal performance.

Compatibility

This keyboard case is specifically designed for the following Samsung Galaxy Tab models:

- Samsung Galaxy Tab S8 Plus 12.4 inch (SM-X800, SM-X806, SM-X806B, SM-X806U, SM-X806N)
- Samsung Galaxy Tab S7 FE 12.4 inch (SM-T730, SM-T733, SM-T735, SM-T736, SM-T738)
- Samsung Galaxy Tab S7 Plus 12.4 inch (SM-T970, SM-T975, SM-T976)

Please verify your tablet model number before use to ensure compatibility.




Image: Compatibility chart illustrating the supported Samsung Galaxy Tab models and their screen sizes.

2. Package Contents

Upon opening your JADEMALL Keyboard Case package, you should find the following items:

- 1 x JADEMALL Keyboard Case for Samsung Galaxy Tab S7 FE/S7 Plus/S7+ 12.4 inch (Black)
- 1 x Wireless Bluetooth Keyboard
- 1 x USB Charging Cable

- 1 x User Manual

3. Setup Guide

Initial Charging

Before first use, ensure the Bluetooth keyboard is fully charged.

1. Connect the provided USB charging cable to the keyboard's charging port.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light on the keyboard will illuminate. Charge the keyboard until this light turns off, indicating a full charge.

Bluetooth Pairing

Follow these steps to pair your JADEMALL Bluetooth keyboard with your Samsung Galaxy Tab:

1. Ensure your tablet's Bluetooth function is activated. You can usually find this in your tablet's settings menu.
2. Turn on the Bluetooth keyboard using its power switch.
3. Press the "**Connect**" button on the keyboard. The Bluetooth indicator light will begin to flash, signifying that the keyboard is in pairing mode.
4. On your tablet, search for available Bluetooth devices. You should see "Bluetooth Keyboard 3.0" appear in the list.
5. Select "Bluetooth Keyboard 3.0" to initiate the pairing process.
6. Once successfully paired, the Bluetooth indicator light on the keyboard will turn off, and your tablet will confirm the connection.



Image: The Bluetooth keyboard layout, highlighting the battery life indicator and Bluetooth connectivity symbol.

Note: *The keyboard will automatically enter sleep mode after 8-10 minutes of inactivity to conserve battery. Press any key and wait 2-3 seconds to reactivate it.*

4. Operating Instructions

Using the Keyboard

The wireless Bluetooth keyboard is magnetic and can be easily attached to or removed from the case. It features a QWERTZ German layout and 7-color backlighting for comfortable typing in various lighting conditions.




Image: A close-up view of the illuminated keyboard, showcasing its colorful backlighting in a dim environment.

The keyboard also includes a trackpad for mouse-like navigation on your tablet, enhancing productivity.



Image: A hand demonstrating the use of the integrated trackpad on the keyboard.



Image: A person typing on the keyboard case, with the tablet screen showing a video conference, illustrating a laptop-like setup.

Case Features

The protective case is made from durable PU leather with a non-slip rubber coating, offering comprehensive protection for your tablet. It features precise cutouts for all ports, buttons, and the camera.

- **Integrated Pen Holder:** A dedicated holder for your stylus (e.g., S Pen).
- **Multiple Viewing Angles:** Three built-in non-slip support grooves allow you to adjust the tablet to comfortable

horizontal viewing angles for typing, watching videos, or drawing.

- **Full Protection:** The high-quality polycarbonate shell protects your tablet from drops and bumps.




Image: The tablet case highlighting its features, including the touchpen holder, speaker cutouts, camera port, microphone, and charging port.

5. Maintenance

To ensure the longevity and optimal performance of your JADEMALL Keyboard Case, follow these maintenance

guidelines:

- **Cleaning:** Gently wipe the case and keyboard with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the keyboard case in a cool, dry place. Ensure the keyboard is turned off to preserve battery life.
- **Avoid Liquids:** Keep the keyboard and case away from liquids to prevent damage to electronic components.
- **Handle with Care:** While the case offers protection, avoid dropping or subjecting it to excessive force.

6. Troubleshooting

If you encounter any issues with your JADEMALL Keyboard Case, please refer to the following common troubleshooting steps:

- **Keyboard Not Connecting:**
  - Ensure the keyboard is charged and turned on.
  - Verify that Bluetooth is enabled on your tablet.
  - Press the "Connect" button on the keyboard to enter pairing mode.
  - Forget "Bluetooth Keyboard 3.0" from your tablet's Bluetooth settings and attempt to re-pair.
  - Restart both your tablet and the keyboard.
- **Keys Not Responding:**
  - Check if the keyboard battery is low; recharge if necessary.
  - Ensure the keyboard is not in sleep mode (press any key to wake it).
  - Confirm the Bluetooth connection is active.
- **Backlight Not Working:**
  - Ensure the keyboard is powered on.
  - Check for a dedicated backlight key or key combination (refer to keyboard markings) to toggle or adjust the backlight.

7. Specifications

Feature	Detail
Brand	JADEMALL
Model Number	1201VL (JDM-S7+/S7 FE/S7 Plus 12.4 Zoll)
Compatible Devices	Samsung Galaxy Tab S7 FE/S7 Plus/S7+ 12.4 inch (SM-T970/T975/T976/T730/T733/T735/T736/T738), Samsung Galaxy Tab S8 Plus 12.4 inch (SM-X800/SM-X806/X8SM-X806B/SM-X806U/SM-X806N)
Connectivity Technology	Bluetooth 3.0
Special Features	Magnetic, Illuminated Keyboard (7 colors), Trackpad, Multiple Viewing Angles, Pen Holder

Material	PU Leather, Polycarbonate
Color	Black/Lighting Keyboard

8. Warranty and Support

JADEMALL is committed to providing the best shopping experience and product service. If you have any questions or concerns regarding your JADEMALL Keyboard Case, please do not hesitate to contact our customer support team. We are dedicated to offering satisfactory after-sales service and solutions.

Please refer to your purchase documentation or the retailer's website for specific warranty details and contact information.

© 2023 JADEMALL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question