

[Manuals.plus](#) /

› [STORAGE MANIAC](#) /

› STORAGE MANIAC 2 Section Laundry Sorter Instruction Manual

STORAGE MANIAC IB-1005004344

STORAGE MANIAC 2 Section Laundry Sorter Instruction Manual

Model: IB-1005004344

INTRODUCTION

Thank you for choosing the STORAGE MANIAC 2 Section Laundry Sorter. This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your new laundry sorter. Please read this manual thoroughly before use to ensure proper functionality and longevity of the product.



Image: The STORAGE MANIAC 2 Section Laundry Sorter in Gray, fully assembled.

SAFETY INFORMATION

- Ensure all parts are securely fastened before use. Loose parts can cause instability.
- Do not overload the laundry bags beyond the recommended capacity of 25 lbs per bag. Overloading may damage the bags or frame.
- Keep hands and fingers clear of moving parts, especially when assembling or moving the sorter.
- Use the lockable wheels to secure the sorter in place when not in motion to prevent accidental movement.
- This product is designed for household use. Do not use it for purposes other than intended.
- Keep away from open flames or excessive heat sources.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Metal Frame Components (various bars and connectors)
- 2 x Removable Laundry Bags (Oxford cloth with waterproof coating)
- 4 x Heavy-Duty Casters (2 with locking mechanism)
- Assembly Hardware (screws, hex wrench, small nut wrench)
- Instruction Manual

SETUP AND ASSEMBLY

Follow these steps to assemble your laundry sorter. It is recommended to have a clear, flat workspace.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Check against the package contents list.
2. **Assemble the Base Frame:** Connect the horizontal bars to the vertical frame pieces using the provided hardware. Ensure the numbered parts correspond to the diagrams in the included instruction sheet.
3. **Attach Wheels:** Insert the 4 heavy-duty casters into the designated holes at the bottom of the frame. Two of these wheels are lockable; position them where they are easily accessible for locking.
4. **Install Upper Bars:** Secure the upper horizontal bars to complete the frame structure. Ensure all connections are tight for stability.
5. **Hang Laundry Bags:** Place the removable laundry bags onto the upper bars using their integrated handles. The bags are designed to hang securely within the frame.



Image: Detailed diagram illustrating the numbered components of the metal frame for correct assembly.

Assembly Video Guide

Your browser does not support the video tag.

Video: An official guide demonstrating the assembly process and features of the STORAGE MANIAC 2 Section Laundry Sorter.

OPERATING INSTRUCTIONS


The STORAGE MANIAC Laundry Sorter is designed for ease of use in organizing and transporting laundry.

- **Sorting Laundry:** Utilize the two separate bags to sort laundry as needed (e.g., lights and darks, delicates and regular).
- **Moving the Sorter:** Unlock the two lockable wheels by flipping their levers. Gently push or pull the sorter to your desired location. Once positioned, engage the wheel locks to prevent movement.
- **Removing Laundry Bags:** Each bag features sturdy metal handles. To remove a bag, simply lift it by its handles from the frame. This allows for easy transport of laundry to the washing machine without moving the entire sorter.

**6 horizontal bars
keep the frame
more stable**



Each bag holds up to



30.9 inch
(78.5 cm)

16.9 inch
(43 cm)



18.5 inch
(47 cm)

Image: Demonstrates how to easily lift and remove a laundry bag using its handles.



Large Handles



Easy Cleaning Lining



Lockable Wheels

Image: Highlights the large handles, easy-clean lining, and lockable wheels for convenient use.

MAINTENANCE

Proper care will extend the life of your laundry sorter.

- **Cleaning Bags:** The laundry bags are made of Oxford cloth with a waterproof coating. They can be easily cleaned by wiping with a damp cloth. For deeper cleaning, the bags can be removed from the frame.
- **Frame Care:** Wipe the metal frame with a soft, dry cloth to remove dust. Avoid abrasive cleaners that may damage the finish.
- **Wheel Maintenance:** Periodically check the wheels for lint or debris that may hinder smooth rolling. Clean as necessary.



Image: A hand wiping the waterproof lining of a laundry bag, demonstrating ease of cleaning.

TROUBLESHOOTING

If you encounter any issues with your laundry sorter, refer to the following common solutions:

- **Sorter is unstable or wobbly:** Ensure all screws and connectors on the metal frame are tightened securely. Check that the frame is assembled correctly according to the instructions.
- **Wheels are not rolling smoothly:** Inspect the casters for any accumulated lint, hair, or debris. Clean the wheels thoroughly. Ensure the wheel locks are disengaged.
- **Laundry bags are sagging:** Verify that the horizontal bar at the bottom of the frame is correctly installed and supporting the bags. Ensure bags are not overloaded beyond their 25 lbs capacity.
- **Difficulty removing bags:** Ensure the bags are properly seated on the upper bars and not caught on any part of the frame. Lift straight up using the metal handles.

SPECIFICATIONS

Feature	Detail
Product Dimensions	18.5" L x 16.9" W x 30.9" H
Capacity	90 Liters (approx. 2 loads), 25 lbs per bag
Number of Sections	2
Material	Alloy Steel (frame), Oxford Cloth with waterproof coating (bags)
Special Features	Scratch Resistant, Washable Bags, Wheeled (2 lockable)
Color	Gray
Item Weight	2.9 kg
Model Number	IB-1005004344

WARRANTY AND SUPPORT

For any questions, concerns, or warranty inquiries regarding your STORAGE MANIAC Laundry Sorter, please contact the manufacturer directly through their official website or the retailer where the product was purchased. Please have your model number (IB-1005004344) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question