

[Manuals.plus](#) /

› [Oumefar](#) /

› Oumefar 1080P Smart Network Security Camera Instruction Manual

Oumefar Oumefarkhbic1mfpo

Oumefar 1080P Smart Network Security Camera Instruction Manual

Model: Oumefarkhbic1mfpo

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Oumefar 1080P Smart Network Security Camera. Please read this manual thoroughly before using the product to ensure proper functionality and safety. This camera is designed for outdoor security monitoring, featuring 1080P high-definition video, motion detection, and night vision capabilities.

2. SAFETY INFORMATION

- Ensure the camera is installed in a stable location to prevent falling.
- Do not expose the camera to extreme temperatures, direct sunlight, or excessive moisture.
- Use only the specified power adapter (if applicable) or battery type.
- Keep the camera away from children and pets.
- Do not attempt to disassemble or repair the camera yourself. Contact customer support for assistance.
- Respect privacy laws and regulations when installing and operating the camera.

3. PACKAGE CONTENTS

Please check the package contents upon unboxing. If any items are missing or damaged, contact customer support.

- Oumefar 1080P Smart Network Security Camera
- Mounting Bracket/Base
- USB Charging Cable
- User Manual (this document)
- (Potentially) Screws and Wall Plugs for mounting

4. PRODUCT OVERVIEW

Familiarize yourself with the camera's components.



Figure 4.1: Front view of the Oumefar Smart Network Security Camera with its adjustable mounting base. The camera features a compact, cube-like design with a central lens and ventilation grilles on the sides.



Figure 4.2: Side view of the Oumefar Smart Network Security Camera, showing the USB charging cable connected. This image highlights the camera's compact size and the micro-USB port for power.

- **Camera Lens:** Captures 1080P high-definition video.
- **Infrared LEDs:** For night vision functionality.
- **Micro USB Port:** For power supply and charging.
- **Reset Button:** To restore factory settings (location may vary).
- **Status Indicator Light:** Shows camera status (e.g., power on, recording, network connection).
- **Mounting Base:** Adjustable base for wall or surface mounting.

5. SETUP

5.1 Charging the Camera

Before initial use, fully charge the camera using the provided USB cable and a compatible USB power adapter (not included). The status indicator light will typically change color to indicate charging status and full charge.

5.2 App Installation and Account Creation

1. Download the designated mobile application (e.g., "Smart Life" or similar, check packaging for QR code) from your smartphone's app store (Android or iOS).
2. Open the app and create a new user account. Follow the on-screen instructions to register.

5.3 Connecting the Camera to Wi-Fi

1. Power on the camera. The status indicator light should blink, indicating it's ready for pairing.
2. Open the mobile app, tap "Add Device" or the "+" icon.
3. Select "Security Camera" or the appropriate device type.
4. Follow the in-app instructions to connect the camera to your 2.4GHz Wi-Fi network. This usually involves scanning a QR code generated by the app with the camera, or entering your Wi-Fi password.
5. Once connected, the status indicator light will become solid, and the camera will appear in your app's device list.

5.4 Mounting the Camera

Choose a suitable outdoor location that provides the desired viewing angle and is within range of your Wi-Fi network. Ensure the mounting surface is stable.

1. Attach the mounting base to the desired surface using screws or the adhesive pad provided.
2. Securely attach the camera to the mounting base.
3. Adjust the camera angle for optimal coverage.

Motion Detection

Send a push alert to the mobile phone once an exception is detected



Figure 5.1: Example of camera placement for wide area surveillance. The camera's compact design allows for discreet installation.

6. OPERATING THE CAMERA

6.1 Live View

Open the mobile app and select your camera from the device list to view the live feed. You can typically pinch to zoom, take screenshots, or record video directly from the live view.



Figure 6.1: The camera positioned next to a smartphone showing its live feed, demonstrating remote monitoring capabilities.

6.2 Motion Detection

The camera features motion detection to alert you to activity. To configure:

1. In the app, navigate to the camera settings.
2. Find the "Motion Detection" or "Alert Settings" option.
3. Enable motion detection and adjust sensitivity levels as needed.
4. Set up push notifications to receive alerts on your smartphone when motion is detected.



Figure 6.2: Illustration of motion detection in action. The camera identifies movement and sends an immediate alert to the user's mobile device, displaying the detected event.

6.3 Night Vision

The camera automatically switches to infrared night vision in low-light conditions, providing clear black and white video footage.




Figure 6.3: Visual comparison demonstrating the camera's ability to capture clear images during the day and in complete darkness using infrared night vision.

6.4 Video Recording and Storage

The camera supports continuous recording or event-triggered recording (e.g., by motion detection). Video footage can typically be stored on a microSD card (not included) or via cloud storage services (subscription may be required).

- **MicroSD Card:** Insert a compatible microSD card into the camera's slot. Format the card via the app settings if prompted.
- **Cloud Storage:** Check the app for available cloud storage plans and subscription details.



Figure 6.4: Example of the camera's 1080P high-definition video quality, capturing details clearly in an indoor environment.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Do not use harsh chemicals or abrasive materials.
- **Firmware Updates:** Regularly check the mobile app for firmware updates to ensure optimal performance and security.

- **Battery Life:** If battery-powered, monitor battery levels via the app and recharge as needed.
- **Storage:** If using a microSD card, periodically check its status and capacity. Back up important footage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera not powering on	Low battery; faulty charging cable/adaptor	Charge the camera fully. Try a different USB cable or power adapter.
Cannot connect to Wi-Fi	Incorrect Wi-Fi password; camera too far from router; 5GHz Wi-Fi network used	Ensure correct 2.4GHz Wi-Fi password. Move camera closer to router. Ensure your router supports 2.4GHz. Reset camera and try pairing again.
No motion detection alerts	Motion detection disabled; incorrect sensitivity; app notifications off	Enable motion detection in app settings. Adjust sensitivity. Check phone's notification settings for the app.
Poor video quality	Dirty lens; poor Wi-Fi signal; low light conditions	Clean the camera lens. Improve Wi-Fi signal strength. Ensure night vision is active in low light.

9. SPECIFICATIONS

- **Model:** Oumefarkhbic1mfpo
- **Video Resolution:** 1080p, 720p
- **Connectivity:** Wi-Fi (2.4GHz)
- **Power Source:** Battery Powered
- **Special Features:** Motion Sensor, Night Vision
- **Indoor/Outdoor Usage:** Outdoor
- **Compatible Devices:** Smartphone (Android)
- **Form Factor:** Bullet
- **Mounting Type:** Wall Mount
- **Video Capture Format:** MPEG-4
- **Package Dimensions:** 4.33 x 3.94 x 1.57 inches

10. WARRANTY AND SUPPORT

Oumefar products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the product packaging or visit the official Oumefar website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C2CN6RRL>

More documents and user manuals: <https://manuals.plus/>