

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Northpoint](#) /

> [Northpoint LED Outdoor Table Lamp 2200 mAh - Solar Panel, Dimmable \(Model 4251730406501\)](#)

Northpoint 4251730406501

Northpoint LED Outdoor Table Lamp - Model 4251730406501

Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient operation, setup, and maintenance of your Northpoint LED Outdoor Table Lamp. Please read these instructions carefully before using the product and retain them for future reference.






Image 1: Front view of the Northpoint LED Outdoor Table Lamp. The lamp features a beige, perforated metal shade and a slender stand on a round base.

SAFETY INSTRUCTIONS

- **Read all instructions:** Before operating the lamp, ensure you have read and understood all safety and operating instructions.
- **Water Resistance:** The lamp has an IP44 rating, making it splash-proof. Do not immerse the lamp in water or expose it to heavy rain for extended periods.
- **Charging:** Only use the provided USB cable or rely on the integrated solar panel for charging. Do not use unauthorized chargers.
- **Battery Care:** Do not attempt to replace the internal battery. Do not expose the battery to extreme temperatures or direct sunlight for prolonged periods when not in use.
- **Cleaning:** Disconnect the lamp from any charging source before cleaning. Use a soft, dry cloth. Do not use abrasive cleaners or solvents.

- **Disposal:** Dispose of the product and its battery responsibly according to local regulations.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- Northpoint LED Outdoor Table Lamp with integrated solar panel and metal base
- 1-meter USB charging cable
- Instruction Manual (this document)

SETUP

1. Initial Charging

Before first use, it is recommended to fully charge the lamp. You have two options:

1. **Solar Charging:** Place the lamp in direct sunlight. The integrated solar panel on top of the lamp shade will convert sunlight into energy to charge the internal 2200 mAh battery. Ensure the solar panel is clean and unobstructed for optimal charging efficiency.
2. **USB Charging:** Connect the provided USB charging cable to the lamp's charging port (typically located near the base or under the shade) and to a standard USB power adapter (not included) or a computer USB port. The charging indicator (if present) will show the charging status.



Image 2: Top view of the lamp, highlighting the integrated solar panel on the upper surface of the shade for convenient outdoor charging.

2. Placement

The Northpoint LED Outdoor Table Lamp is suitable for both indoor and outdoor use. For outdoor use, place it on a stable, flat surface. For optimal solar charging, position the lamp where the solar panel receives maximum direct sunlight throughout the day.

OPERATING INSTRUCTIONS

Power On/Off and Dimming

The lamp features a classic pull-chain switch for operation.

1. **To Turn On:** Gently pull the chain switch once. The lamp will illuminate at its lowest brightness setting.
2. **To Adjust Brightness (Dimming):** Pull the chain switch again to cycle through the 3 available brightness levels.
3. **To Turn Off:** After cycling through all brightness levels, pull the chain switch one more time to turn the lamp off.

The lamp's battery provides up to 14 hours of illumination on a varied intensity setting when fully charged.



Image 3: The Northpoint LED Outdoor Table Lamp providing ambient light on an outdoor wooden table, demonstrating its use in an evening setting.

MAINTENANCE

Cleaning

To maintain the appearance and functionality of your lamp:

- Wipe the lamp's exterior with a soft, slightly damp cloth.
- Ensure the solar panel is kept clean from dust, dirt, and debris to maximize charging efficiency.
- Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the finish or electronic components.

Storage

If storing the lamp for an extended period, ensure the battery is fully charged. Store in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Charge the lamp using the USB cable or place it in direct sunlight for several hours.
Solar charging is ineffective.	Solar panel is dirty or not receiving direct sunlight.	Clean the solar panel. Relocate the lamp to an area with maximum direct sunlight exposure.
Lamp flickers or has low brightness.	Low battery charge.	Recharge the lamp fully.
Pull chain switch is unresponsive.	Mechanical issue or internal fault.	Ensure the chain is pulled gently and directly. If the issue persists, contact customer support.

SPECIFICATIONS

Brand	Northpoint
Model Number	4251730406501
Dimensions (L x W x H)	14.2 x 14.2 x 39.5 cm (approx. Ø 14.2 x 39.5 cm)
Weight	800 grams
Material	Metal
Color	Ivory/Beige
Battery Capacity	2200 mAh
Charging Methods	Integrated Solar Panel, USB Cable
Battery Life	Up to 14 hours (varied intensity mode)
Light Source	LED
Luminous Flux	120 lm
Dimmable	Yes (3 levels)

Protection Rating	IP44 (Splash-proof)
Average Lifespan	30000 Hours






Image 4: Diagram showing the approximate dimensions of the Northpoint LED Outdoor Table Lamp: height approximately 40 cm, base diameter approximately 14 cm.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the seller's information or contact Northpoint customer service. Keep your purchase receipt as proof of purchase.

Manufacturer: Northpoint GmbH
