

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Focal](#) /
- › [Focal Theva N°2 Floorstanding Loudspeaker Instruction Manual](#)

Focal FTHEVAN2DW

Focal Theva N°2 Floorstanding Loudspeaker Instruction Manual

Model: FTHEVAN2DW

1. INTRODUCTION AND OVERVIEW

The Focal Theva N°2 is a three-way floorstanding loudspeaker designed to deliver a rich and balanced audio experience. Featuring 5-inch (13cm) midrange and bass speaker drivers, along with an Aluminium/Magnesium TNF tweeter, this loudspeaker provides clear treble and impactful bass. Its sleek design and tilted stand contribute to both aesthetic appeal and optimized sound projection.



Figure 1: Focal Theva N°2 Floorstanding Loudspeaker in Dark Wood finish, shown with its protective grille.

2. SETUP

2.1 Unpacking

Carefully remove the loudspeaker from its packaging. Retain all packaging materials for future transport or storage. Inspect the speaker for any signs of damage. If damage is found, contact your dealer immediately.

2.2 Placement

Optimal placement is crucial for sound quality. Position the loudspeakers equidistant from your primary listening position. For stereo imaging, ensure the speakers are placed symmetrically within the room. The Theva N°2 features a tilted stand designed for Time Alignment, which focuses the sound towards the listener. Experiment with toe-in (angling the speakers slightly inward) to achieve the best soundstage and imaging in your listening environment.



Figure 2: Side view of the Theva N°2, illustrating the tilted stand for Time Alignment, which optimizes sound projection towards the listener.

2.3 Connections

Connect the loudspeakers to your amplifier using high-quality speaker cables. Ensure correct polarity: connect the positive (+) terminal on the speaker to the positive (+) terminal on the amplifier, and the negative (-) terminal on the speaker to the negative (-) terminal on the amplifier. Incorrect polarity will result in poor sound quality and reduced bass response.






Figure 3: Rear view of the Focal Theva N°2, highlighting the speaker terminals for amplifier connection and the bass reflex port.

3. OPERATING INSTRUCTIONS

Once properly connected, the Focal Theva N°2 loudspeakers are ready for use. Ensure your amplifier is powered off before making any connections. After all connections are secure, power on your amplifier and select the appropriate input source. Adjust the volume on your amplifier to a comfortable listening level. The Slatefiber cone technology provides dynamic and balanced sound, while the TNF tweeter ensures soft and precise treble reproduction.






Figure 4: Front view of the Focal Theva N°2 without its grille, revealing the TNF tweeter and Slatefiber midrange and bass drivers.

3.1 Grille Usage

The Theva N°2 comes with a magnetic protective grille. You may choose to use the loudspeakers with or without the grille. Removing the grille can sometimes offer a slightly more open sound, while keeping it on provides protection for the drivers.



Figure 5: Detail of the magnetic grille attachment mechanism, ensuring easy removal and secure placement.

4. MAINTENANCE

To maintain the appearance and performance of your Focal Theva N°2 loudspeakers, follow these guidelines:

- **Cleaning the Cabinet:** Use a soft, dry cloth to gently wipe the cabinet surfaces. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Cleaning the Drivers:** The speaker drivers (cones and tweeter) are delicate. Do not touch them directly. If dust accumulates, use a soft brush or compressed air from a distance to gently remove it.
- **Grille Care:** The magnetic grille can be cleaned with a soft brush or a lint roller to remove dust and debris.
- **Avoid Direct Sunlight and Heat:** Prolonged exposure to direct sunlight or excessive heat can cause discoloration or damage to the cabinet finish and internal components.

5. TROUBLESHOOTING

If you encounter issues with your Focal Theva N°2 loudspeakers, refer to the following common problems and solutions:

- **No Sound:**
 - Check all cable connections between the speakers and the amplifier. Ensure they are secure and correctly connected (positive to positive, negative to negative).
 - Verify that the amplifier is powered on and the correct input source is selected.
 - Test with another audio source or amplifier if possible to isolate the problem.

- **Distorted Sound:**

- Reduce the volume level on your amplifier. Distortion often occurs when the amplifier is overdriven.
- Check speaker cable connections for any loose strands or short circuits.
- Ensure the speakers are not placed too close to walls or corners, which can cause excessive bass and distortion.

- **Unbalanced Sound (one speaker louder/softer than the other):**

- Check the balance control on your amplifier or audio source.
- Verify that both speaker cables are securely connected and of similar length and gauge.
- Ensure both speakers are positioned symmetrically in the room.

- **Lack of Bass:**

- Confirm correct speaker polarity (+ to + and - to -). Incorrect polarity can cause bass cancellation.
- Check speaker placement; moving speakers closer to walls can increase bass response.
- Ensure your amplifier's bass settings or tone controls are appropriately adjusted.

If these steps do not resolve the issue, please contact your authorized Focal dealer or Focal customer support for further assistance.

6. SPECIFICATIONS

The following table details the key specifications for the Focal Theva N°2 Floorstanding Loudspeaker:

Feature	Detail
Product Dimensions	13.85 x 7.51 x 36.65 inches
Item Weight	48 pounds
Manufacturer	Focal
Model Number	FTHEVAN2DW
Included Components	1 x floorstanding speaker
Drivers	5-inch (13cm) midrange and bass drivers, Aluminium/Magnesium TNF tweeter
Design	3-Way Bass-Reflex Floorstanding Loudspeaker

7. WARRANTY INFORMATION

The Focal Theva N°2 Floorstanding Loudspeaker is covered by a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full details regarding warranty terms, conditions, and claim procedures, please refer to the official Focal website or contact your authorized dealer.

8. SUPPORT

For technical assistance, product inquiries, or service requests, please contact your authorized Focal dealer where you purchased the product. You may also visit the official Focal website for additional resources, FAQs, and contact information for customer support.

Focal Official Website: www.focal.com