Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > WE-VIBE /
- > WE-VIBE Sync Lite Couples Vibrator Instruction Manual

WE-VIBE Sync Lite

WE-VIBE Sync Lite Couples Vibrator Instruction Manual

Model: Sync Lite

1. PRODUCT OVERVIEW

The WE-VIBE Sync Lite is a wearable couples vibrator designed to provide shared vibrations. Its ergonomic C-shape and slim insertable arm ensure comfort and dual stimulation. The device features app control, multiple intensity levels, and is made from body-safe silicone.




Image: WE-VIBE Sync Lite with its companion app.

Key Features:

- C-Shape Design: Engineered for comfortable, hands-free wear during intimate moments.
- **Dual Stimulation:** Provides vibrations for both partners simultaneously.
- App Control: Connects to the free We-Vibe app for remote control and customizable patterns.
- 10 Intensity Levels: Offers a range of vibration strengths for personalized experiences.
- Body-Safe Silicone: Constructed from phthalate-free, BPA-free, and latex-free silicone for safety and comfort.
- Splashproof (IPX4): Designed to withstand splashes, making it easy to clean.

• Rechargeable: Equipped with a USB rechargeable battery.

2. PACKAGE CONTENTS

Verify that all items are present in your WE-VIBE Sync Lite package:

- WE-VIBE Sync Lite device
- USB Charging Cable
- Storage Pouch
- · Quick Start Guide
- Compliance & Safety Information









Image: WE-VIBE Sync Lite package contents.

3. SAFETY INFORMATION

Please read all safety instructions before using your WE-VIBE Sync Lite. Keep this manual for future reference.

- Material Safety: The Sync Lite is made from body-safe silicone. If you experience any irritation, discontinue use immediately.
- Cleaning: Always clean the device before and after each use as described in the Maintenance section.
- Lubrication: Use only water-based lubricants with your Sync Lite. Oil-based lubricants can damage the silicone material.
- Charging: Use only the provided USB charging cable. Do not use the device while it is charging.
- Storage: Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Medical Conditions:** Consult a healthcare professional if you have any medical conditions or concerns before using this product.

4. SETUP

4.1 Initial Charge

Before first use, fully charge your Sync Lite. Connect the USB charging cable to the device's charging port and plug the other end into a USB power source (e.g., computer, wall adapter). The indicator light will show charging status and turn solid when fully charged.

4.2 App Download and Connection

The WE-VIBE Sync Lite can be controlled via the We-Vibe app, available for free on iOS and Android devices.

- 1. Download the 'We-Vibe' app from your device's app store.
- 2. Ensure your Sync Lite is charged and turned on (press and hold the power button).
- 3. Open the We-Vibe app and follow the on-screen instructions to pair your device via Bluetooth.



App & Single-button Controls



Use the simple button on the toy or play together with the We-Vibe app to explore more options.

Image: App and single-button controls for Sync Lite.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

The Sync Lite features a single control button for basic operation:

- Power On/Off: Press and hold the button for 2 seconds.
- Change Vibration Mode/Intensity: Press the button briefly to cycle through the available modes and intensity levels.

5.2 Wearing and Usage

The Sync Lite is designed to be worn comfortably during use.

How to Play



Apply a little lube to the internal arm of the toy and



With the toy inserted, turn the toy on by pressing the control button on its base.



Enjoy shared vibrations by wearing the toy during penetration

Image: How to use the Sync Lite.

- 1. Apply a water-based lubricant to the internal arm of the device.
- 2. Gently insert the slim arm into position.
- 3. Turn on the device using the control button or the We-Vibe app.
- 4. Adjust intensity and patterns as desired for shared vibrations.



10 Intensity Levels



Sync Lite provides 10 different intensity levels, so you can control the power of your vibrations.

Image: Couple using the Sync Lite.

5.3 App Control


The We-Vibe app offers enhanced control and customization:

- Remote Control: Control the Sync Lite from a distance.
- Custom Patterns: Create and save personalized vibration patterns.
- Pre-set Modes: Explore various pre-programmed vibration modes.
- Long-Distance Play: Connect with a partner remotely through the app.

6. MAINTENANCE AND CARE

6.1 Cleaning

The Sync Lite is splashproof (IPX4) for easy cleaning.



Splashproof




Sync Lite is splashproof (IPX4), making it safe from spills and simple to clean.

Image: Sync Lite on a sink, demonstrating splashproof feature.

- 1. Wash the device thoroughly with warm water and mild soap.
- 2. Rinse completely to remove all soap residue.
- 3. Dry with a lint-free cloth or air dry.
- 4. Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.

6.2 Storage

Store your Sync Lite in its provided storage pouch in a clean, dry place, away from direct sunlight and extreme temperatures. Avoid storing it with other toys made of different materials to prevent material degradation.



Silky-smooth Silicone



Sync Lite is fully coated in ultra-hygienic, skin-friendly silicone.

Image: Sync Lite made from silky-smooth silicone.

7. TROUBLESHOOTING

If you encounter issues with your WE-VIBE Sync Lite, refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on	Low battery; Device not charged	Charge the device fully using the provided USB cable.
Cannot connect to app	Bluetooth off; Device not in pairing mode; App issue	Ensure Bluetooth is enabled on your phone. Turn the Sync Lite off and on again. Restart the We-Vibe app. Ensure the device is fully charged.

Problem	Possible Cause	Solution
Vibrations are weak or inconsistent	Low battery; Device malfunction	Charge the device fully. If the problem persists, contact customer support.
Device not responding to button presses	Device frozen; Low battery	Charge the device. Try resetting by holding the button for an extended period (e.g., 10-15 seconds) or allowing the battery to fully drain and then recharging.

8. SPECIFICATIONS

Feature	Detail
Model Name	Sync Lite
Product Dimensions	3.54 x 3.54 x 1.85 inches
Weight	2.47 ounces
Material	Silicone
Color	Aqua
Battery	1 Lithium Ion battery (included)
Water Resistance	Splashproof (IPX4)
Manufacturer	WOW Tech
Date First Available	May 4, 2023

9. WARRANTY INFORMATION

The WE-VIBE Sync Lite is covered by a manufacturer's warranty. Please refer to the warranty card included in your package or visit the official WE-VIBE website for detailed information regarding warranty terms and conditions.

10. SUPPORT

For further assistance, product inquiries, or technical support, please visit the official WE-VIBE website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's website.

WE-VIBE Official Website: www.we-vibe.com

Related Documents - Sync Lite

We-Vibe Sync™: User Guide and Product Information

Comprehensive guide for the We-Vibe Sync[™] couples vibrator, including setup, app connectivity, safety warnings, warranty, and compliance information. Features external and G-spot stimulation.



We-Vibe Sync™ User Manual: Features, Operation, and Care

Comprehensive user manual for the We-Vibe Sync™ personal massager, covering features, charging, operation, safety, app connectivity, and troubleshooting. Learn how to use your Sync for optimal pleasure.



We-Vibe Sync User Manual

Comprehensive guide to the We-Vibe Sync, covering features, usage, charging, pairing, and safety instructions. Learn how to maximize your experience with this advanced personal massager.



We-Vibe Sync™ User Manual: Features, Usage, and Care

Comprehensive guide to the We-Vibe Sync™ personal massager, covering features, operation, cleaning, pairing, safety, and warranty information.



Thrill by We-Vibe User Manual: Dual Stimulation and Features

Comprehensive user manual for the Thrill by We-Vibe, detailing its dual stimulation design, charging, operation, cleaning, troubleshooting, and warranty information.



We-Vibe Sync User Manual: Features, Operation, and Care

Comprehensive user manual for the We-Vibe Sync personal massager, covering features, charging, operation, pairing with remote and app, adjustments, safety, and warranty information.