

[Manuals.plus](#) /

> [Joywhale](#) /

> Joywhale 12V Kids Ride-On Chevrolet 3100 Pickup Instruction Manual

## Joywhale DP-CH01L

# Joywhale 12V Kids Ride-On Chevrolet 3100 Pickup Instruction Manual

Model: DP-CH01L

## 1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Joywhale 12V Kids Ride-On Chevrolet 3100 Pickup. Please read this manual thoroughly before initial use and retain it for future reference. This product is designed for children aged 3-6 years, with a maximum weight capacity of 55 lbs (25 kg).



Image: Front view of the Joywhale 12V Kids Ride-On Chevrolet 3100 Pickup in black, showcasing its classic design and chrome accents.

## 2. SAFETY INFORMATION

**WARNING: Adult assembly required. Adult supervision is required at all times during operation.**

- Always ensure the child is securely fastened with the safety belt before operation.
- Do not operate the vehicle near streets, cars, steep inclines, swimming pools, or other bodies of water.
- Only operate on flat, dry surfaces. Avoid sand, loose dirt, gravel, or wet areas.
- Ensure the charging port is covered when not charging to prevent water ingress.
- This product is intended for one rider only. Do not exceed the maximum weight capacity of 55 lbs (25 kg).
- Keep hands, hair, and clothing away from moving parts.
- The remote control features an emergency brake button for immediate stopping by a supervising adult.
- Regularly inspect the vehicle for damage, loose parts, or wear before each use.

## 3. PRODUCT FEATURES

- **Powerful Motor & Battery:** Equipped with a 12V motor and 7AH battery, providing speeds of 1.2-2.5 mph.
- **Dual Driving Modes:**
  - **Manual Operation:** Child controls steering wheel and foot pedal.
  - **Parental Remote Control:** 2.4G remote with 3 changeable speeds and an emergency brake function.
- **Enhanced Safety:** Constructed from durable, non-toxic plastic, featuring a spacious seat with a safety belt, 4-wheel spring suspension, and resistant wheels for a stable ride.
- **Entertainment System:** Built-in media player with music, FM radio, and wireless technology (Bluetooth) for connecting external devices.
- **Realistic Design:** Licensed Chevrolet 3100 Pickup replica with retro styling, round headlights, lockable doors, and integrated storage space.



Image: A child operating the ride-on car, highlighting the powerful 12V motor and 7AH battery for stable driving.



Image: Illustration of the dual driving modes, showing both child manual operation and parental remote control.




Image: Detailed views of the car's features including lockable doors, interior storage, and functional headlights.



Image: A child enjoying the ride-on car, with an inset showing the built-in media player for music and FM radio.

## 4. SETUP AND ASSEMBLY

This section outlines the general steps for assembling your ride-on car. Refer to the detailed assembly instructions provided in the packaging for specific diagrams and part identification.

1. **Unpacking:** Carefully remove all components from the packaging. Verify all parts are present against the parts list in your specific manual.
2. **Wheel Installation:** Attach the wheels to the axles as per the instructions, ensuring all washers and locking pins are securely in place.
3. **Steering Wheel Assembly:** Connect the steering column to the vehicle body and attach the steering wheel, ensuring electrical connections (if any) are made.
4. **Seat Installation:** Secure the seat to the vehicle body.
5. **Battery Connection:** Connect the battery terminals. Ensure correct polarity. The battery may require an initial charge before first use.

6. **Accessory Attachment:** Install any remaining accessories such as mirrors or windshields.

**Note: Initial battery charge is recommended for 8-12 hours before first use to ensure optimal battery life.**

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Manual Operation (Child Control)

- **Power On:** Turn the main power switch to the "ON" position.
- **Start:** Press the start button or engage the foot pedal.
- **Acceleration:** Press the foot pedal to move forward. Release to brake.
- **Steering:** Use the steering wheel to control direction.
- **Forward/Reverse:** Use the gear selector switch (if present) to choose between forward and reverse.

### 5.2. Parental Remote Control Operation

The 2.4G remote control allows parents to safely guide the vehicle and override child controls when necessary.

- **Pairing:** Follow the specific pairing instructions in your detailed manual to connect the remote control to the vehicle.
- **Directional Control:** Use the joystick or directional buttons to move the car forward, backward, left, and right.
- **Speed Selection:** The remote offers 3 changeable speeds. Select an appropriate speed based on the child's age and environment.
- **Emergency Brake:** Press the dedicated emergency brake button on the remote to immediately stop the vehicle. Release the button to resume operation.

### 5.3. Media Player Usage

- **Music Playback:** Use the built-in music buttons to play pre-loaded tunes.
- **FM Radio:** Activate the FM radio function and use the scan/tune buttons to find stations.
- **Wireless Connection (Bluetooth):** Enable Bluetooth on your mobile device and search for the vehicle's Bluetooth name (refer to specific manual for name). Pair the devices to play audio through the car's speakers.
- **Auxiliary Input:** Connect external audio devices using an AUX cable (if port available).

## 6. CHARGING INSTRUCTIONS

---

- Only use the charger provided with your Joywhale ride-on car. Using an unauthorized charger may damage the battery and void the warranty.
- Locate the charging port on the vehicle.
- Plug the charger into a standard wall outlet, then connect the charger plug to the vehicle's charging port.
- The charging indicator light on the charger will typically show red during charging and turn green when fully charged.
- Charge time is approximately 8-12 hours for a full charge. Do not overcharge the battery.
- Disconnect the charger once charging is complete and cover the charging port.

- Do not charge the battery for more than 20 hours.

## 7. MAINTENANCE

- **Cleaning:** Wipe the vehicle with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid spraying water directly onto electrical components.
- **Storage:** Store the vehicle in a dry, cool place away from direct sunlight and moisture. If storing for extended periods, charge the battery fully every 30 days to maintain its life.
- **Battery Care:** Do not allow the battery to completely discharge. Recharge promptly after each use.
- **Inspection:** Regularly check all screws, nuts, and bolts for tightness. Inspect wheels, steering, and electrical connections for wear or damage.
- **Lubrication:** Periodically lubricate moving parts as recommended in the detailed manual.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vehicle does not move	Battery low or disconnected; Power switch off; Loose wiring; Overload protection activated.	Charge battery; Check battery connections; Turn power switch on; Inspect wiring; Reduce load.
Vehicle moves slowly	Low battery; Overloaded; Operating on rough terrain.	Recharge battery; Reduce weight; Operate on flat, smooth surfaces.
Remote control not working	Remote batteries dead; Remote not paired; Interference.	Replace remote batteries; Re-pair remote (refer to manual); Move to an area with less interference.
No sound from media player	Volume too low; Device not connected properly (Bluetooth/AUX); Media player off.	Increase volume; Reconnect device; Ensure media player is on.

## 9. SPECIFICATIONS

Feature	Detail
Model Number	DP-CH01L
Brand	Joywhale
Battery	12V 7AH
Motor	12V (Dual Motors)
Speed Range	1.2 - 2.5 mph (3-Speeds via remote)
Recommended Age	3 - 6 years
Weight Capacity	55 lbs (25 kg)

Feature	Detail
Overall Dimensions	39.4 x 21.7 x 17.7 inches (L x W x H)
Playtime	Approx. 1-2 hours (varies with usage)
Recharge Time	8-12 hours



Image: Visual representation of the ride-on car's dimensions and recommended user specifications.

## 10. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Joywhale website or contact their customer service department. A comprehensive Instructions for Use (IFU) document is available in PDF format for further details.

You can access the PDF manual [here](#).