

DUKWIN YR22C-086-BK

DUKWIN Watch Winder Instruction Manual

Model: YR22C-086-BK

INTRODUCTION

Thank you for choosing the DUKWIN Watch Winder. This manual provides essential information for the proper setup, operation, and maintenance of your watch winder. Please read these instructions carefully before use to ensure optimal performance and longevity of your device.

SAFETY INFORMATION

- Ensure the watch winder is placed on a stable, level surface to prevent tipping.
- Keep the device away from direct sunlight, extreme temperatures, and high humidity.
- Do not expose the winder to water or other liquids.
- Use only the provided power adapter.
- Keep out of reach of children and pets.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support for assistance.

PACKAGE CONTENTS

Please check the package for the following items:

- DUKWIN Watch Winder Unit
- AC Power Adapter
- Security Key
- Cleaning Cloth
- Instruction Manual (this document)

PRODUCT OVERVIEW

The DUKWIN Watch Winder is designed to keep your automatic watches wound and ready for use, while also

providing storage for additional watches and jewelry. It features a high-gloss piano lacquer finish and built-in illumination.



Image: Front view of the DUKWIN Watch Winder, showing 8 winding slots, 6 static watch holders, and a lower jewelry storage drawer.

Key Features:

- **8 Winding Slots:** For automatic watches.
- **6 Static Watch Holders:** For additional watches.
- **Jewelry Storage Drawer:** Located at the bottom for accessories.
- **High-Gloss Piano Lacquer Finish:** Durable and aesthetic exterior.
- **Built-in Illumination:** White LED lighting to showcase your watches.
- **Security Locking Mechanism:** Prevents unauthorized access.
- **Ultra-Quiet Japanese Motor:** Ensures silent operation.

UPGRADE 3 IN 1 WATCH WINDER

Meet Different Usage Scenarios



Automatic Watch Winding



Extra Storage Holder



Jewelry Storage Drawer

Image: Diagram illustrating the three main functions: automatic watch winding, extra static watch storage, and a jewelry storage drawer.




Image: Visual representation of multiple user-friendly functions including 4 rotation modes, built-in LED lighting, key lock, door sensor button, piano lacquer finish, and premium design.

SETUP

1. Placement

Choose a suitable location for your watch winder. Consider the following:

- **Stable Surface:** Ensure the surface is flat and sturdy to support the winder's weight (approximately 29.85 lbs).
- **Environment:** Avoid areas with direct sunlight, high humidity, or extreme temperature fluctuations.
- **Noise Consideration:** The winder operates with a super quiet motor (less than 5dB), making it suitable for bedrooms or offices without disturbing rest.

WATCH WINDER SIZE PARAMETER



Image: Dimensions of the watch winder: 47cm (18.5in) width, 44cm (17.3in) height, 20cm (7.8in) depth, shown next to a 20-inch suitcase for scale.

ULTRA-QUIET WATCH WINDER



Less Than 5 DB-SUPER Quiet Motor
Low noise, does not disturb your sleep



Alarm Clock



Conversation



Night Sound



Watch Winder

Image: Illustration of the watch winder's ultra-quiet operation (less than 5dB), suitable for placement in a bedroom without disturbing sleep.

2. Power Connection

Connect the provided AC power adapter to the power input port on the back of the watch winder, then plug it into a standard electrical outlet.

OPERATING INSTRUCTIONS

1. Inserting Watches

The watch winder features retractable spring watch pillows designed to accommodate a wide range of watch sizes (110-200mm watch band perimeter, watch diameter up to 60mm, and thickness up to 20mm). Gently compress the pillow and place your automatic watch onto it, ensuring a secure fit. Insert the pillow with the watch into one of the winding slots.

ADJUSTABLE WATCH DISPLAY PILLOW

Fit More Than 99% Automatic Mechanical Watches



Φ60mm



Fit For Watch Band With
Perimeter From **110-200mm**

Fit Watch Diameter Less Than
60mm And Thickness Up To **20mm**

Image: Detailed view of the adjustable spring watch pillow, demonstrating how it fits various watch band sizes (110-200mm perimeter) and watch diameters (up to 60mm) with a maximum thickness of 20mm.

2. Selecting Rotation Modes

The DUKWIN Watch Winder offers four distinct rotation modes to suit different automatic watch requirements. Use the control knobs on the front panel to select your desired mode for each set of winding slots.




Image: Detailed explanation of the four rotation modes, including direction, duration, and rest periods.

- **Mode 1:** Rotates clockwise for 2 minutes, then rests for 6 minutes. Repeats cycle.
- **Mode 2:** Rotates counter-clockwise for 2 minutes, then rests for 6 minutes. Repeats cycle.
- **Mode 3:** Rotates clockwise for 2 minutes, rests for 6 minutes, then rotates counter-clockwise for 2 minutes, rests for 6 minutes. Repeats cycle.
- **Mode 4:** Rotates clockwise for 5 minutes, then counter-clockwise for 5 minutes. This sequence repeats for 3 hours, followed by a 9-hour rest period. Repeats cycle.

3. Using Built-in Illumination

The watch winder includes internal LED lighting. A dedicated switch, typically located on the back or inside the unit, controls the illumination. Turn it on to highlight your watch collection or off to conserve energy.

4. Locking Mechanism

For added security, the winder is equipped with a key lock. Use the provided key to lock and unlock the front door, protecting your watches and jewelry from accidental drops or unauthorized access.

MAINTENANCE

- **Cleaning:** Use the provided cleaning cloth to gently wipe the exterior of the winder. For stubborn marks, a slightly damp cloth can be used, followed by a dry cloth. Avoid abrasive cleaners or solvents.
- **Interior:** Periodically dust the interior with a soft, dry cloth.
- **Watch Pillows:** Ensure watch pillows are clean and free of debris.
- **Power Off:** Always unplug the winder before cleaning or performing any maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Winder is not rotating.	Not plugged in; power adapter faulty; mode not selected; door sensor activated.	Check power connection. Ensure the power adapter is functioning. Select a rotation mode. Close the door securely.
LED light flickers or turns off.	Loose connection; electrical relay issue; power fluctuation.	Ensure all connections are secure. Try turning the light switch off and on again. If the problem persists, contact support.
Watch is not winding properly.	Incorrect rotation mode for the watch; watch not seated correctly; watch pillow too loose/tight.	Consult your watch manufacturer's recommendations for TPD (Turns Per Day) and rotation direction. Ensure the watch is securely placed on the pillow. Adjust the pillow if necessary.
Unit makes unusual noise.	Internal component issue; unit not on a level surface.	Ensure the winder is on a stable, level surface. If the noise persists, discontinue use and contact support.

SPECIFICATIONS

Feature	Detail
Model Number	YR22C-086-BK
Dimensions (L x W x H)	47cm x 20cm x 44cm (18.5 x 7.8 x 17.3 inches)
Weight	Approximately 29.85 lbs
Material	High-Gloss Piano Lacquer Finish
Winding Capacity	8 Automatic Watches
Storage Capacity	6 Static Watches + Jewelry Drawer
Motor Type	Japanese Mabuchi Motor
Noise Level	Less than 5dB
Power Source	AC Power Adapter (included)

WARRANTY AND SUPPORT




DUKWIN offers a **12-month warranty** on this watch winder from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

If you encounter any problems or have questions regarding your DUKWIN Watch Winder, please contact our customer support team. Provide your model number (YR22C-086-BK) and a detailed description of the issue for prompt assistance.

Customer Support: Please refer to your purchase documentation or the DUKWIN brand store on Amazon for contact information.

Related Documents - YR22C-086-BK

	<p>DUKWIN YG22B Fingerprint Lock Series Watch Winder Owner's Manual</p> <p>This owner's manual provides comprehensive guidance for the DUKWIN YG22B Fingerprint Lock Series Watch Winder, covering features, operation, controls, winding modes, and safety instructions for optimal use.</p>
	<p>DUKWIN YG22B Fingerprint Lock Series Watch Winder Owner's Manual</p> <p>This owner's manual provides comprehensive guidance for the DUKWIN YG22B Fingerprint Lock Series Watch Winder, covering features, operation, controls, winding modes, and safety instructions for optimal use.</p>

	<p>MST RMX EX S PRO RC Drift Car Upgrade Guide</p> <p>Official upgrade guide for the MST RMX EX S PRO 1/10 scale RC RWD high-performance drift car, detailing recommended parts and comparisons for enhanced performance.</p>
	<p>BOKE PQL Series Constant Current LED Drivers - Technical Specifications and Features</p> <p>Detailed technical specifications, features, and applications for the BOKE PQL Series of constant current LED drivers. Includes electrical values, life-time data, installation guidelines, and packaging information.</p>
	<p>MST RMX 2.5 RTR 1/10 Scale RC Drift Car Exploded Manual and Upgrade Guide</p> <p>Comprehensive exploded view manual and upgrade guide for the MST RMX 2.5 RTR 1/10 scale RC Drift Car. Includes part numbers, specifications, and assembly instructions.</p>
	<p>Panduit MP75 PXE Series Mobile Printer - Product Bulletin</p> <p>Detailed product bulletin for the Panduit MP75 PXE Series Mobile Printer, covering its features, specifications, and ordering information for various label cassette types, including comparisons with other models. Learn about its network and electrical functionality.</p>