Csasan J90 Pro

Csasan J90 Pro Wireless Earbuds User Manual

Model: J90 Pro | Brand: Csasan

Introduction

The Csasan J90 Pro Wireless Earbuds are designed to provide a superior audio experience with advanced features for daily use and active lifestyles. Featuring Bluetooth 5.3 technology, these earbuds offer stable connectivity, immersive HiFi stereo sound, and effective ENC noise cancellation for clear calls. With a long-lasting battery and IP7 waterproof rating, they are built for convenience and durability.



The Csasan J90 Pro Wireless Earbuds in their rose-colored charging case, showcasing the digital battery display.

What's in the Box

Verify that all components are present in the package:

- Bluetooth headphones (2)
- Charging box (1)
- Manual (1)
- USB-C charging cable (1)
- 3 sizes of ear tips (S/M/L)



Included components: earbuds, charging case, USB-C cable, and various ear tip sizes.

Your browser does not support the video tag.

An overview video demonstrating the Csasan Wireless Earbuds and their features.

Setup


Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a power source. The LED digital display on the case will indicate the charging status and battery levels.


One-Step Auto Pairing

1. Ensure your device's Bluetooth is enabled.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device, search for "J90 Pro" in the Bluetooth settings and select it to connect.

4. Once successfully paired, the earbuds will automatically connect to your phone whenever you open the charging case.



Visual guide for one-step auto pairing with various operating systems.



The earbuds automatically connect to your device upon opening the case after initial pairing.

Operating Instructions

Touch Controls

The J90 Pro earbuds feature sensitive touch control panels on both earbuds for easy management of audio and calls:

- **Play/Pause:** Tap twice on either earbud.
- **Answer/End Call:** Tap once on either earbud.
- **Reject Call:** Press and hold for 2 seconds on either earbud.
- **Volume Up:** Tap once on the Right earbud.
- **Volume Down:** Tap once on the Left earbud.
- **Next Track:** Press and hold for 2 seconds on the Right earbud.
- **Previous Track:** Press and hold for 2 seconds on the Left earbud.
- **Activate Voice Assistant:** Tap 3 times on either earbud.

Long Lasting Battery

Earbuds offer 6-8Hrs of battery life, and an additionally provides multiple full charges in its charging compatible case

8 hrs
Single Charge

40 hrs
Charging Case


1.5 hrs
Fast Charging



Overview of touch control functions for music and calls.


Simple and Comfortable Touch Control

The controls are touch-based and reasonably simple to use while you're in motion



L

- Tap Twice
- Tap Once
- Press and Hold 2s
- L/R Tap 3 Times
- Press and Hold 2s
- Tap Once
- Press and Hold 2s




R

- Tap Twice
- Tap Once
- Press and Hold 2s
- L/R Tap Once
- Press and Hold 2s
- Tap Once
- Press and Hold 2s

Comprehensive guide to left and right earbud touch controls.

Sound Quality and Noise Cancellation

The earbuds feature 13mm composite diaphragms for rich, immersive HiFi stereo sound. Equipped with ENC noise reduction dual microphones, they effectively reduce up to 40dB of external ambient noise, ensuring crystal-clear calls even in noisy environments.



Internal components illustrating the 13mm super large dynamic speaker for powerful stereo sound.




Illustration of the ENC noise cancelling microphone, eliminating up to 40dB of external ambient noise.

Battery Life and LED Display

Enjoy up to 6-8 hours of playback on a single charge. The charging case provides an additional 4 charges, extending total playtime to 40 hours. The smart LED digital display on the charging case shows the battery percentage of the case and the individual charge status of each earbud (L/R).



The charging case with its LED display indicating battery levels for the case and individual earbuds.



Infographic detailing the 40-hour long listening time with the charging case.



The Bluetooth 5.3 chip and the LED power display on the charging case.

Maintenance

IP7 Waterproof Rating

The earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. This makes them suitable for workouts and use in light rain. However, they are not designed for swimming or prolonged submersion. Always ensure the charging port is dry before charging.



The IP7 waterproof rating allows for use during workouts and in various weather conditions.



The IP7 waterproof feature ensures durability against sweat and rain.

Cleaning and Storage

Regularly clean the earbuds and charging case with a soft, dry cloth. Remove ear tips and clean them with mild soap and water, ensuring they are completely dry before reattaching. Store the earbuds in their charging case when not in use to protect them and maintain battery life.

Troubleshooting

Problem	Possible Cause	Solution
Earbuds not pairing/connecting.	Bluetooth off, out of range, previously paired to another device.	Ensure Bluetooth is on. Place earbuds closer to device. Forget "J90 Pro" on other devices and re-pair.
No sound or low volume.	Device volume low, earbuds not seated correctly, dirty ear tips.	Increase device volume. Adjust earbuds for a snug fit. Clean ear tips and earbud mesh.
Earbuds not charging.	Charging cable issue, dirty charging contacts, case battery empty.	Try a different USB-C cable. Clean charging contacts on earbuds and case. Charge the case.
Call quality is poor.	Environmental noise, microphone obstruction.	Move to a quieter environment. Ensure microphones are not covered.

Your browser does not support the video tag.

A video demonstrating the features and usage of the 2024 Bluetooth Headphones, which may assist with common operational queries.

Specifications

Feature	Detail
Model Name	J90 Pro
Brand	Csasan
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	15 Meters
Audio Driver Size	13 Millimeters
Battery Life (Earbuds)	6-8 Hours (single charge)
Total Playtime (with case)	40 Hours
Charging Time	1.5 Hours
Water Resistance Level	IP7 Waterproof
Noise Control	ENC Noise Cancellation (Dual Mic)
Control Type	Touch Control
Compatible Devices	Most iOS and Android devices with Bluetooth

Feature	Detail
Item Weight	30 Grams (earbuds) / 1.06 ounces (total)
Product Dimensions	0.79 x 0.79 x 0.79 inches
Material	Plastic

Warranty and Support

Csasan offers a **2-year warranty** for the J90 Pro Wireless Earbuds, ensuring peace of mind regarding product quality and performance.
For any inquiries, technical assistance, or warranty claims, please contact Csasan customer service. We aim to provide a **24-hour customer service response** to address your needs promptly.
You can also refer to the official User Manual (PDF) for more detailed information.Download User Manual (PDF)



Csasan's commitment to product warranty and customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question