Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Csasan J90 Pro

Csasan Wireless Earbuds User Manual

Model: J90 Pro

Introduction

Thank you for choosing Csasan Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your J90 Pro earbuds to ensure optimal performance and longevity. Please read this manual carefully before use.



Image: The Csasan J90 Pro Wireless Earbuds, white in color, are shown resting inside their matching white charging case. The case features a prominent LED digital display on the front, indicating the battery percentage of the case and individual earbud charge levels (L and R). The earbuds themselves have a sleek, in-ear design with a stem, and a subtle blue light emanates from one of the earbuds, suggesting an active state or touch control area.

Package Contents

- 2 x Csasan J90 Pro Wireless Earbuds
- 1 x Charging Case
- 1 x USB-C Charging Cable
- 3 x Pairs of Ear Tips (S/M/L)

- 1 x User Manual

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and a power source. The LED display on the case will show the charging status.



Image: A visual representation of the Csasan J90 Pro earbuds and their charging case, highlighting battery life. The image shows "8 hrs Single Charge" for the earbuds, "40 hrs Charging Case" for the total playtime with the case, and "1.5 hrs Fast Charging" indicating the charging time. The white charging case with its LED display is prominently featured.

- Earbuds offer 6-8 hours of playtime on a single charge.
- The charging case provides an additional 4 charges, extending total playtime to approximately 40 hours.
- Full charge time for the case is approximately 1.5 hours.

2. Pairing with Your Device (One-Step Auto Pairing)

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device, search for "J90 Pro" in the Bluetooth settings and select it to connect.
4. Once connected, the earbuds will automatically reconnect to your device when you open the charging case for subsequent uses.




Image: This image illustrates the "One Step Pairing, Quick Links" feature of the Csasan J90 Pro earbuds. It shows the white charging case with earbuds inside, emitting a wireless signal. Next to it, a smartphone screen displays Bluetooth settings, with "J90 Pro" listed under "Paired devices," indicating a successful connection. Icons for iOS, Android, and Windows are also present, signifying broad compatibility.

The J90 Pro earbuds utilize advanced Bluetooth 5.3 technology for faster transmission speeds, lower power consumption, and a more stable connection with minimal delay.



Image: A close-up of a Csasan J90 Pro earbud and its charging case, emphasizing Bluetooth 5.3 technology and the LED power display. The earbud shows an internal chip labeled "Bluetooth 5.3," with arrows indicating "Longer transmission range," "Less power consumption," "More stable connection," and "Lower latency." The charging case's LED display is also visible, showing battery levels.

Operating Instructions

Smart Touch Controls

The J90 Pro earbuds feature sensitive touch control panels on both earbuds for easy management of music, calls, and voice assistant.



Image: A diagram illustrating the smart touch controls of the Csasan J90 Pro earbud. It shows the earbud with a highlighted touch area and icons representing various functions: Play/Pause, Answer calls, Hang up calls, Digital Assistant, Volume +, Volume -, Track Forward, and Track Reverse.

Function	Action
Play/Pause	Single tap on either earbud
Answer Call	Single tap on either earbud
Hang Up Call	Single tap on either earbud during a call
Reject Call	Press and hold either earbud for 2 seconds
Next Track	Double tap right earbud
Previous Track	Double tap left earbud
Volume Up	Triple tap right earbud

Function	Action
Volume Down	Triple tap left earbud
Activate Voice Assistant	Press and hold either earbud for 3 seconds

Sound Quality and Noise Cancellation

The J90 Pro earbuds are engineered with 13mm super large dynamic speakers and AAC codec to deliver immersive HD stereo sound with deep bass, natural mids, and crisp highs.



Image: An exploded view diagram illustrating the internal components responsible for the "Powerful Stereo Sound" of the Csasan J90 Pro earbud. It highlights the 13mm super large dynamic speaker, showing its diaphragm and other elements that contribute to immersive sound quality. Icons for Bluetooth 5.3, 13mm Drivers, and Bass Sound are also displayed.

Equipped with dual ENC (Environmental Noise Cancellation) microphones, these earbuds passively cancel up to 80% of background noise, ensuring crystal-clear calls even in noisy environments.



Image: A visual demonstrating the ENC Noise Cancelling Mic feature of the Csasan J90 Pro earbud. The earbud is shown in a user's ear, with an overlay indicating the location of the ENC Noise Cancelling Mic and the Main Mic for Talk. Text states that it "Eliminate Maximum 40dB of External Ambient Noise Accurately," emphasizing its ability to provide clear calls by reducing disruptive background noise.

Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Ear Tips:** Remove and clean the ear tips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water Resistance:** The earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. While suitable for sweat and rain, avoid prolonged submersion or use in hot water. Ensure the charging port is dry before charging.

Troubleshooting

Problem	Possible Solution
Earbuds not pairing	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "J90 Pro" in your device's Bluetooth settings and try pairing again. ◦ Place earbuds back in the case, close, wait 5 seconds, then open again.
Only one earbud working	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the charging case, close the lid, and then open it again to reset the connection. ◦ Try re-pairing the earbuds with your device.
Low volume or poor sound quality	◦ Adjust volume on both your device and the earbuds. ◦ Ensure ear tips are properly seated in your ears for a good seal. ◦ Clean any debris from the earbud speakers. ◦ Try different sized ear tips for a better fit.
Charging case not charging	◦ Check the USB-C cable and power adapter. ◦ Ensure the charging port on the case is clean and free of debris.

Specifications

Feature	Detail
Model Number	J90 Pro
Bluetooth Version	5.3
Driver Size	13mm Dynamic
Noise Cancellation	ENC (Environmental Noise Cancellation)
Playtime (Earbuds)	6-8 hours (single charge)
Total Playtime (with Case)	Up to 40 hours
Charging Time	Approx. 1.5 hours (case)
Water Resistance	IP7 (Waterproof)
Control Type	Touch Control
Compatibility	iOS, Android, and all Bluetooth-enabled devices
Weight	Approx. 30 Grams



Image: A detailed diagram showing the compact and lightweight design of the Csasan J90 Pro earbuds and their charging case, complete with precise dimensions in millimeters. The earbuds are shown next to a US quarter coin for scale, emphasizing their small size. Dimensions for the case (62mm x 48mm x 25mm) and earbuds (35mm x 23mm x 20mm) are clearly labeled.

Warranty and Support

Csasan products come with a**2-year warranty**. For any product-related inquiries, technical support, or warranty claims, please contact Csasan customer service. We aim to provide a 24-hour customer service response.
For further assistance, please refer to the contact information provided on the product packaging or the official Csasan website.

© 2023 Csasan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C2HN1NDB

More documents and user manuals: **https://manuals.plus/**