

[Manuals.plus](#) /

› [JVC](#) /

› JVC Gumy True Wireless Earbuds User Manual

JVC HAA7T2W

JVC Gumy True Wireless Earbuds User Manual

Model: HAA7T2W

Brand: JVC

INTRODUCTION


This manual provides essential information for the safe and effective use of your JVC Gumy True Wireless Earbuds (Model: HAA7T2W). Please read this manual thoroughly before using the product and retain it for future reference.



Image: JVC Gummy True Wireless Earbuds in their charging case.

PACKAGE CONTENTS

- Headphones (Earbuds)
- Wireless Charging Case
- Charging Cable
- Multiple Earpiece Sizes (XS/S/M/L)



Convenient Single-Ear Use

Single-ear use on either side allows you to stay connected to your surroundings when necessary

Image: Contents of the JVC Gumy Earbuds package, including earbuds, charging case, USB cable, and various eartip sizes.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case provides extended battery life for your earbuds.

1. Connect the provided charging cable to the charging case and a USB power source.
2. The LED indicators on the case will show charging status.
3. Place the earbuds into the charging case. Ensure they are properly seated to begin charging.

Charging Time: Approximately 2 hours for earbuds, 3 hours for the charging case.

Battery Life: Up to 24 hours total playback time (earbuds + charging case).

2. Pairing with a Bluetooth Device

The JVC Gumy Earbuds utilize Bluetooth 5.3 for a stable and efficient connection.

1. Open the charging case. The earbuds will automatically enter pairing mode (or manually put them into pairing mode if needed, refer to device specific instructions).
2. On your device (smartphone, tablet, PC), go to Bluetooth settings and enable Bluetooth.
3. Select "JVC Gumy HAA7T2W" from the list of available devices.
4. Once connected, a confirmation sound or indicator will be heard/seen.

Bluetooth Range: Up to 10 meters (33 feet) in an open environment.

OPERATING INSTRUCTIONS

Touch Controls

The earbuds feature intuitive touch controls for managing audio playback and calls.

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Triple Tap (Left/Right Earbud)	Activate Voice Assistant (Siri, Google Assistant, etc.)
Long Press (Left/Right Earbud)	Reject Call

Single Earbud Use

You can use either the left or right earbud independently. This is useful for staying aware of your surroundings or extending battery life by alternating earbuds.

- Simply remove one earbud from the case and leave the other in. The active earbud will automatically connect.
- To switch, place the active earbud back in the case and remove the other.



Image: A person using one earbud, highlighting the single-ear use feature.

Sound Modes

The earbuds offer three customizable sound modes to enhance your listening experience:

- **Normal:** Balanced audio for everyday listening.
- **Bass:** Enhanced bass for a richer, more powerful sound.
- **Clear:** Optimized for vocal clarity, ideal for podcasts and audiobooks.

Refer to the quick start guide or the JVC Headphones app (if available) for instructions on how to switch between sound modes.




Image: Visual representation of the three distinct sound modes available.

MAINTENANCE

Water Resistance (IPX4)

The JVC Gumy Earbuds are rated IPX4 water-resistant, meaning they are protected against splashing water from any direction. This makes them suitable for workouts and light rain.

- Do not submerge the earbuds in water.
- Do not expose them to pressurized water streams.
- Ensure earbuds are dry before placing them back into the charging case to prevent damage.



Image: Earbuds being used during an outdoor activity, highlighting their IPX4 water resistance.

Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Use a dry cotton swab to carefully clean the charging contacts on both the earbuds and the case.

TROUBLESHOOTING

If you encounter issues with your JVC Gumy Earbuds, try the following solutions:

No Sound or Pairing Issues

- Ensure both earbuds are charged.
- Make sure Bluetooth is enabled on your device and the earbuds are within range (10 meters).
- Forget the device ("JVC Gumy HAA7T2W") from your device's Bluetooth settings and attempt to re-pair.
- Restart your Bluetooth device.
- If only one earbud is playing sound, try placing both earbuds back in the case, closing it, waiting a few seconds, and then taking them out again.

Charging Problems

- Verify the charging cable is securely connected to both the case and the power source.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- Try a different USB charging cable or power adapter.
- Confirm the earbuds are correctly seated in the charging case.

Poor Sound Quality

- Ensure the eartips are the correct size for a secure and comfortable fit, providing good sound isolation.
- Clean the earbud nozzles and eartips to remove any earwax or debris.
- Move closer to your Bluetooth device to avoid interference.
- Try switching between the available sound modes.

SPECIFICATIONS

Feature	Detail
Model Name	GUMY True Wireless (HAA7T2W)
Connectivity Technology	Bluetooth
Bluetooth Version	5.3
Bluetooth Range	10 Meters
Water Resistance Level	IPX4 (Water Resistant)
Battery Life (Earbuds)	Up to 22 Hours (Total with case)
Charging Time (Earbuds)	2 Hours
Charging Time (Case)	3 Hours
Frequency Response	20 - 20000 Hz
Impedance	16 Ohm
Control Type	Voice Control, Touch Control
Earpiece Shape	In Ear
Material	Plastic, Thermoplastic Elastomer (TPE)
Item Weight	3.52 Ounces
UPC	046838501968

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official JVC website or contact JVC customer service directly.

- **Online Support:** Visit the official JVC website for FAQs, driver downloads, and support resources.
- **Customer Service:** Contact details for JVC customer service can typically be found on their website or in the product packaging.

Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I reset the JVC Gumy True Wireless Earbuds (Model: HAA7T2W)?

The provided manual for the JVC Gumy True Wireless Earbuds (Model: HAA7T2W) does not contain specific instructions for performing a factory reset. However, a common troubleshooting step for Bluetooth devices when experiencing pairing or...

[Read full answer](#)