

Dolphin E10

Dolphin E10 Robotic Pool Cleaner User Manual

Model: E10 | Brand: Dolphin

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Dolphin E10 Automatic Robotic Pool Cleaner. Please read this manual thoroughly before using the product to ensure proper function and longevity.

The Dolphin E10 is designed for above-ground pools up to 30 feet in length, offering ultra-fine filtration and active scrubbing for a pristine clean.

2. SAFETY INFORMATION

Always adhere to the following safety guidelines to prevent injury or damage to the unit.

- Ensure the power supply is disconnected from the electrical outlet before performing any maintenance or cleaning tasks.
- Do not operate the cleaner if the power cable is damaged. Contact authorized service for replacement.
- Keep the power supply unit away from water and direct sunlight.
- Only use the original power supply unit provided with the cleaner.
- Do not allow children to play with the cleaner or its power supply.
- The cleaner is designed for pool use only. Do not use it for other purposes.

3. PRODUCT COMPONENTS

The Dolphin E10 Robotic Pool Cleaner system includes the following main components:

- Dolphin E10 Cleaner Unit
- Power Supply Unit
- Ultra-Fine Filter Basket



Image: The Dolphin E10 robotic pool cleaner unit shown alongside its ultra-fine filter basket, ready for assembly or use.

PRODUCT ANATOMY

Explorer E10




Image: An exploded view diagram illustrating the key components of the Dolphin E10, including the ergonomic handle, easy-access top-load filter, lightweight design, and active brushing mechanism.

4. SETUP INSTRUCTIONS

Follow these steps to prepare your Dolphin E10 for its first use:

1. **Unpack the Cleaner:** Carefully remove the Dolphin E10 and its components from the packaging.
2. **Position the Power Supply:** Place the power supply unit at least 12 feet (3.6 meters) from the edge of the pool. Ensure it is not exposed to direct sunlight or standing water.
3. **Connect the Cleaner to Power Supply:** Insert the floating cable into the power supply unit. Ensure the connector is aligned correctly and securely fastened.
4. **Plug into Outlet:** Connect the power supply unit to a grounded electrical outlet.
5. **Place in Pool:** Gently lower the Dolphin E10 into the pool. Allow it to sink to the bottom. Ensure there are no kinks in the floating cable.



Image: A person's hands are shown connecting the power cable to the Dolphin E10's power supply unit, demonstrating the simple plug-and-play setup.

5. OPERATING INSTRUCTIONS

Operating your Dolphin E10 is straightforward:

1. **Start Cleaning Cycle:** Once the cleaner is in the pool and the power supply is connected, press the ON/OFF button on the power supply unit. The cleaner will begin its cleaning cycle.
2. **Cleaning Duration:** The Dolphin E10 will operate for approximately 1.5 hours per cycle, systematically cleaning the pool floor.
3. **Automatic Shut-off:** The cleaner will automatically shut off at the end of its cleaning cycle.
4. **Remove from Pool:** To remove the cleaner, pull the floating cable gently until the cleaner reaches the surface. Use the handle to lift the cleaner out of the water. Allow excess water to drain before placing it on the pool deck.

Easy-Access **Top Load Filter**



Open the top, pull the filter basket out, and rinse



Image: The Dolphin E10 robotic pool cleaner submerged in a pool, actively scrubbing the floor, highlighting its powerful cleaning action.



Image: A person is shown lifting the Dolphin E10 out of the pool, demonstrating its quick water release feature which makes it lighter and easier to remove.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your Dolphin E10.

6.1 Cleaning the Filter Basket

After each cleaning cycle, the filter basket should be cleaned:

1. **Access Filter:** Open the top cover of the Dolphin E10.
2. **Remove Basket:** Pull out the filter basket using its handle.
3. **Empty Debris:** Open the filter basket and empty any collected debris.
4. **Rinse Filters:** Rinse the filter panels thoroughly with a garden hose until all debris is removed.
5. **Reinsert Basket:** Place the clean filter basket back into the cleaner and close the top cover.



Image: A person is shown easily accessing and removing the top-load filter basket from the Dolphin E10, illustrating the simple cleaning process.

6.2 Cleaning the Scrubbing Brush

Periodically inspect the scrubbing brush for any trapped debris (e.g., hair, leaves). Remove any obstructions to ensure effective scrubbing.

6.3 Storage

When not in use, store the Dolphin E10 in a shaded area on its side to allow water to drain completely. Store the power supply unit in a dry, protected location.

7. TROUBLESHOOTING

If you encounter issues with your Dolphin E10, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cleaner does not turn on.	Power supply not connected or faulty.	Ensure power supply is securely connected to the cleaner and a working electrical outlet. Check for power at the outlet.

Problem	Possible Cause	Solution
Cleaner moves slowly or erratically.	Filter basket is full or clogged.	Clean the filter basket thoroughly.
Poor cleaning performance.	Filter basket is dirty or brush is worn.	Clean the filter basket. Inspect the scrubbing brush for wear and replace if necessary.
Cleaner does not cover entire pool.	Excessive cable length or tangles.	Ensure only the necessary cable length is in the water. Untangle any kinks in the cable.

If the problem persists after attempting these solutions, please contact Dolphin customer support.

8. SPECIFICATIONS







Feature	Specification
Model Name	E10
Product Dimensions	20 x 20 x 20 inches
Item Weight	23 pounds
Power Source	AC
Control Method	Touch
Special Feature	Self Propelled
Material	Plastic
UPC	810071221323
Item Model Number	99996133-USF-Filters

9. WARRANTY AND SUPPORT

The Dolphin E10 Robotic Pool Cleaner comes with a Limited Warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Dolphin website.

For technical support, service, or to purchase replacement parts, please contact Dolphin customer service. You can find contact information on the official Dolphin website or through your product retailer.

Visit the [Dolphin Store](#) for more information and products.

	<p>Dolphin LIBERTY 600 Robotic Pool Cleaner User Manual</p> <p>Comprehensive user manual for the Dolphin LIBERTY 600 robotic pool cleaner, covering setup, operation, maintenance, troubleshooting, and app connectivity. Includes safety instructions, specifications, and cleaning procedures.</p>
	<p>Dolphin W20 Robotic Pool Cleaner User Manual Maytronics</p> <p>User manual for the Maytronics Dolphin W20 robotic pool cleaner. Learn how to set up, operate, clean, maintain, and troubleshoot your Dolphin W20 for efficient pool cleaning.</p>
	<p>Dolphin M400 / M500 Pool Cleaner Operating Instructions</p> <p>Comprehensive operating instructions for the Maytronics Dolphin M400 and M500 robotic pool cleaners, covering setup, usage, maintenance, troubleshooting, and caddy assembly.</p>
	<p>Dolphin S150 Robotic Pool Cleaner User Instructions</p> <p>Comprehensive user instructions for the Dolphin S150 Robotic Pool Cleaner by Maytronics, covering setup, operation, maintenance, and troubleshooting.</p>
	<p>Dolphin LIBERTY Robotic Pool Cleaner User Instructions (Models 100, 200, 300, 400)</p> <p>Comprehensive user instructions for the Dolphin LIBERTY series cordless robotic pool cleaners (Models 100, 200, 300, 400). Covers setup, specifications, features, maintenance, troubleshooting, and app usage.</p>
	<p>Dolphin Robotic Pool Cleaner Quick Start Guide</p> <p>Get started quickly with your Maytronics Dolphin robotic pool cleaner. This guide provides essential setup, operation, and maintenance instructions for optimal pool cleaning performance.</p>

