

[Manuals.plus](#) /

› [Zassenhaus](#) /

› Zassenhaus Oak Salt Mill 24 cm - Model 023800 User Manual

Zassenhaus 023800

Zassenhaus Oak Salt Mill 24 cm - Model 023800

User Manual

INTRODUCTION

Thank you for choosing the Zassenhaus Oak Salt Mill, Model 023800. This high-performance mill is designed for precision seasoning, featuring a durable ceramic grinder that effortlessly handles salt crystals and dried herbs. This manual provides essential information for the proper setup, operation, and maintenance of your new salt mill.

SAFETY INSTRUCTIONS

- Keep the mill out of reach of children.
- This product is intended for grinding salt and dried herbs only. Do not use it for other substances.
- Avoid exposing the mill to excessive moisture or direct sunlight.
- Do not immerse the mill in water. It is not dishwasher safe.
- Handle with care to prevent damage to the ceramic grinding mechanism.

PARTS LIST

Your Zassenhaus Oak Salt Mill consists of the following main components:

- **Mill Body:** The main oak wood housing.
- **Grinding Mechanism:** The high-performance ceramic grinder located at the bottom.
- **Adjustment Knob:** Located at the top, used to set the grind size.
- **Filling Cap/Top:** The removable top part for refilling.



Image: Zassenhaus Oak Salt Mill 24 cm. This image displays the complete salt mill, highlighting its natural oak wood finish and classic design. The top knob for grind adjustment is visible, as is the overall elegant form of the mill.

SETUP

Filling the Mill

1. Unscrew and remove the top adjustment knob.
2. Carefully lift off the top part of the mill.
3. Fill the mill chamber with your desired salt crystals or dried herbs. Do not overfill.
4. Replace the top part, ensuring it sits correctly.
5. Screw the adjustment knob back on, but do not tighten it completely yet.

OPERATING

Adjusting Grind Size

The Zassenhaus mill features a continuous grind adjustment with 6 levels, from very fine (1) to coarse (6). To adjust the grind size:

1. Turn the adjustment knob clockwise for a finer grind.
2. Turn the adjustment knob counter-clockwise for a coarser grind.
3. Test the grind size by turning the mill over a plate until you achieve your desired consistency.

Grinding

Once the mill is filled and the grind size is set:

- Hold the mill firmly with one hand.
- With the other hand, twist the top part of the mill clockwise to activate the grinding mechanism.
- Continue twisting until the desired amount of ground salt or herbs is dispensed.

MAINTENANCE

Cleaning

- To clean the exterior, wipe the oak wood body with a slightly damp cloth. Dry immediately.
- Do not use harsh detergents or abrasive cleaners.
- The mill is **not dishwasher safe**. Immersion in water will damage the wood and mechanism.
- For the ceramic grinder, a small brush can be used to remove any residue.

Storage

Store your salt mill in a dry place, away from direct heat and humidity, to preserve the wood and ceramic mechanism.

TROUBLESHOOTING

- **Mill not grinding or grinding inconsistently:**
 - Check if the mill is sufficiently filled with salt or herbs.
 - Ensure the adjustment knob is tightened enough for the desired grind size. If it's too loose, the mechanism may not engage properly.
 - Inspect the ceramic grinder for any blockages.
- **Difficulty turning the mill:**
 - The grind setting might be too fine for the type of salt or herb used. Try adjusting to a coarser setting.
 - Ensure the mill is not overfilled.

SPECIFICATIONS

Model Number	023800
Material	Oak Wood
Color	Natural
Height	24 cm
Diameter	5.9 cm

Operation Mode	Manual
Grinding Mechanism	High-Performance Ceramic
Dishwasher Safe	No

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the documentation provided at the time of purchase or contact Zassenhaus customer service directly. Keep your proof of purchase for any warranty claims.

© 2023 Zassenhaus. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question