

WESTTREE X26A

WESTTREE X26A Portable Camping Fan User Manual

Model: X26A | Brand: WESTTREE

1. INTRODUCTION

Thank you for choosing the WESTTREE X26A Portable Camping Fan. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your fan. Please read it thoroughly before use and retain it for future reference.

2. PRODUCT OVERVIEW

The WESTTREE X26A is a versatile, battery-powered fan designed for outdoor and indoor use, featuring a large capacity battery, integrated LED lighting, and a power bank function.



Figure 2.1: Front view of the WESTTREE X26A Portable Camping Fan, highlighting its integrated LED lights and USB charging port for external devices.

20000mAh Rechargeable Battery Operated Fan

16-58H Long Lasting, Powerful Wind Coolness



Figure 2.2: The WESTTREE X26A fan providing airflow in an outdoor fishing scenario, demonstrating its portability and battery life.

3 Level Brightness Camping Fan

Come with 2 color temperatures warm and white Light



Figure 2.3: The fan suspended inside a tent, showcasing its 3-level LED lantern function for nighttime illumination.

Portable Camping Fan

Compact size & powerful wind



Figure 2.4: The compact size and powerful airflow of the fan being utilized in a beach setting.

Faster Charge & Emergency Discharge



Timer Setting & Power Indicator Display



Figure 2.5: The fan on a desk, illustrating its fast charging capability and power indicator display, also functioning as an emergency power source.

No Noise & Double Blades

Quiet ($\leq 20\text{dB}$) fans for bedroom, enjoy coolness



Figure 2.6: The fan operating quietly (below 28dB) next to a sleeping individual, highlighting its suitability for bedroom use.

Perfet for Portablle Outdoor Fan

Keep cool anytime and anywhere, such as beach fan, desk fan, tent fan



Figure 2.7: The fan providing cooling in an outdoor gathering, demonstrating its versatility for various portable outdoor activities.

3. KEY FEATURES

- **Double Blade & 270° Adjustment:** Features a double blade design for powerful airflow and a 270° pivoting head for directional cooling. Stepless speed regulation allows for precise control.
- **High Capacity Battery & Power Bank Function:** Equipped with a 20000mAh rechargeable battery, providing up to 58 hours of operation. Includes a Type-C input and USB output port, allowing it to function as a power bank for other devices.
- **Quiet Operation:** Utilizes the latest brushless motor technology and ultra-thin fan blades to deliver strong airflow with a noise level below 28dB, ensuring minimal disturbance.
- **Integrated LED Lantern:** Features a 3-brightness setting LED lantern, providing convenient lighting for camping, tents, or emergency situations.
- **Portable & Durable Design:** Compact, foldable, and lightweight, making it ideal for camping, fishing, power outages, and other outdoor activities.
- **Power Indicator:** Configured with Warnlight and daylight indicators to remind you when to charge the fan.

4. SETUP

1. **Unpacking:** Carefully remove the fan and all accessories from the packaging. Verify that all components listed in the package contents are present.
2. **Initial Charge:** Before first use, fully charge the fan using the included Type-C charging cable. Connect the Type-C end to the fan's input port and the USB-A end to a compatible 5V/3A power adapter (not included). The charging indicators will show progress. A full charge typically takes 6 hours.
3. **Positioning:** Place the fan on a stable, flat surface. The 270° pivoting head allows you to adjust the fan angle to direct airflow as needed. For hanging, utilize the integrated hook.

5. OPERATING INSTRUCTIONS

5.1 Fan Operation

1. **Power On/Off:** Locate the power button/dial on the front of the fan. Turn the dial clockwise to power on the fan and increase the fan speed. Turn counter-clockwise to decrease speed and power off.
2. **Adjusting Fan Speed:** The fan features stepless speed regulation. Rotate the dial to precisely control the airflow from low to high.
3. **Adjusting Fan Angle:** Manually tilt the fan head up or down to achieve the desired airflow direction. The head can pivot up to 270°.

5.2 LED Light Operation

1. **Turning On/Off:** Press the dedicated light button (usually located near the fan control dial) to cycle through light modes.
2. **Brightness Settings:** The LED lantern has 3 brightness settings. Press the light button repeatedly to cycle through Low, Mid, and High brightness, then off.

5.3 Power Bank Function

1. **Charging External Devices:** Connect your device's charging cable to the USB output port on the fan. The fan's internal battery will begin charging your device.
2. **Battery Indicators:** Monitor the battery indicator lights to check the remaining power of the fan.

6. MAINTENANCE

- **Cleaning:** Ensure the fan is turned off and unplugged before cleaning. Use a soft, dry cloth to wipe down the exterior. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Do not immerse the fan in water.
- **Blade Cleaning:** Periodically check the fan blades for dust and debris. Use a soft brush or compressed air to gently clean the blades through the grille. Do not attempt to disassemble the fan for cleaning.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) before storage to prolong its lifespan.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan fully using the provided Type-C cable.
Fan airflow is weak.	Low battery level; Obstruction in fan blades.	Recharge the fan. Check for and remove any obstructions from the fan grille and blades.
LED light does not work.	Battery is depleted; Light button not pressed correctly.	Charge the fan. Press the light button firmly to cycle through modes.
Cannot charge external device.	Fan battery is too low; Incorrect cable/port used.	Ensure the fan has sufficient charge. Use the correct USB output port and a functional charging cable for your device.

8. SPECIFICATIONS

Feature	Detail
Brand	WESTTREE
Model Name	X26A Orange
Power Source	Battery Powered
Battery Capacity	20000mAh (Lithium Metal)
Charging Input	5V/3A via USB Type-C
USB Output	Yes (for power bank function)
Fan Blades	Double Blade Design
Adjustable Angle	270° Pivoting Head
Noise Level	<28 dB
LED Light	3 Brightness Settings
Dimensions (H x W x D)	10.8" x 8.5" x 4.7"
Item Weight	3.27 Pounds
Indoor/Outdoor Usage	Outdoor

9. WARRANTY AND SUPPORT

WESTTREE products are designed for reliability and performance. For any questions, technical support, or warranty claims, please contact WESTTREE customer service through the retailer's platform or the official WESTTREE website. Please retain your proof of purchase for warranty validation.

For more information, visit: [WESTTREE Brand Store](#)

