

Armocity DJ55

Armocity DJ55 55.2-inch Gaming Desk with Hutch and LED Lights Instruction Manual

Model: DJ55 | Brand: Armocity

1. SETUP AND ASSEMBLY

1.1 Unpacking and Component Check

Carefully unpack all components from the packaging. Verify that all parts listed in the included assembly guide are present and undamaged. If any parts are missing or damaged, please contact Armocity customer support.

1.2 Tools Required

- Phillips Head Screwdriver (not included, an electric screwdriver can expedite assembly)
- Included Hex Key

1.3 Assembly Steps

Follow the step-by-step instructions provided in the separate assembly manual included with your desk. Pay close attention to the orientation of parts, especially pieces 7 and 8, to ensure correct assembly. Using the correct screws for each step is crucial to prevent damage to the desk boards.




Figure 1: Desk Dimensions and Component Breakdown. This image illustrates the overall dimensions of the desk, including the hutch and monitor stand, and shows how the desk, bookshelf, and pegboard integrate into a single unit.

It is recommended that two people assemble this desk for easier and quicker completion.

2. OPERATING FEATURES

2.1 LED Lighting System

The desk features integrated LED lights. Control the light brightness, speed, and color using either the dedicated mobile application or the included RF remote control. The mobile application also supports music synchronization, allowing the lights to respond to audio played on your mobile device.




Figure 2: LED Light Control Options. This image displays the desk with its LED lights active, highlighting the two methods of control: a mobile app and an RF remote. It also notes features like RGB colors, a built-in microphone, and music synchronization.

To use the mobile app, download it by scanning the QR code provided in the assembly instructions.

2.2 Integrated Charging Station

The desk is equipped with a charging station featuring 3 standard outlets and 2 USB ports. This allows for convenient power access for various electronic devices such as lamps, phones, audio equipment, and PC monitors. The power cable length is 6.56 feet (2 meters). The charging station's design is reversible, allowing it to be installed on either the right or left side of the desk to suit user preference.



Reversible Outlets on Desk



Figure 3: Reversible Charging Station. This image shows two desks configured for a dual workstation setup, emphasizing the reversible nature of the integrated power outlets and USB ports on the desk surface.

2.3 Movable Monitor Stand

A movable monitor stand is included to help achieve an ergonomic viewing height for your monitor. Adjusting the monitor to eye level can promote a correct sitting posture and reduce strain during extended use.



Movable Monitor Stand is a Must Have for Your Correct Sitting Position

Figure 4: Ergonomic Monitor Stand. This image highlights the importance of the movable monitor stand for maintaining a correct sitting position, contrasting an incorrect posture with an ergonomically sound one.

2.4 DIY Pegboard and Storage Hutch

The desk features a versatile pegboard with four included hooks, allowing for customization and organization of tools, keys, headsets, or other accessories. The tall hutch provides additional shelving for storage, helping to keep the workspace tidy.



Figure 5: Desk Features Overview. This image provides a comprehensive view of the desk, labeling its various components and functionalities, including the pegboard, hutch, monitor stand, and charging station.

3. MAINTENANCE

3.1 Cleaning Instructions

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Ensure the charging station is unplugged before cleaning.

3.2 General Care

- Periodically check all screws and fasteners to ensure they remain tight.
- Avoid placing excessively hot or cold items directly on the desk surface without protection.
- Do not overload shelves or the desk surface beyond the recommended weight capacity.

4. TROUBLESHOOTING

4.1 Assembly Difficulties

- **Issue:** Parts do not align or fit together.
- **Solution:** Double-check the assembly manual for correct part orientation and ensure you are using the designated screws for each step. Incorrect screws can cause misalignment or damage.

4.2 LED Lights Not Functioning

- **Issue:** LED lights do not turn on or respond to controls.
- **Solution:** Ensure the LED light cable is securely plugged into a functional USB port on the charging station or another power source. Verify that the power strip is plugged into a wall outlet and turned on. Check the remote control battery or ensure the mobile app is correctly paired.

4.3 Charging Station Not Providing Power

- **Issue:** Outlets or USB ports on the charging station are not working.
- **Solution:** Confirm the desk's main power cord is securely plugged into a live wall outlet. Test the wall outlet with another device to ensure it is functional.

For issues not covered here, please refer to the contact information in the Support section.

5. SPECIFICATIONS

Feature	Detail
Brand	Armocity
Model Number	DJ55
Product Dimensions	55.2"D x 19.7"W x 29.1"H
Color	White and Dark Blue
Material	Metal (Base, Furniture Legs, Hutch), Wood (Tabletop)
Finish Type	Powder Coated
Special Feature	Reversible design, LED Lights, Charging Station, Pegboard
Maximum Weight Recommendation	550 Pounds
Item Weight	56 Pounds
Charging Station	3 Outlets, 2 USB Ports (6.56ft cable)
Assembly Required	Yes (Recommended 2 people)

6. WARRANTY AND SUPPORT

6.1 Warranty Information

Armocity offers a **2-year warranty** for this computer desk. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims.

6.2 Customer Support

For any questions regarding assembly, damaged parts, or product functionality, please contact Armocity customer support. Our team is available to assist you with any concerns.

Contact information can typically be found on the Armocity official website or through your purchase platform.

7. IMPORTANT SAFETY INFORMATION

- **Children are not allowed to climb on the computer gaming desk for safety use.**
- Ensure the desk is placed on a stable, level surface to prevent tipping.
- Do not exceed the maximum weight recommendation of 550 pounds.
- Keep liquids away from the charging station and electrical components.