

Timegyro B0C2PNY3SV

Timegyro Digital Alarm Clock (Model B0C2PNY3SV) User Manual

Your guide to setting up and using your Timegyro Digital Alarm Clock.

Overview	Features	Setup	Operation	Maintenance & Support	Troubleshooting	Specifications	Warranty
--------------------------	--------------------------	-----------------------	---------------------------	---	---------------------------------	--------------------------------	--------------------------

1. PRODUCT OVERVIEW

The Timegyro Digital Alarm Clock (Model B0C2PNY3SV) is a battery-operated LED display clock designed for bedrooms and various indoor settings. It features a long battery life, adjustable brightness, 12/24 hour display modes, and a convenient snooze function. Its compact and portable design makes it suitable for use as a desk clock, bedside clock, or travel clock.



Figure 1: Front view of the Timegyro Digital Alarm Clock.

2. KEY FEATURES

- **Battery Operated:** Powered by 4 AA batteries, providing over 1 year of operation. No USB ports or power cords required, allowing flexible placement.
- **Adjustable Brightness:** Three brightness levels to suit your preference. Includes a Night-Mode that automatically dims the display between 8:00 PM and 6:00 AM to prevent dazzling.
- **LED Digital Display:** Clear and easy-to-read LED display.
- **12/24 Hour Mode:** Easily switch between 12-hour and 24-hour time formats.
- **Snooze Function:** Press the top button to activate a 7-minute snooze, repeatable up to 3 times.
- **Compact and Portable:** Dimensions of 5.1 x 1.5 x 2.6 inches, making it ideal for desks, bedside tables, or travel.



Figure 2: Overview of key features including easy setting, snooze, 12/24 hour format, and daily alarm.

3. SETUP GUIDE

3.1. Battery Installation

1. Locate the battery compartment cover on the back of the clock.
2. Slide the cover off to open the compartment.
3. Insert 4 new AA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover.

I Three Levels of Brightness

Set three levels of the LED brightness to ensure it will not disturb you.



Figure 3: Rear view of the clock, highlighting the battery compartment and control buttons.

3.2. Initial Time Setting

1. Press the **TIME SET** button located on the back of the clock. The hour digits will begin to flash.
2. Use the **HOUR (12/24)** button to adjust the hour. Press and hold for faster adjustment.
3. Press the **TIME SET** button again. The minute digits will flash.
4. Use the **MIN (AL ON/OFF)** button to adjust the minutes. Press and hold for faster adjustment.
5. Press the **TIME SET** button one more time to confirm the time setting.

4. OPERATING INSTRUCTIONS

4.1. Setting the Alarm

1. Press the **AL SET** button. The alarm hour digits will flash.
2. Use the **HOUR (12/24)** button to set the desired alarm hour.
3. Press the **AL SET** button again. The alarm minute digits will flash.
4. Use the **MIN (AL ON/OFF)** button to set the desired alarm minutes.
5. Press the **AL SET** button one more time to confirm the alarm setting.

4.2. Turning Alarm On/Off

To turn the alarm on or off, press the **MIN (AL ON/OFF)** button when not in time or alarm setting mode. An alarm icon will appear on the display when the alarm is active.

4.3. Snooze Function

When the alarm sounds, press the large **SNOOZE/STOP** button on the top of the clock. The alarm will pause for 7 minutes and then sound again. This can be repeated up to 3 times.



Figure 4: Activating the snooze function by pressing the top button.

4.4. Adjusting Brightness

Use the brightness switch (indicated by a light bulb icon) on the back of the clock to select one of the three available brightness levels. The clock also features a Night-Mode that automatically adjusts brightness between 8:00 PM and 6:00 AM.



Figure 5: The three adjustable brightness levels of the LED display.

4.5. 12/24 Hour Mode Selection

Press the **HOUR (12/24)** button when not in time or alarm setting mode to toggle between 12-hour (AM/PM) and 24-hour (military time) display formats.

12-hour / 24-hour switchable

**12-hour
(Standard Time)**



**24-hour
(Military Time)**



Figure 6: Demonstrating the 12-hour and 24-hour display modes.

5. MAINTENANCE

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace all 4 AA batteries when the display becomes dim or the clock stops functioning. Ensure to use fresh batteries and dispose of old batteries responsibly.
- **Storage:** If storing the clock for an extended period, remove the batteries to prevent leakage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is blank or dim.	Low or dead batteries. Incorrect battery installation.	Replace all 4 AA batteries with new ones. Ensure batteries are inserted with correct polarity.

Problem	Possible Cause	Solution
Alarm does not sound.	Alarm is not activated. Alarm volume is too low (if applicable). Incorrect alarm time set.	Ensure the alarm is turned ON (check for alarm icon on display). Verify the alarm time is set correctly.
Time is incorrect.	Time was not set correctly.	Follow the "Initial Time Setting" instructions to reset the time.
Snooze function not working.	Snooze button not pressed correctly.	Ensure the top SNOOZE/STOP button is pressed firmly when the alarm is sounding.

If you continue to experience issues, please contact customer support.

7. PRODUCT SPECIFICATIONS

- **Brand:** Timegyro
- **Model:** B0C2PNY3SV
- **Color:** Black case with Blue Digits
- **Display Type:** Digital LED
- **Power Source:** 4 x AA Batteries (not included)
- **Product Dimensions:** 5.1" (W) x 1.5" (D) x 2.6" (H) (approximate, based on feature bullets)
- **Item Weight:** 0.13 Kilograms
- **Special Features:** Alarm, Snooze, 3 Brightness Levels, 12/24 Hour Mode, Night-Mode
- **Material:** Plastic
- **Room Type:** Bedroom, Dining Room, Home Office, Kid's Room, Kitchen

8. PRODUCT VIDEOS

8.1. Timegyro Digital Alarm Clock Review

Your browser does not support the video tag.

Video 1: An honest review of the Timegyro Digital Alarm Clock, highlighting its features and battery operation.

8.2. Alarm Clock Overview

Your browser does not support the video tag.

Video 2: A brief overview of the alarm clock's design and functionality.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided in your product packaging or reach out to Timegyro customer service.

Customer Service Email: chaorong@shenzhenchaorong.com

