Ninja BN400

Ninja BN400 Nutri Pro Compact Personal Blender User Manual

Model: BN400 | Brand: Ninja

1. Important Safety Instructions

Please read all instructions carefully before using your Ninja BN400 Nutri Pro Compact Personal Blender. Failure to follow these instructions may result in injury or damage to the appliance.

- Always ensure the motor base is placed on a clean, dry, and level surface.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the container while blending to reduce the risk of severe injury to persons or damage to the blender.
- **Caution:** The Pro Extractor Blades Assembly is extremely sharp. Handle with care to avoid injury. Always hold the blade assembly by its base.
- Never operate the blender with an empty cup.
- Do not overfill the cups beyond the 'MAX FILL' line.
- Ensure the blade assembly is securely tightened onto the cup before placing it on the motor base. The blender will not operate unless the cup and blade assembly are correctly locked into place.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.

2. What's in the Box

Your Ninja BN400 Nutri Pro Compact Personal Blender package includes the following components:

- 1000-Watt Motor Base
- 18 oz. Single Serve Cup
- 24 oz. Single Serve Cup
- Pro Extractor Blades Assembly
- Two (2) Spout Lids

What's in the box



Image: All components included with the Ninja BN400 Nutri Pro Compact Personal Blender, laid out on a kitchen counter.

3. Setup

1. **Place the Motor Base:** Position the 1000-watt motor base on a clean, dry, and level countertop. The base features suction cups on the bottom to ensure stability during operation.
2. **Prepare Ingredients:** Add your desired ingredients into either the 18 oz. or 24 oz. single-serve cup. Ensure that the ingredients do not exceed the 'MAX FILL' line indicated on the cup.
3. **Attach Blade Assembly:** Screw the Pro Extractor Blades Assembly onto the open end of the cup until it is securely tightened.
4. **Mount on Motor Base:** Invert the cup and blade assembly, then place it onto the motor base. Twist the cup clockwise until it clicks and locks into place. The control panel lights will illuminate, indicating the blender is ready for operation.




NINJA
START/
STOP
CRUSH
45
SMOOTHIE
PULSE
AUTO iQ

Image: The Ninja BN400 Nutri Pro Compact Personal Blender fully assembled and ready for use.

4. Operating Instructions

The Ninja BN400 features Auto-iQ Technology with intelligent programs for consistent results.

- **Auto-iQ Programs:** The blender offers two pre-set Auto-iQ programs:**CRUSH** and **SMOOTHIE**. These programs are uniquely timed to deliver optimal results for frozen drinks and smoothies, eliminating guesswork. Simply press the desired program button, and the blender will automatically start, pause, and stop as needed.
- **Manual Control:** For manual operation, use the**START/STOP** button to begin blending and press it again to stop. The **PULSE** button provides short bursts of power for controlled chopping or mixing.



Image: The illuminated control panel of the Ninja BN400, highlighting the Auto-iQ programs for Crush and Smoothie.

Blending Tips:

- For best results with smoothies, use the dedicated **SMOOTHIE** Auto-iQ program.
- When crushing ice, utilize the **CRUSH** Auto-iQ program for efficient pulverization.
- If ingredients are not blending evenly, remove the cup from the base, shake it, and re-attach to continue blending.

5. Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your blender.

- **Dishwasher Safe:** The cups, spout lids, and Pro Extractor Blades Assembly are all dishwasher safe. Place them on the top rack of your dishwasher.
- **Hand Washing:** For hand washing, use warm, soapy water. Rinse thoroughly.
- **Immediate Rinsing:** To prevent food residue from drying and sticking, rinse the cups and blade assembly immediately after use. This makes cleaning significantly easier, especially around the ridges of the cups and the sharp edges of the blades.
- **Motor Base Cleaning:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
- **Blade Caution:** Always handle the Pro Extractor Blades Assembly with extreme care. The blades are very sharp. Avoid touching the sharp edges directly with your fingers.




Image: Detached cups, lids, and blade assembly of the Ninja BN400 placed in a dishwasher for cleaning.

6. Troubleshooting

- **Blender Not Starting:** Ensure the cup with the blade assembly is securely twisted and locked onto the motor base. The control panel lights should illuminate when correctly seated. If not, remove and re-attach the cup, twisting firmly until it clicks.
- **Ingredients Not Blending:** If ingredients are stuck or not circulating, remove the cup from the motor base, shake it gently, and then re-attach it. You may also need to add more liquid.
- **Overheating:** If the motor stops unexpectedly, it may be due to overheating. Unplug the unit and allow it to cool down for at least 15 minutes before attempting to use it again. Reduce the load or amount of ingredients if this occurs frequently.

7. Specifications

Brand	Ninja
Model	BN400
Power	1000 Watts
Capacity	18 oz. & 24 oz. Single Serve Cups
Special Feature	Programmable, Single Serve, Auto-iQ Technology
Control Type	Push Button, Preset Programs
Material	Plastic, Stainless Steel
Product Dimensions	6.34 x 6.94 x 14.29 inches
Item Weight	7.6 pounds

8. Warranty and Support

The Ninja BN400 Nutri Pro Compact Personal Blender comes with a**90-day limited warranty**. For warranty claims or technical support, please refer to the contact information provided in your product packaging or visit the official Ninja website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question